

UNCLASSIFIED

AD NUMBER

AD869323

LIMITATION CHANGES

TO:

Approved for public release; distribution is unlimited.

FROM:

Distribution authorized to U.S. Gov't. agencies and their contractors; Critical Technology; FEB 1970. Other requests shall be referred to U.S. Army Aviation Materiel Laboratories, Fort Eustis, VA 23604. This document contains export-controlled technical data.

AUTHORITY

USAAMRL ltr, 23 Jun 1971

THIS PAGE IS UNCLASSIFIED

AD 869323

AB

**USAALABS TECHNICAL REPORT 69-10B
ADVANCEMENT OF SMALL GAS TURBINE
COMPONENT TECHNOLOGY
ADVANCED SMALL AXIAL COMPRESSOR
VOLUME II - TEST AND REDESIGN**

By

James V. Davis

Edmund J. Deller

February 1970

**U. S. ARMY AVIATION MATERIEL LABORATORIES
FORT EUSTIS, VIRGINIA**

CONTRACT DA 44-177-AMC-296(T)

CONTINENTAL AVIATION AND ENGINEERING CORPORATION


DETROIT, MICHIGAN

This document is subject to special
export controls, and such transmittal
to foreign governments or foreign
nationals may be made only with
prior approval of US Army Aviation
Materiel Laboratories, Fort Eustis,
Virginia 23604.



113

DISCLAIMER NOTICE



**THIS DOCUMENT IS BEST
QUALITY AVAILABLE. THE COPY
FURNISHED TO DTIC CONTAINED
A SIGNIFICANT NUMBER OF
PAGES WHICH DO NOT
REPRODUCE LEGIBLY.**

ACCESSION FOR	
OFSTL	WHITE SECTION
DOC	SUFF SECTION
UNARMED	
INSTRUCTION	
DISTRIBUTION / AVAILABILITY CODE	
DIST.	AYAH
SPECIAL	

DISCLAIMERS

The findings in this report are not to be construed as an official Department of the Army position unless so designated by other authorized documents.

When Government drawings, specifications, or other data are used for any purpose other than in connection with a definitely related Government procurement operation, the United States Government thereby incurs no responsibility nor any obligation whatsoever; and the fact that the Government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission, to manufacture, use, or sell any patented invention that may in any way be related thereto.

DISPOSITION INSTRUCTIONS

Destroy this report when no longer needed. Do not return it to the originator.



DEPARTMENT OF THE ARMY
U. S. ARMY AVIATION MATERIEL LABORATORIES
FORT EUSTIS, VIRGINIA 23604

The research described herein was conducted by Continental Aviation and Engineering Corporation under U.S. Army Contract DA 44-177-AMC-296(T). The work was performed under the technical management of Mr David B. Cale, Propulsion Division, U.S. Army Aviation Materiel Laboratories.

Appropriate technical personnel of this Command have reviewed this report and concur with the conclusions contained herein.

The findings and recommendations outlined herein will be considered in the planning of future axial compressor programs.

This is the second volume of a two-volume report. Volume I, USAAVLABS Technical Report 69-10A, covers the analysis and design. This volume covers test and redesign. The aerodynamic redesign portion of this volume is published as a classified addendum under separate cover.

Task 1G162203D14413
Contract DA 44-177-AMC-296 (T)
USAAVLABS Technical Report 69-10B
February 1970

**ADVANCEMENT OF SMALL GAS TURBINE
COMPONENT TECHNOLOGY**

ADVANCED SMALL AXIAL COMPRESSOR

VOLUME II - TEST AND REDESIGN

Continental Report 1033

By

**James V. Davis
Edmund J. Dellert**

Prepared By

**Continental Aviation and Engineering Corporation
Detroit, Michigan**

for

**U.S. ARMY AVIATION MATERIEL LABORATORIES
FORT EUSTIS, VIRGINIA**

This document is subject to special export controls,
and each transmittal to foreign governments or
foreign nationals may be made only with prior ap-
proval of US Army Aviation Materiel Laboratories,
Fort Eustis, Virginia 23604.

SUMMARY

This report presents the preliminary design and analysis of an advanced axial-centrifugal compressor for small gas turbines, and the detail design of the axial stages.

The program objective was to advance and demonstrate efficient high-pressure-ratio axial compressor technology to a level where, when matched analytically with both the advanced centrifugal compressor technology supplied by U. S. Army Aviation Materiel Laboratories (USAAVLABS) and the conventional engine component characteristics, a potential for a 0.460-pound-per-horsepower-hour specific fuel consumption (SFC) turboshaft engine at 2500°F turbine inlet gas temperature would be provided.

This volume discusses the fabrication, tests, and redesign of the axial compressor. The original axial compressor design (Volume I) was fabricated and tested. The axial compressor performance was capable of providing a potential for a 0.484-pound-per-horsepower-hour SFC turboshaft engine at 2500°F turbine inlet gas temperature. However, a low flow problem prevented the compressor from achieving the target efficiency.

The compressor was redesigned, fabricated, and tested. This compressor performance exceeded the contract objective by demonstrating 80 -percent efficiency at 3.1:1 pressure ratio with a 4.91 lb/sec airflow, thus providing a potential for a 0.457-pound-per-horsepower-hour specific fuel consumption turboshaft engine at 2500°F turbine inlet gas temperature.

FOREWORD

This program is sponsored by the United States Army Aviation Material Laboratories under Contract DA44-177-AMC-296(T), Task 1G162203D14413.

This report, prepared by Continental Aviation and Engineering Corporation, presents Phase II and Phase III of a small axial compressor program for the advancement of small gas turbine component technology.

The detailed aerodynamic redesign of the compressor is presented in an addendum of Volume II under separate cover.

The details of the compressor concept definition and compressor mechanical design are included in Volume I. The original compressor design is published under separate cover as an addendum of Volume I.

TABLE OF CONTENTS

	<u>Page</u>
SUMMARY	iii
FOREWORD	v
LIST OF ILLUSTRATIONS	viii
LIST OF TABLES	xiv
INTRODUCTION	1
DISCUSSION	2
Fabrication of Original Design	2
Apparatus and Procedures	4
First Rig Test of Axial Compressor	21
Second Rig Test of Axial Compressor	59
Third Rig Test of Axial Compressor	62
Compressor Redesign	62
Mechanical and Structural Compressor Redesign .	68
FABRICATION OF REDESIGNED COMPRESSOR	83
Rotor Assembly	83
Stator Assembly	83
Inlet Guide Vane Assembly	87
FINAL RIG TEST OF REDESIGNED COMPRESSOR	88
Aerodynamic Test Results	88
Mechanical Test Results	98
CONCLUSIONS	104
RECOMMENDATIONS	105
APPENDIXES	
I. Description of Traverse Data Computer Output .	107
II. Computer Output of Traverse Data for Compressor - Original Design	118
III. Computer Output of Traverse Data for Compressor Redesign	138
DISTRIBUTION	158

LIST OF ILLUSTRATIONS

<u>Figure</u>		<u>Page</u>
1	Advanced Axial Compressor Test Rig Design Layout	2
2	Rotor Assembly - Electron Beam Weldment	3
3	First-Stage Stator Assembly	5
4	Second-Stage Stator Assembly	5
5	Compressor Test Cell 1400 No. 1 Layout	7
6	Compressor Installation - 1400 No. 1 Test Cell . .	9
7	Compressor Test Cell 1400 No. 2 Layout	11
8	Compressor Installation - 1400 No. 2 Test Cell . .	13
9	Inlet Duct Probe Calibration	16
10	Exit Duct Probe Calibration	16
11	Survey Probe Calibration	20
12	Survey Probe Calibration - Fully Shielded	20
13	Axial Compressor Map - First Rig Test	22
14	Axial Compressor First Rig Test - Transition Duct Exit Temperature and Pressure Ratio Data	24
15	Axial Compressor First Rig Test - Transition Duct Exit Mach Number and Efficiency Data	25
16	Axial Compressor First Rig Test - Static Pressure Distribution Along Compressor Tip	26
17	Axial Compressor First Rig Test - Transition Duct Static Pressure Distribution	27
18	Axial Compressor Rotor One - Deviation and Incidence Angle Along Blade Radial Height.	28

LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Page</u>
19 Axial Compressor Rotor One - Exit and Inlet Relative Mach Number Along Blade Radial Height	29
20 Axial Compressor Rotor One - Exit Mach Number and Diffusion Factor Along Blade Radial Height	30
21 Axial Compressor Rotor One - Adiabatic Efficiency and Pressure Loss Coefficient Along Blade Radial Height	31
22 Axial Compressor Rotor One - Temperature and Pressure Ratio Along Blade Radial Height	32
23 Axial Compressor Stator One - Incidence and Absolute Inlet Air Angle Along Blade Radial Height	33
24 Axial Compressor Stator One - Inlet and Exit Mach Number Along Blade Radial Height	34
25 Axial Compressor Stator One - Pressure Loss and Diffusion Factor Along Blade Radial Height	35
26 Axial Compressor Stator One - Adiabatic Efficiency and Pressure Loss Coefficient Along Blade Radial Height	36
27 Axial Compressor Stator One - Static Temperature and Pressure Ratio Along Blade Radial Height	37
28 Axial Compressor Rotor Two - Deviation and Incidence Angle Along Blade Radial Height	38
29 Axial Compressor Rotor Two - Inlet and Exit Mach Number Along Blade Radial Height	39
30 Axial Compressor Rotor Two - Exit Axial Mach Number and Diffusion Factor Along Blade Radial Height	40

LIST OF ILLUSTRATIONS

<u>Figure</u>		<u>Page</u>
31	Axial Compressor Rotor Two - Adiabatic Efficiency and Pressure Loss Coefficient Along Blade Radial Height	41
32	Axial Compressor Rotor Two - Temperature and Pressure Ratio Along Blade Radial Height	42
33	Axial Compressor Stator Two - Incidence and Air Inlet Angle Along Blade Radial Height	43
34	Axial Compressor Stator Two - Exit and Inlet Mach Number Along Blade Radial Height	44
35	Axial Compressor Stator Two - Pressure Loss and Diffusion Factor Along Blade Radial Height	45
36	Axial Compressor Stator Two - Adiabatic Efficiency and Pressure Loss Coefficient Along Blade Radial Height	46
37	Axial Compressor Stator Two - Temperature and Pressure Ratio Along Blade Radial Height	47
38	First- and Second-Stage Axial Compressor Head Coefficient Versus Flow Coefficient	49
39	Erosion of Feltmetal Rotor Shroud Material in First Stage of USAAVLABS Two-Stage 3:1 Compressor Test Rig	50
40	Typical Section, USAAVLABS First-Stage Rotor Passage Area	53
41	USAAVLABS First-Stage Rotor Passage Area Distribution	55
42	USAAVLABS First-Stage Rotor - Comparison of Hub Contours	58
43	Advanced Two-Stage Axial Compressor Rig Test - Hub Relief	60

LIST OF ILLUSTRATIONS

<u>Figure</u>		<u>Page</u>
44	First-Stage Stator Assembly Showing Deep Groove on Labyrinth Seal Rub Ring	61
45	Advanced Two-Stage Axial Compressor Rig Test - Blade Twist	63
46	Two-Stage Axial Compressor - Original Design . . .	64
47	The Effect of Solidity on Shock Location for Supersonic Cascades	66
48	Comparison of USAAVLABS First-Stage Flow Paths	69
49	Phase III Compressor - First-Stage Rotor Disc Radial and Centrifugal Stress	72
50	Phase III Compressor - First-Stage Rotor Blades Gas Force Intensity	73
51	Phase III Compressor - First-Stage Rotor Blade Centrifugal Stress	74
52	Phase III Compressor - First-Stage Rotor Blade Centrifugal Untwist Stress	74
53	Phase III Compressor - First-Stage Rotor Blade Gas Bending Stress	75
54	Phase III Compressor - First-Stage Rotor Blade Modified Goodman Diagram	76
55	USAAVLABS Phase III Compressor - First-Stage Rotor Blade Interference Diagram	77
56	USAAVLABS Phase III Compressor - Second Stage Rotor Disc Radial and Tangential Stress	78
57	USAAVLABS Phase III Compressor - Second-Stage Rotor Blade Gas Force Intensity	78

LIST OF ILLUSTRATIONS

<u>Figure</u>		<u>Page</u>
58	USA AVLabs Phase III Compressor - Second-Stage Rotor Blade Centrifugal Stress	79
59	USA AVLabs Phase III Compressor - Second-Stage Rotor Blade Centrifugal Untwist Stress	79
60	USA AVLabs Phase III Compressor - Second-Stage Rotor Blade Gas Bending Stress	80
61	USA AVLabs Phase III Compressor - Second-Stage Rotor Blade Modified Goodman Diagram.	81
62	USA AVLabs Phase III Compressor - Second-Stage Rotor Blade Interference Diagram.	82
63	Redesigned Welded Rotor Assembly	84
64	Redesigned First-Stage Stator and Compressor Housings	85
65	Redesigned First-Stage Stator Showing EDM Cut in Vane Tip	86
66	Redesigned Variable Inlet Guide Vane Assembly . .	87
67	The Effect of Overall Axial-Centrifugal Compressor Pressure Ratio and Axial Compressor Performance on Brake Specific Fuel Consumption	89
68	USA AVLabs Centrifugal Compressor Technology Performance Along Given Operating Line	90
69	USA AVLabs Two-Stage Transonic Axial Compressor Performance	92
70	Two-Stage Axial Compressor Transition Duct Exit Performance at Compressor Design Speed - Efficiency and Pressure Ratio	93

LIST OF ILLUSTRATIONS

<u>Figure</u>		<u>Page</u>
71	Two-Stage Axial Compressor Transition Duct Exit Performance at Compressor Design Speed - Mach Number and Absolute Velocity	94
72	Two-Stage Axial Compressor Transition Duct Exit Triangle for a Centrifugal Compressor Inducer Inlet at Design RPM	95
73	Parametric Results of a Family of Centrifugal Compressors Operating in Single-Spool Configuration Behind USAAVLABS Two-Stage Axial Compressor	96
74	Advanced Two-Stage Axial Compressor Transition Duct Total Pressure Loss	98
75	Static Pressure Distribution Along Compressor Tip	99
76	Two-Stage Compressor Transition Duct Exit Static Pressure Distribution	100
77	Transonic Two-Stage Axial Compressor - The Effect of Variable Inlet Guide Vane Setting Angle on 100-Percent Design Speed Compressor Performance . .	101
78	Transonic Two-Stage Axial Compressor - The Effect of Variable Inlet Guide Vane Setting Angle on 100-Percent Design Speed Compressor Performance . .	102
79	Advanced Two-Stage Compressor Comparison of Nominal and +20 Degree Inlet Guide Vane Stagger Angle on Compressor Performance	103

LIST OF TABLES

<u>Table</u>		<u>Page</u>
I	First-Stage Rotor Modification Possibilities.	56
II	Analysis of High-Pressure-Ratio Axial Rotors	67
III	Summary of Phase III Component Redesign	70
IV	Computer Output of Traverse Data for Compressor - Original Design - Test Number 19	118
V	Computer Output of Traverse Data for Compressor - Original Design - Test Number 20	123
VI	Computer Output of Traverse Data for Compressor - Original Design - Test Number 21	128
VII	Computer Output of Traverse Data for Compressor - Original Design Test Number 22	133
VIII	Computer Output of Traverse Data for Compressor - Redesign - Test Number 15	138
IX	Computer Output of Traverse Data for Compressor - Redesign - Test Number 16	143
X	Computer Output of Traverse Data for Compressor - Redesign - Test Number 17	148
XI	Computer Output of Traverse Data for Compressor - Redesign - Test Number 18	153

INTRODUCTION

This report presents the work accomplished in Phases II and III of Contract DA 44-177-AMC-296(T) for the United States Army Aviation Materiel Laboratories, Fort Eustis, Virginia.

The project objectives are to advance and demonstrate efficient high-pressure-ratio axial compressor technology to the level where, when matched analytically with the advanced centrifugal compressor technology supplied by USAAVLABS and the conventional engine component characteristics, a potential for a 0.460-pound-per-horsepower-hour SFC turboshaft engine at 2500°F turbine inlet gas temperature will be provided.

The Phase I objectives are presented in Volume I.

The Phase II objectives were to fabricate and test the axial compressor to determine basic performance and to provide aerodynamic data for any necessary modification of the blade rows. An additional test of a modified compressor was to be conducted.

The Phase III objective was to redesign the axial compressor using the Phase II aerodynamic data as the basis for aerodynamic direction. The redesigned compressor was to be fabricated and tested to determine basic performance.

DISCUSSION

FABRICATION OF ORIGINAL DESIGN

General Fabrication Techniques

The Continental-designed compressor rig, Figure 1, is primarily an aerodynamic research vehicle, with the structural design emphasizing mechanical integrity, ease of assembly and instrumentation, and reasonable cost, wherever possible. Consequently, the majority of the stationary hardware fabrication was straightforward utilizing weldments and other common techniques. However, the manufacturing techniques used in the rotor and stator assemblies were somewhat more complex and are discussed in the following paragraphs.




Figure 1. Advanced Axial Compressor Test Rig Design Layout.

Rotor Assembly

The integrally bladed rotors and the rear shaft, each machined from a solid AMS 5616 forging, were joined into a unitized assembly by electron-beam welding. The weld joints on the rotor assembly are shown in Figure 2. Two rotor assemblies were fabricated in this manner.

Electron-Beam Weld Joints




Figure 2. Rotor Assembly - Electron Beam Weldment.

After welding of the first rotor assembly, radiographic (X-Ray) inspection revealed extensive porosity throughout the weld. The short span between the first- and second-stage rotors prevented the use of X-Ray techniques and porosity depth repair procedures. Therefore, prior to welding the second rotor assembly, an extensive weld qualification technique was developed and is summarized as follows:

1. Establish basic weld parameters by using a sample bead weld on plate.
2. Evaluate joint configuration using flat plates by:
 - a. X-Ray examination
 - b. Macroscopic examination of the weld.
3. Evaluate joint configuration using circular components in the same manner as above.

4. Weld rotor assembly

- a. Examine by fluorescent penetrant**
- b. Examine by X-Ray**

During the course of establishing the qualification technique, it was determined that the operator's skill in focusing the electron beam and subtle changes in the operation of the beam filament were major factors in producing a sound weld.

Use of this technique resulted in an acceptable weld for the second rotor assembly. Maximum runout after welding was 0.003 inch; the total indicator reading after stress relief was 0.007 inch. The excessive runout condition after stress relief was corrected by heat straightening.

Final machining of the rotor assembly was accomplished following acceptance of the welds. Excess stock was provided in critical areas, such as bearing journals and labyrinth seals, so that any misalignment resulting from the welding operation could be readily corrected.

Stator Assembly

The individual contours of both the first- and second-stage stator vanes were machined by conventional methods from AISI 410 stainless steel.

The assembly of both stators was similar. The electron discharge machining (EDM) of the vane slots, in the inner and outer shrouds, was accomplished by using the vane section as an electrode. The vanes were then placed in the slots and brazed in place (Figures 3 and 4).

Variations in vane thickness made it necessary to hand rework and fit each vane in a particular slot. In addition, holding fixtures were needed to maintain vane positioning during the brazing process.

APPARATUS AND PROCEDURES

Test Cell Installation

The compressor, with the integrally mounted speed increaser was adapted as a package to the test cell and driving facilities. Input torque for this package is restricted by the integral speed increaser



Figure 3. First-Stage Stator Assembly.




Figure 4. Second-Stage Stator Assembly.

to approximately 360 horsepower at the compressor design speed of 59,600 rpm. Consequently, in order to decrease the horsepower requirements, the compressor had to be operated at reduced inlet pressures up to 24 inches of mercury absolute at design point.

Two test cells can accommodate the compressor: the 1400 No. 1 or the 1400 No. 2. These test cells are in adjacent areas arranged back-to-back such that two reversible, 700-horsepower, electrical dynamometers can be coupled in series for 1400 horsepower to either cell or operated independently for 700 horsepower in each cell. Each cell provides lubrication services, inlet air temperature regulation from 300°F to -65°F, inlet air pressure regulation from 40 inches of mercury absolute to highly depressed conditions, and exhaust services ranging from atmospheric to high vacuum conditions.

The original compressor design was installed and tested in 1400 No. 1 test cell (Figures 5 and 6). This cell provides airflow measurement by means of an ASME nozzle station with the cell inlet plenum. Drive provision was from the intermediate shaft of a two-stage, 2500-horsepower, 42,000-rpm, 21:1 ratio gearbox. The first-stage ratio of this gearbox is 6.93:1 (1386 rpm) so that operation ranging to less than half speed adequately accommodate the input to the compressor/integral speed increaser package.

The redesigned compressor was installed and tested in 1400 No. 2 test cell (Figures 7 and 8). Installation of the No. 2 test cell required airflow measurement by means of a previously calibrated compressor inlet station because no cell measurement station was provided. Drive provision was from an intermediate shaft of a two-stage, 1400-horsepower, 42,000-rpm, 21:1 ratio gearbox. The first-stage ratio of this gearbox is 3.263:1 (65 rpm); due to its design of twin load-sharing intermediate shafts, it is limited to 700 horsepower at 6500 rpm. Operation ranging to 80 percent speed adequately provided the input to the compressor/integral speed increaser package.

Adjacent to each test cell is its respective control room, which provides instrumentation read-out equipment for both aerodynamic and mechanical units, control of service equipment, and control of the drive systems. Inlet air temperature and pressure, drive speeds, discharge air pressure, and required service equipment such as flowpath traversing instrumentation, oil pressure, and oil temperature are regulated remotely from the control rooms to provide the desired ranges for test operation.





Figure 5. Compressor Test Cell 1400 No. 1 Layout.



out.

B




Figure 6. Compressor Installation - 1400 No. 1 Test Cell.

Test Procedure

Both the original design and the redesigned compressors were run at low speed to check mechanical integrity and then gradually accelerated from 50 to 100 percent of design speed in increments of 10 percent with the exit throttle valve open. The abradable shrouds were inspected at intervals of 50, 70, 90, and 100 percent of design speed. The compressor map was defined by setting a specific speed and gradually closing the throttle valve to determine the speed line. Approximately five data points, at different flow rates, were obtained for each speed line. Surge was determined by observing fluctuations in the exit manometers and the inlet flow manometers. Traverse data were obtained at selected points after the compressor map was defined.

Aerodynamic Instrumentation

In general, the same aerodynamic instrumentation was used for both the original design and the redesigned compressors, except for the methods of airflow measurement and the presence of traverse probes in the original design compressor. The different methods of flow measurement, as described below, were necessitated by the lack of a nozzle station in the 1400 No. 2 test cell.

Specific instrumentation installations for both compressor configurations are discussed in the following paragraphs.

Compressor Inlet. The compressor inlet conditions were measured in the tapered inlet transition duct at a plane 4.0 inches forward of the compressor inlet housing. The rake instrumentation was equally spaced at four points across the duct inner radius of 3.30 inches. The temperature was measured with four bare wire iron-constantan temperature probes. The inlet total pressure was measured by four elements of 0.062-inch diameter with a 30-degree internal taper. One inlet duct wall static was provided at this plane for Mach number correction of the temperature rake.

Compressor Exit. The compressor exit incorporated one three-element total pressure rake, positioned 0.075 inch behind the trailing edge of the second-stage stator vane and centered between vanes. The three elements were equally spaced across the 0.545 inch passage and fabricated from 0.040-inch tubing. Two outside diameter wall static taps were installed 90 degrees apart, approximately 0.020 inch behind the trailing edge of the stator and centered between vanes.





Figure 7. Compressor Test Cell 1400 No. 2 Layout.



you.

B




Figure 8. Compressor Installation - 1400 No. 2 Test Cell.

Transition Duct. Instrumentation at the exit of the transition duct consisted of three 3-element total pressure probes and three 3-element total temperature probes. The temperature probes were bare wire iron-constantan thermocouples, and the pressure probes were fabricated from 0.040-inch tubing. Elements were equally spaced across the 0.889-inch passage width. The rakes were circumferentially spaced 120 degrees apart. The sensing plane was located at approximately 0.190 inch behind the mating surface of the rear bearing housing and the transition duct. Two outside diameter and one inside diameter wall static pressure taps were installed at this plane.

Wall static instrumentation through the transition duct consisted of three static pressure taps - two at the outside diameter, 90 degrees apart, and one at the blade diameter - at each of three locations evenly spaced axially between the duct inlet and the duct exit.

Interstage Stat. Pressure Instrumentation

Instrumentation through this section consisted of outside diameter wall static pressure taps installed in pairs, 90 degrees apart, at the following locations:

1. At the center of the variable inlet guide vane housing flange, one between the vanes and another in line with a vane.
2. At the first-stage rotor inlet, opposite the point of intersection of the rotor leading edge with the hub.
3. At the inlet to the first-stage stator, slightly ahead of the leading edge.
4. At the exit of the first-stage stator, slightly behind the trailing edge.
5. In line with the leading edge of the second-stage stator.

Inlet Airflow. With the redesigned compressor, the airflow was measured, using an airflow coefficient established by calibration of the inlet assembly against a 4.00- and a 5.00-inch ASME nozzle, over the flow range of 1.65 to 5.00 pounds per second. An average coefficient of 0.1553 was established for use with a conventional airflow calibration curve. The inlet total pressure was measured by four wall static pressure taps manifolded together and located in the inlet plenum forward of the inlet transition duct. To establish the pressure drop, two wall static

pressure taps, located in the inlet housing, were manifolded and teed to the inlet plenum pressure. On the original design compressor, airflow was measured with a 5-inch ASME nozzle mounted in the inlet plenum upstream of the compressor.

Traverse Probes. Actuated total pressure cobra probes and bare wire iron-constantan total temperature probes were installed axially behind each rotor on the original design compressor. The leading edge of one stator vane was removed to enable the probes to traverse radially.

No traverse probes were utilized on the redesigned compressor.

Mechanical Instrumentation

The compressor assembly incorporated the usual rotating component rig instrumentation consisting of thermocouples on each of the bearing outer races, oil-in and -out temperatures and pressures, and vertical and horizontal accelerometers mounted on the front and rear of the compressor housing.

In addition, strain gages were mounted on two beams of the front bearing cage, at 90-degree spacing, to detect shaft oscillations transmitted through the cantilevered cage, thereby giving an indication of shaft motion relative to the housing.

The signals from the strain gages were fed into a dual beam oscilloscope, where they could be displayed in sine wave or orbit form.

Data Reduction

Overall Data. The average inlet total temperature was established by arithmetically averaging the four thermocouple temperature readings at the inlet station. The average inlet total pressure was established by manifolding the four manometers connected to the four inlet pressure probes. The exit conditions were measured in a similar manner to the inlet conditions.

Since the Mach number at the inlet plane and at the exit plane is high enough to cause velocity effects on the total temperature probe, the inlet probes were calibrated against a known source as a function of Mach number. The calibrations for each test are shown in Figures 9 and 10. The method of obtaining the actual temperature is summarized in the following:




Figure 9. Inlet Duct Probe Calibration.

- - Rake No. 1, Calibration $T_0 = 637^\circ\text{R}$
- - Rake No. 2, Calibration $T_0 = 637^\circ\text{R}$
- △ - Rake No. 3, Calibration $T_0 = 636^\circ\text{R}$




Figure 10. Exit Duct Probe Calibration.

1. Obtain static pressure and total pressure from manometer readings at the total temperature measuring station.
2. Calculate flow Mach number, using the following:

$$M = \sqrt{\frac{2}{\alpha - 1}} \left[\left(\frac{P_t}{P_s} \right)^{\frac{\alpha - 1}{\alpha}} - 1 \right] \quad (1)$$

where:

M = Mach number

α = Specific heat ratio

P_t = Total pressure, psia

P_s = Static pressure, psia

3. Determine the temperature correction ($\Delta T/T_t$) from the calibration curves (Figures 9 and 10) and calculate the actual or true temperature as follows:

$$T_{true} = T_t \left(1 + \frac{\Delta T}{T_t} \right) \quad (2)$$

T_{true} = True temperature, °R

T_t = Measured temperature by the probe, °R

$\frac{\Delta T}{T_t}$ = Percentage difference between actual temperature and probe temperature.

Overall Efficiency. The overall efficiency was computed using the standard efficiency formula shown below:

$$\eta = \frac{\left(\frac{P_t}{P_s} \right)^{\frac{\alpha - 1}{\alpha}} - 1}{TR - 1} \quad (3)$$

where:

η = Efficiency

PR = Exit total pressure divided by inlet total pressure

TR = Exit total temperature (corrected for Mach number effects) divided by inlet total temperature.

α = Ratio of specific heats determined by an integrated averaging process

Traverse Data Measurements. The probes were traversed radially inward, and the data were recorded at the following percentages of blade height locations: 5, 10, 30, 50, 70, 90, and 95. The total pressure probe was adjusted to the proper flow angle by balancing the static pressures. The temperature probe data were recorded at the flow angles determined by the total pressure probe.

Both the total temperature and the total pressure probes were calibrated for Mach number effects. The method of obtaining the actual traverse temperature is equivalent to the method used for obtaining the actual overall temperature. The method of calculating the actual pressure is summarized below:

1. At each radial station, obtain the absolute Mach number from computer results. A definition of the computer output parameters is included in Appendix I.
2. Obtain pressure ratio (P_t probe/ P_t true) from the probe calibration curve and calculate the actual pressure as defined below:

$$P_t \text{ actual} = P_t \text{ measured} \times \frac{1}{P_t \text{ probe}/P_t \text{ true}} \quad (4)$$

where:

P_t actual = Actual pressure measured in calibration tunnel, psia

P_t measured = Measured total pressure, psia

P_t probe = Instrument pressure measurement in calibration tunnel, psia

$$P_t \text{ probe} / P_t \text{ true} = \text{Calibration total pressure ratio}$$

The calibration curves for all of the traverse probes are presented in Figures 11 and 12.

Traverse Data Reduction. At the inlet to the first-stage rotor, the test static pressure, total temperature, and total pressure were assumed constant from hub to tip. Flow conditions at this station were obtained by the continuity relationship.

At the exit of the rotors, traverse data total temperature and total pressure were used to establish flow conditions. The slope of static pressure with radius was determined by assuming radial equilibrium. The level of static pressure was calculated by assuming continuity. The tangential velocity was established from the total temperature rise and the Euler turbomachinery equation.

The flow conditions behind the first-stage stator were established by assuming design losses to obtain the total pressure distribution. No change in total temperature was assumed from the exit of the first-stage rotor to the exit of the first-stage stator along a streamline. The flow direction was considered to be axial, and radial equilibrium was used to calculate the static pressure slope at the stator exit. Continuity determined the level of static pressure.

The exit conditions from the second-stage stator were calculated in the same manner as those from the first-stage stator except that the total pressure rake installed at the second stator exit was used to calculate the stator loss.




Figure 11. Survey Probe Calibration.




Figure 12. Survey Probe Calibration - Fully Shielded.

FIRST RIG TEST OF AXIAL COMPRESSOR

The axial compressor assembled with the long transition duct and without the variable inlet guide vanes was tested to define basic performance and to provide data for any necessary aerodynamic modifications. The design pressure ratio objective was reached. However, because of a low-flow condition, the compressor did not obtain the design flow and efficiency. A comparison of the demonstrated performance with the design objectives at 59,600 rpm is shown below:

	<u>Design</u>	<u>Demonstrated</u>
Overall pressure ratio	3.0:1	3.0:1
Efficiency, percent	82.3	72.5
Corrected flow, lb/sec.	5.00	4.32

Mechanically, the rig functioned satisfactorily, except for the air erosion of the abradable feltmetal (metal fiber) shrouds.

Aerodynamic Test Results

Overall Performance Data. Sufficient test data, Figure 13, were obtained to define an overall compressor map. These data were measured from the inlet of the compressor (4.5 inches upstream of the inlet struts) to the transition duct exit. The test data indicated performance potential for obtaining the design objectives. The overall compressor characteristics obtained were more than adequate. An excellent flow range was demonstrated by the compressor at all speeds. The design speed stall margin attained at 3.0:1 pressure ratio was 10.5 percent. The definition of stall margin is shown below:

$$\text{Stall Margin} = \frac{\left(\frac{PR}{W_a \sqrt{0/\delta}} \right)_S - \left(\frac{PR}{W_a \sqrt{0/\delta}} \right)_{OP}}{\left(\frac{PR}{W_a \sqrt{0/\delta}} \right)_{OP}} \times 100\% \quad (5)$$

where:

PR = Compressor total pressure ratio

$W_a \sqrt{0/\delta}$ = Inlet corrected airflow

S = Surge

OP = Operating point




Figure 13. Axial Compressor Map - First Rig Test.

Because of premature choking condition, the compressor did not obtain the design flow and efficiency. Some improvement in flow was noticed with severe erosion of the first-stage rotor shroud, Figure 13.

The transition duct overall data, Figures 14 and 15, show a flow shift from the hub to the tip. This is indicated by the increase in absolute Mach number from hub to tip. A decaying efficiency gradient from hub to tip is noticed.

Static Pressure Data. The static pressure data, Figure 16, was normalized by the inlet total pressure to account for differences in the inlet total pressure. A complete range of data from choke to surge is also shown in Figure 16, for 100 percent of design speed.

The transition duct static pressure distribution, Figure 17, shows good agreement with the analytical prediction. The overall level of static pressure was high with respect to the predicted level because of the reduced flow rate.

Traverse Data. Traverse data were obtained for the compressor at the rotor exits in order to provide a basis for either a modification or a redesign. The interstage performance was recorded and reduced for the following test points:

<u>Test Number</u>	<u>Corrected Airflow-Lb/Sec</u>	<u>Corrected Speed-Percent</u>	<u>Overall Pressure Ratio</u>
19	4.514	105	2.898
20	4.315	100	3.095
21	4.359	100	3.032
22	4.372	100	2.903

Complete flow conditions for all blade rows obtained from the traverse data of the above test runs are presented in Appendix II. This appendix represents the computer program output data. The assumptions used to calculate the flow conditions are included in the discussion of traverse data reduction. A description of the computer program output symbols is included in Appendix I. Curves of the data from Continental Test 822B, run number 21 (plotted from Appendix II), are shown in Figures 18 through 37 and are compared to the design objectives. This particular test point (run 21) is of particular interest because it was conducted near the design pressure ratio, 3.0:1, and the design speed, 59,600 rpm.




Figure 14. Axial Compressor First Rig Test - Transition Duct Exit Temperature and Pressure Ratio Data.




Figure 15. Axial Compressor First Rig Test Transition Duct Exit Mach Number and Efficiency Data.




Figure 16. Axial Compressor First Rig Test - Static Pressure Distribution Along Compressor Tip.




Figure 17. Axial Compressor First Rig Test - Transition Duct Static Pressure Distribution.




Figure 18. Axial Compressor Rotor One - Deviation and Incidence Angle Along Blade Radial Height.




Figure 19. Axial Compressor Rotor One - Exit and Inlet Relative Mach Number Along Blade Radial Height.




Figure 20. Axial Compressor Rotor One - Exit Mach Number and Diffusion Factor Along Blade Radial Height.




Figure 21. Axial Compressor Rotor One - Adiabatic Efficiency and Pressure Loss Coefficient Along Blade Radial Height.




Figure 22. Axial Compressor Rotor One - Temperature and Pressure Ratio Along Blade Radial Height.




Figure 23. Axial Compressor Stator One - Incidence and Absolute Inlet Air Angle Along Blade Radial Height.




Figure 24. Axial Compressor Stator One - Inlet and Exit Mach Number Along Blade Radial Height.




Figure 25. Axial Compressor Stator One - Pressure Loss and Diffusion Factor Along Blade Radial Height.




Figure 26. Axial Compressor Stator One - Adiabatic Efficiency and Pressure Loss Coefficient Along Blade Radial Height.




Figure 27. Axial Compressor Stator One - Static Temperature and Pressure Ratio Along Blade Radial Height.




Figure 28. Axial Compressor Rotor Two - Deviation and Incidence Angle Along Blade Radial Height.




Figure 29. Axial Compressor Rotor Two - Inlet and Exit Mach Number Along Blade Radial Height.




Figure 30. Axial Compressor Rotor Two - Exit Axial Mach Number and Diffusion Factor Along Blade Radial Height.




Figure 31. Axial Compressor Rotor Two - Adiabatic Efficiency and Pressure Loss Coefficient Along Blade Radial Height.




Figure 32. Axial Compressor Rotor Two - Temperature and Pressure Ratio Along Blade Radial Height.




Figure 33. Axial Compressor Stator Two - Incidence and Air Inlet Angle Along Blade Radial Height.




Figure 34. Axial Compressor Stator Two - Exit and Inlet Mach Number Along Blade Radial Height.




Figure 35. Axial Compressor Stator Two - Pressure Loss and Diffusion Factor Along Blade Radial Height.




Figure 36. Axial Compressor Stator Two - Adiabatic Efficiency and Pressure Loss Coefficient Along Blade Radial Height.




Figure 37. Axial Compressor Stator Two - Temperature and Pressure Ratio Along Blade Radial Height.

A head-flow analysis, using results of the traverse data, showed that both stages are operating at lower than design flow coefficient at near design point pressure ratio (Figure 38). A definition of the head flow parameters is shown below.

Definition of head and flow coefficient:

$$\text{Head Coefficient } \psi = \frac{GJ C_p T_{t1} \left[(PR) \frac{\delta - 1}{\delta} - 1 \right]}{U^2} \quad (6)$$

$$\text{Flow Coefficient } \phi = \frac{C_x}{U} \quad (7)$$

where:

G = Gravity Constant, ft/sec^2

J = Mechanical heat equivalent, ft-lb/Btu

C_p = Specific heat at constant pressure, $\text{Btu/lb } {}^\circ\text{R}$

T_{t1} = Stage inlet total temperature, ${}^\circ\text{R}$

PR = Stage total pressure ratio

δ = Ratio of specific heats

U = Mean radius wheel speed, ft/sec

C_x = Mean axial velocity, ft/sec

Mechanical Test Results. In completing the first test series, the advanced two-stage small axial compressor demonstrated excellent mechanical integrity with only minor problems developing.

The primary problem, realized during the early phases of testing, involved the abradable shrouds used in providing minimum tip clearances on the rotors. Initially, both the first- and second-stage shrouds utilized feltmetal as the abradable material. During testing, high-speed air erosion was experienced on the first-stage shroud, as shown in Figure 39.




Figure 38. First-and Second-Stage Axial Compressor Head Coefficient Versus Flow Coefficient.




Figure 39. Erosion of Feltmetal Rotor Shroud Material in First Stage
of USAAVLABS Two Stage 3:1 Compressor Test Rig.

After considering the problems experienced with the feltmetal, a search of other abradable material candidates was made, resulting in the decision to use flame-sprayed aluminum on the first-stage shroud. This shroud has proven to be very effective in use.

Aerodynamic Data Analysis

Comparison of Static Pressure Data and Traverse Data. The static pressure distribution shows an indication of choke in the vicinity of the inlet to the second-stage rotor. A choked condition exists when changes in downstream pressure do not affect the flow conditions upstream of the choked area; in this case, the flow is unaffected upstream of the second rotor inlet. Since all of the static pressure taps were located between blade rows (that is, there are no static pressure taps directly over the rotor blades or stator vanes) an exact location of the actual choked position was undeterminable from these data.

In general, the traverse data indicate a severe loss at the first-stage rotor tip and a tip-to-hub flow shift as the flow passes through this blade row. The first-stage stator, as a consequence of this flow shift, is stalled at the tip and choked at the hub. Both the second-stage rotor and the second-stage stator appear to be in stall, as indicated by high blade and vane incidence values. This observation, which is contrary to the results of the static pressure data, is discussed in detail below.

The analysis of the aerodynamic data was directed to determining the cause of the low-flow condition and to finding a solution. The anomaly in the data, a choked second-stage rotor based on static pressure measurements on the one hand, and a stalled second-stage rotor based on traverse data measurements on the other hand, was most difficult to decipher.

The conclusion reached from all the data was that the flow in the first rotor was stalled (or separated) at the tip, which caused a flow shift from the tip to the hub. This flow shift caused the first stator to be choked at the hub and stalled at the tip. The second-stage rotor, as a result of operating with a low inlet total pressure caused by the stator hub choke losses and the stator tip incidence losses, is choked and thus limits the overall compressor flow rate.

The apparent anomaly in the traverse data showing the second-stage rotor in stall can be explained by the assumptions used to reduce the data and to obtain the velocity triangles.

The first rotor exit traverses of total pressure and total temperature completely define the static conditions from hub to tip between the first-stage rotor and the first-stage stator with addition of the following assumptions:

1. No swirl is assumed at the rotor inlet.
2. The Euler turbomachinery equation defines the tangential swirl behind the rotor.
3. Design values of flow blockage are used.
4. Continuity was assumed.
5. Radial equilibrium was assumed.

These data and assumptions are considered adequate enough to describe the flow conditions behind the first-stage rotor. However, since traverses were impracticable to obtain behind the first-stage stator, loss assumptions had to be made in order to define the total pressure distribution in this location. In this case, the first-stage stator design losses were assumed. At the time that the data were being reduced, no blade row loss analysis was available at Continental to predict the stator losses and accompanying flow shifts that result from the severe tip stall-hub choke phenomenon. Therefore, the traverse data assumptions used in this particular blade row were probably inadequate. The losses should be much higher than shown, and in turn, the total pressure behind the stator is probably much lower than shown. Thus, if the stator losses were much higher than the values assumed, the second-stage rotor would show indications of choking.

Examination of Various Rotor Modifications. In order to pinpoint the cause of the first rotor tip stall condition, and in turn unchoke the second-stage rotor, an analytical study was conducted. This study consisted of determining why the first-stage rotor was stalled and of examining various modifications to increase the flow and provide aerodynamic data for the redesign phase. These modifications were assessed for performance increase, practicality, length of time required to complete the modification, and cost.

An analysis of the first-stage rotor flow passage between adjacent blades revealed that the variation of area normal to the relative flow does not follow that of a typical rotor. This area, shown in Figure 40, is defined as being normal to the relative flow and bounded by:




Figure 40. Typical Section, USAAVLABS First-Stage Rotor Passage Area.

- the suction side, surface of a blade
- the pressure side, surface of an adjacent blade
- the hub circumferential distance between blades
- the tip circumferential distance between blades

The area distribution, shown on Figure 41, minimizes at approximately 0.1 inch upstream of the rotor stacking line. Using this minimum area as a basis, one-dimensional flow analyses, assuming both design aerodynamic and test data conditions, were performed. The flow analyses showed that, in both cases, the rotor was choked. In addition, further analyses showed that the inlet area to the flow passage or channel, Figure 41, was large enough to pass design flow. Based on these results, modifications to the first rotor were considered.

The modifications which were evaluated to increase the flow of the first rotor and in turn the overall efficiency are presented in Table I and include:

1. Open tip blade twist (or restagger), 5 degrees
2. Open leading edge twist, 7 degrees
3. Hub relief, 0.110 inch
4. Extended tip, 0.060 inch
5. Variable inlet guide vanes, 21 degrees
6. Redesign, new stage one rotor and new inlet assembly

The flow and efficiency considerations for each of these candidate modifications are discussed below:

1. Blade Twist

The 5-degree open twist should increase the flow to the design value of 5 pounds per second, but at a first-stage efficiency penalty. Usually, when a rotor is twisted open, the throat is increased, but in turn, with an increase in incidence. For example, the first rotor incidence would increase from 6.6 to 7.25 degrees at a design speed.




Figure 41. USAAVLABS First-Stage Rotor Passage Area Distribution.

TABLE I

FIRST-STAGE ROTOR MODIFICATION POSSIBILITIES

Modification	Blade Twist	Leading Edge Twist			Hub Relief	Extended Tip	Inlet Guide Vanes	Variable Redesign
		5°	7°	0.110 in.				
Amount of Modification				0.060 in. nominal		21°	Setting angle	New stage one rotor new inlet assembly
Predicted Design Speed		7.25°	9.25°	3.0°		6.1°	8.0°	
Predicted Design Speed	5.0 lb/sec	5.0 lb/sec	5.0 lb/sec	5.0 lb/sec		4.5 lb/sec	4.5 lb/sec	3.0°
Time Required to Complete Modification*	5 days	5 days	10 days	20 days	3 days	3 days	6 months	

* Does not include time for reassembly.

High incidence values significantly increase the rotor relative shock losses and cause severe flow separation.

2. Leading Edge Twist

The 7-degree leading edge twist should also increase the flow to 5 pounds per second, but the incidence at design speed will be even higher. Since the minimum passage area is near the center (Figure 41), a higher twist angle is required for the leading edge twist than for the blade twist to obtain an equivalent amount of area increase. Thus, the rotor losses will be even higher than those of the blade twist.

3. Hub Relief

The hub relief shown on Figure 42 should increase the flow by the required amount and at the same time reduce the incidence to that of design, 3.0 degrees. This method opens the minimum area without changing the blade shape or stagger. The passage area, after relief, should approximate that of a typical rotor, as shown on Figure 41.

4. Extended Tip

The extended tip requires a tip radius increase of about 0.060 inch in order to pass 5 pounds-per-second flow. However, the incidence at design speed will not significantly change from the test value of 6.6 degrees even though the flow would be increased; because the axial velocity and tip speed remain nearly constant, the relative air angle and, in turn, the incidence would not be substantially changed. The actual change in incidence is about 0.5 degree and is not sufficient to substantially decrease the first-rotor losses.

5. Variable Inlet Guide Vanes

Use of the variable inlet guide vanes would not increase the flow to 5 pounds per second as shown in Table I. Since the airflow is lower than predicted, the relative air angles into the first rotor are much higher than the design angles. Therefore, the inlet velocity triangle is much "flatter" than originally intended, and a very large inlet guide vane turning angle is required to substantially increase the flow. As shown in Table I,




Figure 42. USAAVLABS First-Stage Rotor - Comparison of Hub Contours.

the relatively high value of variable inlet guide vane setting angle (21 degrees) increases the flow to only approximately 4.5 pounds per second.

6. Redesign

A redesign of the first rotor, using the first rig test results and the analytical study as a basis, should increase the flow and efficiency of the compressor to design values. The first stage would be redesigned to a slightly higher hub/tip ratio and different hub contour to ensure a satisfactory blade passage area distribution.

On the basis of the above flow and efficiency considerations for each modification, the hub relief and the redesign were recommended as being the most practical on the basis of time, cost, and risk.

SECOND RIG TEST OF AXIAL COMPRESSOR

Aerodynamic Test Results

The second rig test, with the hub relief first-stage rotor, was conducted and data were obtained at 60, 80, 90, and 100 percent of design speed. No significant change in compressor performance was observed compared to the first rig test. The flow at 100-percent design speed increased from 4.359 pounds per second to 4.428 pounds per second, an increase of about 1.5 percent (see Figure 43). No traverse data were obtained because of the small change in flow. Since the flow did not change, a check on the analysis of rotor flow passage area (candidate modification 3 (see Fabrication) was conducted. This analysis showed that the assumption of using the one-dimensional flow was inadequate. The examination should have used individual stream tube areas as the basis for analysis.

The decision was made to twist the rotor open 5 degrees at the tip (modification number 1 (see Fabrication)). This is the only modification that had the possibility of providing a flow increase without a major change in hardware. As mentioned, the 5-degree open twist should increase the flow to the design value, but at a first-stage efficiency penalty. However, the overall compressor efficiency should increase because of the improved second-stage aerodynamic match. In addition, second-stage data should be obtained at near design inlet aerodynamic conditions, which is required to determine if the second-stage is performing satisfactorily and to provide a basis for a first-stage rotor redesign.

Mechanical Test Results

During the second rig test with the hub relief on the first-stage rotor, the compressor mechanical performance was again satisfactory. The only problems experienced were a result of a relatively strong, sustained surge at 103-percent mechanical speed. Running at this speed (equivalent to 100-percent corrected speed with heated inlet) was necessary to avoid the speed range within which blade vibration had been experienced.

The only damage to the compressor resulting from the surge consisted of heavy rubs on the second-stage abradable shroud and on the first-stage labyrinth seal silver rub ring (Figure 44).




Figure 43. Advanced Two-Stage Axial Compressor Rig Test - Hub Relief.




Figure 44. First-Stage Stator Assembly Showing Deep Groove on Labyrinth Seal Rub Ring.

THIRD RIG TEST OF AXIAL COMPRESSOR

Aerodynamic Test Results

The third rig test, with the hub relief and 5-degree twisted-open first-stage rotor, was conducted and data were obtained at 60, 80, 90, and 100 percent of design speed. A reduction in flow from the previous test was noticed as shown in Figure 45. The flow at 100 percent of design speed was reduced from 4.428 to 4.36 pounds per second. Traverse data were obtained at the following pressure ratios at design speed: 2.56:1, 2.97:1, and 3.13:1, shown in Appendix III. An additional traverse data point was obtained at 80-percent design speed, also shown in Appendix III. The data, in general, showed no significant change except for a further reduction in efficiency from that of the first test. Therefore, these data were used only in overall content as the basis for the redesign.

Mechanical Test Results

During the third test, no mechanical problems were encountered.

COMPRESSOR REDESIGN

Aerodynamic Redesign

Data Analysis of First Three Rig Tests. Based on the data of the first three rig tests, it was theorized and concluded that the second-stage rotor was choked and was therefore limiting the compressor flow. The problem in interpreting this theory and applying it as a basis for a redesign was twofold. It had to be determined whether the choked rotor by itself was limiting the flow for the entire compressor, or whether some phenomenon upstream of the second stage was causing the second stage to be choked and, in turn, limiting the compressor flow.

It was concluded that the low-flow phenomenon noticed on the first three rig tests was caused by a stalled or separated first-stage rotor tip. The flow in the first-stage rotor is forced to shift down towards the hub, causing a choked hub area as a result of the stalled tip area (see Figure 46). This condition in turn chokes the first-stage stator hub and stalls the first-stage stator tip. The accompanying high losses due to these flow shifts cause the second-stage rotor to be operating in choke.




Figure 45. Advanced Two Stage Axial Compressor Rig Test - Blade Twist.

FLOW DIRECTION FROM TRAVERSE
DATA (ARROWS)




Figure 46. Two-Stage Axial Compressor - Original Design.

Preliminary Aerodynamic Redesign. Before the aerodynamic details of the redesign were approached, the cause of the first-stage rotor stalled tip had to be resolved. Therefore, a detailed analysis of a family of high-pressure-ratio axial compressor rotors (seven Continental rotors and the NASA rotor 2E*) was conducted to accomplish this task and to provide direction for the redesign. All of the compressors included in the family have demonstrated near design pressure ratio and flow test performance with the exception of the USAAVLABS rotors, which did not demonstrate design flow.

The analysis included investigations and comparisons of actual design data, free vortex design data, and test data. The design conditions for the eight rotors were mainly compared on a free vortex basis to establish equivalent design diffusion and blade loading criteria. Since the data used in the analysis are proprietary, only the overall results are presented.

Many test correlations of tip loss coefficient, tip efficiency, tip relative Mach number, aspect ratio, and so forth were tried and related to the free vortex design criteria. The only successful correlation was a relationship between test data tip performance and tip solidity. A definite trend was established that showed a significant increase in tip performance with decreasing solidity. Since, in general, a high solidity positions the adjacent blade shock intersection towards the leading edge as shown in Figure 47, severe shock boundary layer interactions may occur and in turn cause high losses with a high tip Mach number - high tip solidity axial rotor design, such as the original USAAVLABS design.

A comparison of the range of design parameters for the family of axial compressor rotors with the USAAVLABS design parameters in Table II showed that the USAAVLABS rotor is within the range of aerodynamic parameters investigated with the exception of flow rate, aspect ratio, and solidity. Since there was an axial rotor very near the flow rate and aspect ratio of the USAAVLABS rotor (the Continental small 2.0:1 pressure ratio axial compressor, 7.14-pounds-per-second flow rate and 0.67 aspect ratio), only the tip solidity stands out as a possible cause of the stalled tip condition, thus supporting the correlation developed with tip solidity and tip aerodynamic performance.

Detailed Aerodynamic Redesign. The detailed aerodynamic redesign of the compressor is presented in the classified Addendum to this report, published under separate cover.

*Reference NASA Report CR-54583




Figure 47. The Effect of Solidity on Shock Location for Supersonic Cascades.

TABLE II
ANALYSIS OF HIGH-PRESSURE-RATIO AXIAL ROTORS

Design Parameter	Range of Design Parameters Covered in Analysis		First Rotor Design Parameter
	Low	High	
Flow Rate, lb/sec	5.0	215.5	5.0
Pressure Ratio	1.70:1	2.05:1	1.86.1
Efficiency, percent	84	90	87
Inlet Hub/Tip Ratio	0.45	0.68	0.50
Tip Aspect Ratio	0.58	1.57	0.58
Tip Solidity	1.00	1.80	1.80
Tip Relative Inlet Air Angle*, degrees	63.9	68.3	65.5
Tip Air Turning Angle*, degrees	0.9	17.3	8.0
Tip Pressure Ratio Head Coefficient*	0.219	0.394	0.30
Tip Relative Velocity Ratio*	0.61	0.76	0.70
Tip Axial Velocity Ratio	0.77	1.04	0.91
Inlet Tip Speed, ft/sec	1324.0	1480.0	1411.0
Tip Relative Inlet Mach Number*	1.37	1.52	1.43
Tip Diffusion Factor*	0.37	0.53	0.39
Static Pressure Rise/ Inlet Velocity Head*	0.279	0.375	0.34

*Based on free vortex criteria.

MECHANICAL AND STRUCTURAL COMPRESSOR REDESIGN

The prime objective in the Phase III mechanical design was to provide a structurally sound vehicle for testing the redesign aerodynamics. The nature of the aerodynamic changes incorporated in the redesign made it feasible to use much of the Phase II hardware without modifications.

Mechanical Redesign

Figure 48 shows a comparison of the redesigned and original configurations of the compressor. The majority of the rig hardware is unchanged from the first design, consequently the assembly sequence, stack-ups, lubrication systems, and instrumentation also remain unchanged.

Table III lists the components which were redesigned to satisfy the new aerodynamic physical parameters. As seen from this table, four of the nine major components were manufactured through modification of original hardware. Since these components were some of the more complex ones in the compressor rig, substantial savings in cost and lead time were obtained. All of the other components, except those listed in Table III, were used without modification for the Phase III rig test.

Structural Redesign

The main area of structural investigation was in the rotating assembly. This included the rotor disc and blade stresses, vibratory characteristics, and shaft dynamics.

First-Stage Rotor and Blades. The integrally bladed first-stage rotor was machined from a Greek Ascoloy (AMS 5616) forging. The certified material exhibited the following physical properties at room temperature:

Ultimate tensile strength	142 ksi
Yield strength at 0.2 percent	114 ksi
Endurance limit stress - smooth bar	63 ksi
Endurance limit stress - notched	
bar K _t = 3.6	22 ksi

Continental computer programs, based on the Manson Elastic Method, were utilized for the disc analysis.




Figure 48. Comparison of USAVLABS First-Stage Flow Paths.

TABLE III
SUMMARY OF PHASE III COMPONENT REDESIGN*

Part No.	Part Name	New/Modified	Description of Major Change or Modification
715663	Air Inlet Housing	Modified	Increased diameter of outer flowpath.
715667	VIGV Housing	Modified	Increased diameter of outer flowpath and revised method of retaining inlet guide vanes.
715666	Inlet Guide Vane Support	New	Configuration changed because of new method of retaining inlet guide vanes.
715665	Inlet Guide Vane Sleeve	New	Configuration changed because of new method of retaining inlet guide vanes.
715675	First-Stage Stator	Modified	Closed leading edge of stator vane 8.5 degrees, and modified integral first-stage rotor shroud to accommodate new first-stage rotor.
715664	Front Bearing Oil Seal Retainer	New	Lengthened to compensate for shorter axial length of first-stage rotor.
715658	First Stage Rotor	New	Totally new aerodynamic design.
715676	Second Stage Rotor	New	Only change is number of blades but being integrally bladed; new one has to be made.
715844	Inlet Duct	Modified	Increased diameter to accommodate new flowpath.

*Does not include miscellaneous hardware.

Rotor radial and tangential stresses are shown in Figure 49 as a function of distance from rotor centerline. The maximum radial and tangential bore stress of 38,500 psi at the design speed of 59,600 rpm is well within the allowable material limits. Average tangential stress of 35,300 psi provided an ample burst margin of 1.87 for the first-stage rotor.

The structural analysis of the first-stage blading was performed using Continental computer methods for the gas load conditions specified in Figure 50 and a design speed of 59,600 rpm.

Figures 51, 52, and 53 show blade centrifugal stresses, centrifugal untwist, and gas bending stresses, respectively. All stresses are within the AMS 5616 physical material property limits. The relatively high compressive untwist stress combined with centrifugal and gas bending stresses results in a net moderate compressive stress at the blade leading and trailing edges. A maximum combined steady stress of 76,000 psi tension occurs at the blade midchord root location. This point is shown on the modified Goodman diagram, Figure 54. As indicated on the diagram, the vibratory margin for the blades is high.

The torsional and bending natural frequencies of the first-stage blade are given in Figure 55. The interference diagram indicates that at design speed, no resonance will occur in any of the modes.

Second-Stage Rotor and Blades. The second-stage rotor, like the first, is integrally bladed and machined from the same AMS 5616 forging. The only change made in this rotor was the number of blades. The disc, being identical to the Phase II disc but carrying a lower rim load, exhibits conservative stress levels.

Figure 56 shows the disc tangential and radial stresses as derived from the Continental computer programs. The maximum radial and tangential stress, at the bore, is 48,500 psi at 59,600 rpm. An average tangential stress of 43,500 psi results in a conservative burst margin of 1.69 for the rotor.

The second-stage blading is physically identical to the Phase II blades. However, the decrease in number of airfoils results in an increase in gas loading per blade (Figure 57) and consequent changes in stress levels.

Design speed analysis of the blades resulted in centrifugal untwist and in gas bending stresses as shown in Figures 58, 59, and 60 respectively. None of the stresses exceed the safe operating limits.







Figure 49. Phase III Compressor - First-Stage Rotor Disc Radial and Centrifugal Stress.



**Figure 50. Phase III Compressor - First-Stage Rotor Blades
Gas Force Intensity.**



DISTANCE FROM ROTOR CENTERLINE - IN.
 Figure 52. Phase III Compressor - First-
 Stage Rotor Blade Centrifugal
 Untwist Stress.



DISTANCE FROM ROTOR CENTERLINE - IN.
 Figure 51. Phase III Compressor - First-
 Stage Rotor Blade Centrifugal
 Stress.




Figure 53. Phase III Compressor - First-Stage Rotor Blade Gas Bending Stress.




Figure 54. Phase III Compressor - First-Stage Rotor Blade Modified Goodman Diagram.




Figure 55. USAAVLABS Phase II' Compressor - First-Stage Rotor Blade Interference Diagram.




Figure 56. USAAVLABS Phase III Compressor - Second-Stage Rotor Disc
Radial and Tangential Stress.




Figure 57. USAAVLABS Phase III Compressor - Second-Stage Rotor
Blade Gas Force Intensity.




Figure 58. USAAVLABS Phase III Compressor - Second-Stage Rotor Blade Centrifugal Stress.




Figure 59. USAAVLABS Phase III Compressor - Second-Stage Rotor Blade Centrifugal Untwist Stress.




Figure 60. USAAVLABS Phase III Compressor - Second-Stage Rotor Blade Gas Bending Stress.

At the blade root trailing edge location, a maximum combined steady stress of 47,000 psi tension exists. Figure 61 shows this maximum stress point on the modified Goodman diagram and indicates a satisfactory vibratory margin for the second stage blades.

The interference diagram in Figure 62, showing the natural frequencies of the blades, indicates that no resonance will occur at design speed.

Shaft Dynamics. The shaft dynamics of the Phase III USAAVLABS compressor configuration were analyzed to determine if the original main bearing spring cages could be utilized or if one or both of the supports would have to be redesigned to accommodate the change in mass and moment of inertia resulting from the new rotor geometry.




Figure 61. USAAVLABS Phase III Compressor - Second-Stage Rotor Blade Modified Goodman Diagram.

Using the original bearing support spring rates and the new rotor mass parameters as input, the first three modes of lateral vibrator were calculated by computer techniques using the Prohl-Myklestad Holzer type analysis. The results are tabulated below:

First Critical	6,800 rpm
Second Critical	12,700 rpm
Third Critical	132,000 rpm

With the operating range of the compressor between 20,000 and 60,000 rpm, it was concluded that the existing main bearing spring supports would function satisfactorily with the new rotor configuration.




Figure 62. USAAVLABS Phase III Compressor - Second-Stage Rotor Blade Interference Diagram.

FABRICATION OF REDESIGNED COMPRESSOR

The redesigned components for the Phase III compressor and the nature of their redesign are listed in Table III. As shown in Table III, some parts were fabricated by modifying Phase II hardware in addition to total fabrication of items such as the rotors.

Fabrication of some of the more critical components is covered in the following paragraphs.

ROTOR ASSEMBLY

Because of the overall similarity of the redesigned rotor to the original rotor, the integrally bladed rotors were machined by the same methods as used previously. On the second-stage rotor, where the only change was the number of blades, it was possible to use much of the original tooling.

The two rotors and the shaft were electron-beam welded into an assembly, using the same procedure as was used in welding the first two rotor assemblies. The rotor weldment was acceptable, with no excessive runout (see Figure 63).

STATOR ASSEMBLY

Increasing the tip diameter of the first-stage rotor required that corresponding changes be made to the stationary abradable rub shroud, integral with the first-stage stator. In addition to machining the diameter of the shroud, the flame-sprayed aluminum insert was replaced to provide proper clearances (see Figure 64).

Also, for aerodynamic reasons, the top 20 percent of the first-stage stator vane leading edge was closed, varying from 8.5 degrees at the tip to 0 degrees at 80-percent vane length. This was accomplished by making an EDM cut at the vane tip extending downstream approximately 50 percent of the chord length. Through the use of a fixture, the vane was then bent the appropriate amount (see Figure 65). The EDM slots were then filled with epoxy and blended to provide a smooth flowpath.

No modifications were made to the second-stage stator.



Figure 63. Redesigned Welded Rotor Assembly.




Figure 64. Redesigned First-Stage Stator and Compressor Housings.




Figure 65. Redesigned First-Stage Stator Showing EDM Cut in Vane Tip.

INLET GUIDE VANE ASSEMBLY

The increased rotor tip diameter required that the outer flowpath diameter in the variable inlet guide vane (VIGV) assembly also be increased. It was possible to maintain the original vanes and actuation system, although the vanes are cantilevered through the outer flowpath, by modifying or replacing the bushings and spacers in the vane retention system. Figure 66 shows the modified VIGV assembly as it will be installed for the final rig test.




Figure 66. Redesigned Variable Inlet Guide Vane Assembly.

FINAL RIG TEST OF REDESIGNED COMPRESSOR

AERODYNAMIC TEST RESULTS

The compressor was assembled with the long transition duct and with the variable inlet guide vanes. The compressor was tested with the instrumentation as defined in Volume I except for the traverse probes.

The redesigned compressor test demonstrated sufficient performance to provide a potential for a 0.457-pound-per-horsepower-hour specific fuel consumption engine. Figure 67 represents the performance of an engine using the USAAVLABS centrifugal technology, Figure 68, and the conventional engine component characteristics listed below. The calculation of specific fuel consumption is based on an unregenerated free shaft power turbine engine cycle which is operated as follows:

1. The centrifugal compressor, Figure 68, runs at 100-percent mechanical speed.
2. The total cycle pressure drop is 11.5 percent:

Inlet	0.5 percent
Combustor	4.5 percent
Exhaust	6.5 percent

3. Turbine efficiencies are:

High Pressure	83.9 percent
Low Pressure	86.0 percent
Power Turbine	88.1 percent

4. Combustion efficiency is 98.5 percent.
5. Output mechanical efficiency is 98 percent.
6. Turbine inlet gas temperature is 2500°F.
7. Air cooling bleed is 2 percent from centrifugal compressor discharge into the exhaust duct.




Figure 67. The Effect of Overall Axial Centrifugal Compressor Pressure Ratio and Axial Compressor Performance on Brake Specific Fuel Consumption.




Figure 68. USAVLABS Centrifugal Compressor Technology Performance Along Given Operating Line.

The compressor demonstrated the following performance at design speed (performance measured from compressor inlet to transition duct exit):

Pressure ratio	3.0:1	3.1:1	3.2:1
Efficiency, percent	79.0	80.0	81.0
Airflow, lb/sec	4.920	4.910	4.865

The overall compressor characteristics, Figure 69, are probably more than adequate for use in an engine. As can be seen in Figure 69, a peak efficiency of 84 percent was obtained at a 2.3:1 pressure ratio. A stall margin (defined in First Rig Test Section) of 10.1 percent was obtained at a 3.1:1 pressure ratio.

The transition duct exit pressure ratio and efficiency radial profiles at 100 percent of design speed are presented in Figure 70. As can be seen, the pressure ratio profile is reasonably flat while the efficiency profile falls off towards the shroud as a result of higher losses at the tip of the compressor. The pressure ratio and efficiency radial profiles translate to the velocity and Mach number profiles shown in Figure 71. These data were obtained by assuming a linear gradient of measured static pressure from hub to tip. The radial profiles at the transition duct exit are, in general, skewed from hub to tip. This condition can be improved through minor development, if necessary. However, these profiles do provide acceptable inlet conditions to a centrifugal compressor inducer, as shown in Figure 72. This figure presents inlet velocity triangles to a centrifugal compressor inducer running at the same mechanical speed (single spool) as the axial compressor. The inducer tip inlet relative Mach number is 0.88 and the tip inlet relative flow angle is 58.8 degrees, both well within conventional inducer design limits.

Since this axial compressor was designed for a specific engine application using a centrifugal compressor, the design rotational speed was maximized to provide for as high a centrifugal specific speed as practical for single spool application. Figure 73 shows the effect of the overall axial-centrifugal compressor pressure ratio and centrifugal specific speed. This figure is for a family of centrifugal compressors capable of match behind the axial compressor running at design speed and at a 3.1:1 pressure ratio. If, for example, an overall axial-centrifugal pressure ratio of 15:1 is desired, the required centrifugal pressure ratio would be 4.85:1 and the specific speed would be 71.2.




Figure 59. USAFV BS Two-Stage Transonic Axial Compressor Performance.




Figure 70. Two-Stage Axial Compressor Transition Duct Exit Performance at Compressor Design Speed - Efficiency and Pressure Ratio.






Figure 71. Two-Stage Axial Compressor Transition Duct Exit Performance at Compressor Design Speed - Mach Number and Absolute Velocity.

Test Data Point
Axial Corrected Speed = 59,600 RPM
Axial Corrected Flow = 4.91 lb/sec
Axial Pressure Ratio = 3.1:1
Axial Efficiency = 80%

$\beta_1 = 58.8^\circ$
 $C_x = 610 \text{ ft/sec}$
 $MIR = 0.880$
 $M_x = 0.455$
 $U = 1012 \text{ ft/sec}$



$\beta_1 = 52.2^\circ$
 $C_x = 606 \text{ ft/sec}$
 $MIR = 0.758$
 $M_x = 0.465$
 $U = 781 \text{ ft/sec}$



$\beta_1 = 54.0^\circ$
 $C_x = 400 \text{ ft/sec}$
 $MIR = 0.525$
 $M_x = 0.309$
 $U = 550 \text{ ft/sec}$




Figure 72. Two-Stage Axial Compressor Transition Duct Exit Triangle for a Centrifugal Compressor Inducer Inlet at Design RPM.




Figure 73. Parametric Results of a Family of Centrifugal Compressors Operating in Single-Spool Configuration Behind USAAVLABS Two-Stage Axial Compressor.

An investigation of the transition duct loss using the averaged total pressure test data, Figure 74, showed that the duct loss at the 3.1:1 pressure test point was 2.25 percent. It is believed that the actual loss is more in the order of 1 percent. The transition duct inlet total pressure test data are based on a rake of three probes circumferentially located midway between adjacent stage two stator vanes, and therefore, records main passage pressure. Thus, the pressure rake does not measure the true mass averaged pressure. Additional probes on the suction surface and pressure surface of the vanes were not installed because of possible blockage effects. A compressor efficiency (measured from compressor inlet to second-stage stator exit) of 82.5 percent at 3.17 pressure ratio is calculated if the measured pressure is assumed.

The measured tip static pressure distribution throughout the compressor at 100 percent design speed is compared to the design static pressure distribution in Figure 75. The data for run number 14, at 3.015 pressure ratio, compare very well with the design tip static pressure values except for the exit of rotor one. The higher measured static pressure values at this location are possibly attributable to tip losses higher than those of design rotor one. However, in the absence of traverse data, no definite conclusion can be reached as to the cause of the higher pressure. There are indications that the second-stage rotor choking condition has been relieved. This is shown by the larger spread in static pressure at the inlet to the second-stage rotor as compared to the original design measured static pressure distribution at this location.

The transition duct measured static pressure values are compared to the design values in Figure 76. The minor differences between design and test static pressure are probably attributable to the skewed radial velocity gradient at the compressor exit.

The effect of the variable inlet guide vane on design speed compressor performance is shown in Figure 77. A peak efficiency of 81.5 percent was recorded at +10 degrees stagger angle. As can be seen in Figure 78, a 30-degree change in stagger angle produced a 3.5-percent change in surge flow at design speed. A more dramatic change in flow was expected with the part-span guide vanes based on results of previous Continental testing of another transonic axial compressor. Those data may indicate that the first stage is not limiting flow and, therefore, making the compressor insensitive to inlet guide vane changes.




Figure 74. Advanced Two-Stage Axial Compressor Transition Duct Total Pressure Loss.

A compressor test at 50, 70, 90, and 100 percent of design speed was conducted with the variable inlet guide vanes set at +20 degrees stagger angle. The data from this test, shown in Figure 79, as compared to the nominal inlet guide vane data, showed a loss in efficient flow range. Therefore, the nominal guide vane setting angle provides the best compressor performance at both high and low speeds. The difference in performance shown on Figure 79, is due to the rematch between stages as a result of inlet guide vane swirl. An increase in part speed performance with inlet guide vane swirl is expected after the compressor is fully developed.

MECHANICAL TEST RESULTS

During the final test series, the compressor rig, incorporating the redesigned hardware, exhibited excellent mechanical integrity.

The only minor problem that developed during running was erratic vibration readings at 100 percent design speed. These readings were observed on the vertical accelerometer mounted on the outside of the compressor housing. The horizontal accelerometer showed no vibration. Also, the strain gages on the front bearing cage gave no indication that the rotor was vibrating relative to the housing. Therefore, it was concluded that the compressor assembly as a whole was being excited.

Although the amplitude was not excessive, refrigerated inlet was used at the higher speed lines to keep the mechanical speed below 95 percent and, consequently, out of this vibration range.




Figure 75. Static Pressure Distribution Along Compressor Tip.




Figure 76. Two-Stage Compressor Transition Duct Exit Static Pressure Distribution.




Figure 77. Transonic Two-Stage Axial Compressor - The Effect of Variable Inlet Guide Vane Setting Angle on 100-Percent Design Speed Compressor Performance.




Figure 78. Transonic Two-Stage Axial Compressor - The Effect of Variable Inlet Guide Vane Setting Angle on 100-Percent Design Speed Compressor Performance.




Figure 79. Advanced Two-Stage Compressor Comparison of Nominal and +20 Degree Inlet Guide Vane Stagger Angle on Compressor Performance.

CONCLUSIONS

1. The performance of the redesigned axial compressor has exceeded the contractual aerodynamic pressure ratio and efficiency goals. A potential for a 0.457-pound-per-horsepower-hour specific fuel consumption turboshaft engine at 2500°F turbine inlet gas temperature using the projected USAAVLABS advanced centrifugal technology and conventional engine component characteristics was demonstrated. The feasibility of a 17:1 overall axial-centrifugal pressure ratio was shown.
2. The redesigned compressor configuration showed a significant increase in design and part power performance level, over that of the original design compressor.

	<u>Original Design</u>		<u>Redesign</u>	
Percent Corrected Speed	100	80	100	80
Airflow	4.36	3.29	4.91	3.72
Pressure Ratio	3.0:1	2.1:1	3.1:1	2.1:1
Percent Efficiency	72.5	76	80	84

3. The performance increase was attributed to the reduced solidity in the first- and second-stage rotors of the redesigned compressor.
4. The mechanical design of the compressor and the rig proved to be extremely reliable over the entire 97 hours of rig running.
5. Through development, the compressor should be capable of even higher efficiency levels than those that were demonstrated.
6. The exact performance contribution for each of the combined variations such as the solidity, aspect ratio, and blade shape, made to the redesigned compressor is not known at this time. Time and funding precluded an independent analysis of each of the variations.

RECOMMENDATIONS

The compressor should be developed to increase efficiency and part-speed flow range. Traverses of the redesigned compressor should be conducted to determine interstage performance and to provide direction for any modifications.

The following additional tasks are recommended to increase and more closely define the performance of the compressor:

1. A series of first-stage tests should be conducted with varying solidity of the first-stage rotor to extend the data used for redesign and thus determine the optimum solidity for this type of rotor configuration.
2. The blade shape of the first-stage rotor should be changed in an attempt to minimize shock losses.
3. A series of rotor tip clearances tests should be conducted to determine the optimum tip clearance.
4. A straight transition duct should be tested to evaluate the basic compressor performance and the long transition duct losses.
5. The short transition duct should be evaluated.

APPENDIX I

DESCRIPTION OF TRAVERSE DATA COMPUTER OUTPUT

OUTPUT NOMENCLATURE AND UNITS

The following is a listing of output quantities in the sequence of their appearance in the program output. For each quantity, the symbol is given as it appears in output, and the quantity is defined as to its meaning and units.

The output appears under one of the following three row designations: INLET, ROTOR, or STATOR. Under any of these readings, two types of output appear. The first is the output for each streamline; flow characteristics, properties, and geometry are described on a streamline or incremental basis within the flow field at particular radial stations. The second is the row output summary; interstage flow performance and geometric properties are summarized on an overall basis for the row. Appropriate quantities, given also on a streamline basis, are mass averaged in the summary.

As mentioned previously, the three types of rows, or axial stations, within a compressor are INLET, ROTOR, and STATOR. INLET is self-descriptive; it refers to the initial axial station considered, and all quantities given apply to the inlet stations. ROTOR refers to an axial station or row which, in terms of radial specification of streamlines, is considered to be at a rotor exit; however, both rotor inlet and exit quantities appear in ROTOR output. Similarly, STATOR refers to stator exit with respect to the definition of radial stations; as for a rotor, stator inlet and exit quantities are given under STATOR.

The three types of axial stations or rows lend themselves to a form of subscripting. Symbols for output quantities may contain a numeric character for row designation according to the following convention:

1. Refers to compressor inlet row or inlet to first stator.
2. Refers to a rotor exit and stator inlet row.
3. Refers to a stator exit and/or rotor inlet row.

OUTPUT:

INLET TO COMPRESSOR:

FLOW	Absolute Airflow	lb/sec
------	------------------	--------

OUTPUT: (Continued)

INLET TO COMPRESSOR: (Continued)

RPM	Actual Speed	revolutions/minute
P01	Inlet Total Pressure	psia
T01	Inlet Total Temperature	$^{\circ}$R
PS	Inlet Static Pressure	psia
TS	Inlet Static Temperature	$^{\circ}$R
AL1	Inlet Air Angle	degrees
EPS1	Streamline Angle With Respect to Axis at Inlet	degrees
PERL	Percent Radial Height (From Hub)	%
R1	Radius at Inlet	inches
R/R_T	Streamline Radius/Actual Tip Radius	-
CX1	Inlet Axial Air Velocity	ft/sec
CU1	Inlet Tangential Air Velo- city	ft/sec
CR1	Inlet Radial Air Velocity	ft/sec
CM1	Inlet Meridional Air Velocity	ft/sec
U1	Blade Velocity Based on Radial at Inlet	ft/sec
CA1	Inlet Absolute Air Velocity	ft/sec
M1A	Inlet Absolute Mach No.	-
DW1	Incremental Flow Rate Between Streamlines	lbm/sec

OUTPUT: (Continued)

INLET TO COMPRESSOR: (Continued)

RC	Radius of Curvature of Streamline	inches
WCR1	Corrected Inlet Flow Rate	lbm/sec
NCR1	Corrected Wheel Speed	rpm
WC/A1	Ratio of Corrected Inlet Flow to Actual Inlet Area	lbm/sec
POA	Mass Averaged Total Pressure	psia
TOA	Mass Averaged Total Temperature	°R
PHI	Ratio of Inlet Axial Air Velocity to Blade Velocity at Mean Radii	
HUB/TIP	Ratio of Hub Radius to Tip Radius Actual	
AREA	Inlet Annular Area, Actual	inches ²
AREAE	Inlet Annual Area, Effective	inches ²
CP	Constant Pressure Specific Heat	Btu/lbm°R
GAMMA	Ratio of Specific Heats	

ROTOR OUTPUT:

PO1R	Total Pressure at Rotor Inlet, Relative to Rotor	psia
PO2R	Total Pressure at Rotor Exit, Relative to Rotor	psia

OUTPUT: (Continued)

ROTOR OUTPUT: (Continued)

TO1R	Total Temperature at Rotor Inlet, Relative to Rotor	$^{\circ}$ R
TO2R	Total Temperature at Rotor Exit, Relative to Rotor	$^{\circ}$ R
PS2	Static Pressure at Rotor Exit	psia
ZR	Rotor Loss Coefficient $\frac{PO1R - PO2R}{PO1R - PSI}$	-
PERL2	Percent Radial Height at Rotor Exit	%
R2	Radius at Rotor Exit	inches
R/R T	Radius at Streamline Divided by Tip Radius	-
B1	Inlet Air Angle, Relative to Rotor	degrees
THETA	Flow Turning Angle, (B1 - B2)	degrees
B2	Exit Air Angle, Relative to Rotor	degrees
DB1	Incidence Angle, (B1 - B1*)	degrees
SLD	Solidity, Ratio of Chord to Spacing	-
DFAC IR	Rotor Diffusion Factor	-
DP/QR	$\frac{PS2 - PSI}{PO1R - PSI}$ for Rotor	-
DEQUIV	Equivalent Diffusion Factor	-

OUTPUT: (Continued)

ROTOR OUTPUT:(Continued)

DW2	Incremental Flow Rate Between Streamlines at Rotor Exit	lb/sec
B1*	Angle Between Tangent to Blade Mean Camber Line and Axis at Inlet	degrees
THETA*	Blade Turning Angle ($B1^* - B2^*$)	degrees
B2*	Angle Between Tangent to Blade Mean Camber Line and Axis at Exit	degrees
DEV	Deviation Angle, ($B2 - B2^*$)	degrees
EPS2	Streamline Angle With Respect to Axis, at Rotor Exit	degrees
RC2	Radius of Curvature of Stream- line at Exit	degrees
F-TANG	Tangential Force on Blades	lbf
F-AXIAL	Axial Force on Blades	lbf
R-STRESS	Radius at Which Forces are Given	inches
M1R	Inlet Relative Mach No.	-
M2R	Exit Relative Mach No.	-
W1R	Inlet Air Velocity, Relative to Blade	ft/sec
W2R	Exit Air Velocity, Relative to Blade	ft/sec
CX2	Exit Axial Air Velocity	ft/sec

OUTPUT: (Continued)

ROTOR OUTPUT: (Continued)

WU2	Exit Tangential Air Velocity	ft/sec
CM2	Exit Meridional Air Velocity	ft/sec
CR2	Exit Radial Air Velocity	ft/sec
U2	Exit Blade Velocity	ft/sec
PRS	Stage Total Pressure Ratio	-
TRS	Stage Total Temperature Ratio	-
EFFS	State Efficiency	%
PRC	Cumulative Total Pressure Ratio	-
TRC	Cumulative Total Tempera- ture Ratio	-
EFFC	Cumulative Efficiency	%
MX2	Axial Mach No. at Rotor Exit	-
CX2/CX1	Ratio of Exit to Inlet Axial Velocity	-
WCR2	Corrected Flow Rate, at Rotor Exit	lbm/sec
NCR2	Corrected Wheel Speed, at Rotor Exit	rev/min
WC/A2	Ratio of Corrected Exit Flow Rate to Actual Rotor Exit Area	lbm/sec ft ²
PRSA	Mass Averaged Stage Pressure Ratio	-
TRSA	Mass Averaged Stage Tempera- ture Ratio	-

OUTPUT: (Continued)

ROTOR OUTPUT: (Continued)

EFFSA	Mass Averaged Stage Efficiency	%
PRCA	Mass Averaged Cumulative Pressure Ratio	-
TRCA	Mass Averaged Cumulative Temperature Ratio	-
EFFCA	Mass Averaged Cumulative Efficiency	%
PO2A	Mass Averaged Total Pressure at Rotor Exit	psia
TO2A	Mass Averaged Total Temperature at Rotor Exit	°R
PHI2	Flow Coefficient - Ratio of Rotor Exit Axial Air Velocity to Rotor Exit Mean Blade Velocity	-
PSI2	Pressure Coefficient	-
AREA2	Actual Rotor Exit Area	inches ²
AREE2	Effective Rotor Exit Area	inches ²
HPS	Stage Horsepower (Absorbed)	horsepower
HPC	Cumulative Stage Horsepower	horsepower
CP	Specific Heat Constant Pressure	Btu/lbm °R
GAMMA	Ratio of Specific Heats	-

STATOR OUTPUT:

PO2A	Absolute Total Pressure at Stator Inlet	psia
------	---	------

OUTPUT: (Continued)

STATOR OUTPUT: (Continued)

PO3A	Absolute Total Pressure at Stator Exit	psia
TO23A	Absolute Total Temperature through Stator (at both Inlet and Exit)	$^{\circ}$ R
PS3	Static Pressure at Stator Exit	psia
ZS	Stator Loss Coefficient	-
DPO/P	Ratio of Total Pressure Loss Across Stator to Stator Inlet Total Pressure	-
PERL3	Percent Length (from Hub) at Stator Exit	-
R3	Radius, at Stator Exit	inches
R/RT	Radius at Streamline Divided by Tip Radius	-
AL2	Stator Inlet Air Angle	degrees
THETA	Stator Flow Turning Angle	degrees
AL3	Stator Exit Air Angle	degrees
DAL2	Stator Incidence Angle	degrees
SLD	Solidity; Ratio of Vane Chord to Spacing	-
DFACTS	Stator Diffusion Factor	-
DP/QS	$\frac{PS3 - PS2}{PS2A - PS2}$	-
DEQUIV	Equivalent Diffusion Parameter	-

OUTPUT: (Continued)

STATOR OUTPUT: (Continued)

DW3	Incremental Flow Rate Between Streamlines, at Stator Exit	lbm/sec
AL2*	Stator Inlet Metal Angle; Angle between Tangent to Vane Element Mean Line at Leading Edge and Axis	degrees
THETA*	Vane Camber or Turning Angle	degrees
AL3*	Stator Exit Metal Angle; Angle between Tangent to Vane Element Mean Line at Trailing Edge and Axis	degrees
DEV	Stator Deviation Angle	degrees
EPS3	Streamline Angle With Respect to Axis, at Stator Exit	degrees
RC3	Radius of Curvature of Streamlines at Stator Exit	inches
F-TANG	Tangential Force on Blades	lb
F-AXIAL	Axial Force on Blades	lb
R-STRESS	Radius at Which F-TANG and F-AXIAL Are Given	inches
M2A	Stator Inlet Absolute Mach No.	-
M3A	Stator Exit Absolute Mach No.	-
C2A	Stator Inlet Absolute Air Velocity	ft/sec
C3A	Stator Exit Absolute Air Velocity	ft/sec
CX3	Stator Exit Axial Air Velocity	ft/sec

OUTPUT: (Continued)

STATOR OUTPUT: (Continued)

CU3	Stator Exit Tangential Air Velocity	ft/sec
CM3	Stator Exit Meridional Air Velocity	ft/sec
CR3	Stator Exit Radial Air Velocity	ft/sec
U3	Blade Velocity, Based on R3, of Next Rotor	ft/sec
PRS	Stage Total Pressure Ratio	-
TRS	Stage Total Temperature Ratio	-
EFFS	Stage Efficiency	-
PRC	Cumulative Total Pressure Ratio	-
TRC	Cumulative Total Temperature Ratio	-
EFFC	Cumulative Efficiency	%
MX3	Axial Mach No. at Stator Exit	-
CU2	Stator Inlet Tangential Velocity	ft/sec
WCR3	Corrected Flow Rate, at Stator Exit	lbm/sec
NCR2	Corrected Wheel Speed, at Stator Exit	rev/min
WC/A3	Ratio of Corrected Exit Flow to Actual Stator Exit Area	lbm/sec ft ²

OUTPUT: (Continued)

STATOR OUTPUT: (Continued)

PRSA	Mass Averaged Stage Pressure Ratio	-
TRSA	Mass Averaged Stage Temperature Ratio	-
EFFSA	Mass Averaged Stage Efficiency	%
PRCA	Mass Averaged Cumulative Pressure Ratio	-
TRCA	Mass Averaged Cumulative Temperature Ratio	-
EFFCA	Mass Averaged Cumulative Efficiency	%
PO3A	Mass Averaged Total Pressure at Stator Exit	psia
TO3A	Mass Averaged Total Temperature at Stator Edge	°R
PHI3	Flow Coeffieicnt - Ratio of Stator Exit Axial Air Velocity to Rotor Inlet Mean Blade Velocity	-
PSI3	Pressure Coefficient	-
AREA3	Stator Exit Area, Actual	inches ²
AREE3	Stator Exit Area, Effective	inches ²
CP	Specific Heat Constant Pressure	Btu/lbm °R
GAMMA	Ratio of Specific Heats	-

APPENDIX II

COMPUTOR OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - ORIGNAL DESIGN

TABLE IV
COMPUTER OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - ORIGNAL DESIGN
TEST NUMBER 19

***** INLET *****									
RPM = 0.5603000 05 FLOM = 0.3640000 01									
STRA	PUB	PS	T01	TS	ALI	EPS1	PERL	R/R1	
1	0.1125000 02	0.4190000 03	0.4638840 01	0.3984460 03	0.0	0.0	0.5000000D-02	0.1346900 01	0.4951840 00
2	0.1125000 02	0.4190000 03	0.4638840 01	0.3984460 03	0.0	0.0	0.2285130 00	0.1655430 01	0.6086140 00
3	0.1125000 02	0.4190000 03	0.4638840 01	0.3984460 03	0.0	0.0	0.4155290 00	0.1913430 01	0.7034670 00
4	0.1125000 02	0.4190000 03	0.4638840 01	0.3984460 03	0.0	0.0	0.5810910 00	0.211850 01	0.7874450 00
5	0.1125000 02	0.4190000 03	0.4638840 01	0.3984460 03	0.0	0.0	0.7305680 00	0.238160 01	0.8632930 00
6	0.1125000 02	0.4190000 03	0.4638840 01	0.3984460 03	0.0	0.0	0.8671390 00	0.2556450 01	0.9325950 00
7	0.1125000 02	0.4190000 03	0.4638840 01	0.3984460 03	0.0	0.0	0.9950000 00	0.2713100 01	0.9974430 00
SIHM	CAL	CUL	CM1	CM2	U1	CA1	MA1	OM1	PC
1	0.4962100 03	0.1	0.4962100 03	0.6563720 03	0.4962100 03	0.4962100 03	0.5068440 00	0.0	0.1000000 01
2	0.4962100 03	0.0	0.4962100 03	0.8094290 03	0.4962100 03	0.4962100 03	0.5068440 00	0.6412500 00	0.1000000 01
3	0.4962100 03	0.0	0.4962100 03	0.9355790 03	0.4962100 03	0.4962100 03	0.5068440 00	0.63774100 00	0.1000000 01
4	0.4962100 03	0.0	0.4962100 03	0.1046220 04	0.4962100 03	0.4962100 03	0.5068440 00	0.6412500 00	0.1000000 01
5	0.4962100 03	0.0	0.4962100 03	0.116140 04	0.4962100 03	0.4962100 03	0.5068440 00	0.6412500 00	0.1000000 01
6	0.4962100 03	0.0	0.4962100 03	0.1240310 04	0.4962100 03	0.4962100 03	0.5068440 00	0.6377410 00	0.1000000 01
7	0.4962100 03	0.0	0.4962100 03	0.132658D 04	0.4962100 03	0.4962100 03	0.5068440 00	0.6412500 00	0.1000000 01
TL41	NCPL	NC/AL	PUA	TOA	PHI	WU3/TIP	AREA	AR&AE	
0.45046710 01	0.6234070 05	0.3689370 02	0.1125000 02	0.4190000 03	0.4999210 00	0.4926470 00	0.1760170 02	0.1742570 02	
CP	GAMA								
0.2393140 00	0.1401620 01								

TABLE IV - Continued

TABLE IV - Continued

TABLE IV - Continued

***** STATOR *****											
STRM	P02A	P13A	T023A	P53	PS3	DEU/PD	DEU/PD	PERL3	R3	R/R3	
1	0.237750 0.2	0.242990 0.2	0.153550 0.3	0.190640 0.2	0.3988130-0.01	0.150000-0.01	0.1932000 0.1	0.7102940 0.0	0.7102940 0.0	0.7102940 0.0	
2	0.231940 0.2	0.222360 0.2	0.532530 0.3	0.190640 0.2	0.4481620-0.01	0.200000-0.01	0.2022620 0.0	0.2081810 0.1	0.7653710 0.0	0.8164440 0.0	
3	0.226950 0.2	0.2224140 0.2	0.5369310 0.3	0.190640 0.2	0.4968170 0.0	0.200000-0.01	0.5375911 0.0	0.2240730 0.1	0.8647870 0.0	0.2352220 0.1	
4	0.2249380 0.2	0.2204090 0.2	0.5416650 0.3	0.190640 0.2	0.537530-0.01	0.200000-0.01	0.5402760 0.0	0.2352220 0.1	0.8647870 0.0	0.2352220 0.1	
5	0.2177010 0.2	0.2133530 0.2	0.5569050 0.3	0.190640 0.2	0.6094140-0.01	0.200000-0.01	0.6959210 0.0	0.2476740 0.1	0.9105670 0.0	0.2476740 0.1	
6	0.2129430 0.2	0.2086440 0.2	0.5768000 0.3	0.190640 0.2	0.6094140-0.01	0.200000-0.01	0.6959210 0.0	0.2476740 0.1	0.9105670 0.0	0.2476740 0.1	
7	0.2166160 0.2	0.2172830 0.2	0.5952110 0.3	0.190640 0.2	0.7203380-0.01	0.200000-0.01	0.7950000 0.0	0.2703000 0.1	0.9355880 0.0	0.2703000 0.1	
STRM	AL2	AL2*	AL3	DAL2	SLO	DFACTS	DRYQS	DEQIVY	DM3	R-STRESS	
1	0.4412330 0.2	0.4442350 0.2	0.0	-0.151640 0.1	0.228000 0.1	0.6076350 0.0	0.5048380 0.0	0.2252070 0.1	0.0	0.0	
2	0.4600220 0.2	0.4600270 0.2	0.0	-0.201470 0.1	0.2138190 0.1	0.6063690 0.0	0.6063690 0.0	0.2247140 0.1	0.0	0.0	
3	0.4569490 0.2	0.4569490 0.2	0.0	-0.7778620 0.0	0.1992270 0.1	0.6179710 0.0	0.6027130 0.0	0.2262280 0.1	0.0	0.0	
4	0.4710290 0.2	0.4710290 0.2	0.0	0.1922670 0.1	0.1867780 0.1	0.6249310 0.0	0.5952600 0.0	0.2255980 0.1	0.0	0.0	
5	0.5492210 0.2	0.5492210 0.2	0.0	0.994380 0.1	0.1742260 0.1	0.6892220 0.0	0.5210800 0.0	0.2125530 0.1	0.0	0.0	
6	0.692590 0.2	0.692590 0.2	0.0	0.261150 0.2	0.1625240 0.1	0.7641130 0.0	0.382240 0.0	0.2316550 0.1	0.0	0.0	
7	0.8933630 0.2	0.8933630 0.2	0.0	0.4701610 0.2	0.1512000 0.1	0.7467540 0.0	0.5681440 0.0	0.1926100 0.1	0.0	0.0	
STRM	M2A	M3A	AL3*	DEV	EPS3	RC3	F-TANG	F-AXIAL	F-AXIAL	R-STRESS	
1	0.493400 0.2	0.499400 0.2	0.0	0.0	0.0	0.1000000 0.1	0.182960 0.2	0.0	0.0	0.0	
2	0.490170 0.2	0.480170 0.2	0.0	0.0	0.0	0.1000000 0.1	0.182960 0.2	0.0	0.0	0.0	
3	0.4647270 0.2	0.4647270 0.2	0.0	0.0	0.0	0.1000000 0.1	0.1540180 0.2	0.0	0.0	0.0	
4	0.4517610 0.2	0.4517610 0.2	0.0	0.0	0.0	0.1000000 0.1	0.1420400 0.2	0.0	0.0	0.0	
5	0.4408140 0.2	0.4408140 0.2	0.0	0.0	0.0	0.1000000 0.1	0.1297560 0.2	0.0	0.0	0.0	
6	0.4314440 0.2	0.4314440 0.2	0.0	0.0	0.0	0.1000000 0.1	0.1178610 0.2	0.0	0.0	0.0	
7	0.4232050 0.2	0.4232050 0.2	0.0	0.0	0.0	0.1000000 0.1	0.1124000 0.2	0.0	0.0	0.0	
STRM	M2A	M3A	C2A	L_A	CX3	CD3	CM3	CM3	CM3	U3	
1	0.1048400 0.1	0.5428230 0.0	0.010175100 0.6	0.5975810 0.3	0.5975810 0.3	0.0	0.5975810 0.3	0.0	0.0	0.9446590 0.3	
2	0.9503150 0.0	0.5075820 0.0	0.99686810 0.3	0.5998860 0.3	0.5998860 0.3	0.0	0.5998860 0.3	0.0	0.0	0.9946590 0.3	
3	0.8802110 0.0	0.4742213 0.0	0.9319710 0.3	0.5262030 0.3	0.5262030 0.3	0.0	0.5262030 0.3	0.0	0.0	0.8647870 0.3	
4	0.4927610 0.0	0.4529830 0.0	0.9999810 0.3	0.5140400 0.3	0.5140400 0.3	0.0	0.5140400 0.3	0.0	0.0	0.1150130 0.3	
5	0.7752040 0.0	0.74040580 0.0	0.80294690 0.3	0.49593120 0.3	0.49593120 0.3	0.0	0.49593120 0.3	0.0	0.0	0.1211010 0.3	
6	0.7158830 0.0	0.3615530 0.0	0.80294690 0.3	0.4206100 0.3	0.4206100 0.3	0.0	0.4206100 0.3	0.0	0.0	0.1268640 0.3	
7	0.6974290 0.0	0.3947303 0.0	0.7955500 0.3	0.4651150 0.3	0.4651150 0.3	0.0	0.4651150 0.3	0.0	0.0	0.1324090 0.3	
STRM	PR5	TWS	EFFS	HIC	IRC	FFFC	FFFC	CU2	CU2	CU2	
1	0.2911110 0.1	0.1273390 0.1	0.3535380 0.0	0.2071110 0.1	0.1273390 0.1	0.8677810 0.0	0.5427830 0.0	0.8042520 0.3	0.8042520 0.3	0.8042520 0.3	
2	0.2020520 0.1	0.1270950 0.1	0.4206113 0.0	0.2020520 0.1	0.1270951 0.1	0.8233290 0.0	0.5073820 0.0	0.7169850 0.3	0.7169850 0.3	0.7169850 0.3	
3	0.1977020 0.1	0.1270693 0.1	0.7795099 0.0	0.1977030 0.1	0.1276610 0.1	0.7786190 0.0	0.4742210 0.0	0.6712400 0.3	0.6712400 0.3	0.6712400 0.3	
4	0.1592020 0.1	0.1292160 0.1	0.7259590 0.0	0.1959230 0.1	0.1292760 0.1	0.7233170 0.0	0.4597830 0.0	0.6593060 0.3	0.6593060 0.3	0.6593060 0.3	
5	0.1496470 0.1	0.1324450 0.1	0.6205430 0.0	0.1896470 0.1	0.1322350 0.1	0.6199960 0.0	0.4040060 0.0	0.6266680 0.3	0.6266680 0.3	0.6266680 0.3	
6	0.1554327 0.1	0.1376110 0.1	0.51622830 0.0	0.15544910 0.1	0.1376610 0.1	0.5138320 0.0	0.2615530 0.0	0.7539340 0.3	0.7539340 0.3	0.7539340 0.3	
7	0.1866450 0.1	0.1420551 0.1	0.4744850 0.0	0.1866450 0.1	0.1420551 0.1	0.3947570 0.0	0.3947570 0.0	0.7965970 0.3	0.7965970 0.3	0.7965970 0.3	
STRM	MC43	MC42	MC/A3	PRSA	TASA	PRCA	EFFSA	PRCA	PRCA	EFFCA	
0.263770 0.1	0.5651760 0.5	0.3256210 0.2	0.1955550 0.1	0.1307580 0.1	0.61686640 0.0	0.1955550 0.1	0.1307580 0.1	0.1307580 0.1	0.1307580 0.1	0.61686640 0.0	
PJ3A	0.5418773 0.1	0.4596050 0.0	0.5409710 0.0	0.5409710 0.0	0.1166160 0.2	0.1166160 0.2	0.2398390 0.0	0.1400390 0.1	0.1400390 0.1	0.2398390 0.0	

TABLE IV - Continued

***** RUTOR 2*****											
STAR#	PC1A	PC2A	T01R	T02R	PS2	R	PFRL2	R/R1			
1	J-1576510 J2	2.1457500 .02	0.6194810 .03	0.6214850 .03	0.2437270 .02	0.3068100 .00	0.1500000 .01	0.209945D .01	0.771870 .00		
2	0.4143410 .02	0.4337100 .02	0.6130270 .03	0.6130270 .03	0.2461520 .02	0.3092860 .01	0.1926880 .00	0.2213270 .01	0.813730 .00		
1	0.60009920 .02	0.6335940 .02	0.6111520 .03	0.6111520 .03	0.2222160 .02	0.3174770 .00	0.3664940 .00	0.220890 .01	0.853670 .00		
2	0.4211330 .02	0.3101900 .02	0.6520780 .03	0.6589440 .03	0.2500310 .02	0.4600000 .00	0.5306860 .00	0.224330 .01	0.891990 .00		
5	0.4274130 .02	0.3491250 .02	0.6814950 .03	0.6814950 .03	0.4168640 .02	0.6816200 .00	0.6816200 .00	0.232540 .01	0.927710 .00		
6	0.4313510 .02	0.3681980 .02	0.7111490 .03	0.7136230 .03	0.2625440 .02	0.2894940 .00	0.8387860 .00	0.2618440 .01	0.962660 .00		
7	0.4317230 .02	0.3465510 .02	0.7415610 .03	0.7415610 .03	0.2645160 .02	0.2673260 .00	0.9800000 .00	0.2710550 .01	0.995260 .00		
STAR#	T01A		T02A		SLD		OFACR		OP/QR		QEDUV
1	0.5154270 .02	2.245470 .02	0.3109800 .02	0.3109800 .02	0.2390400 .01	0.2978280 .00	0.299030 .00	0.1596130 .01	0.0	0.0	Dm2
2	0.4111810 .02	0.2172550 .02	0.3945693 .02	0.3945693 .02	0.333210 .01	0.274770 .01	0.4235520 .01	0.296010 .00	0.1751660 .01	0.0	0.0
3	0.6114840 .02	0.1903110 .02	0.4511160 .02	0.4511160 .02	0.465180 .01	0.2165450 .01	0.6653860 .01	0.2272250 .00	0.1644390 .01	0.0	0.0
4	0.4591770 .02	0.1484770 .02	0.5103931 .02	0.5103931 .02	0.2000360 .01	0.516190 .00	0.236590 .00	0.197050 .01	0.6115650 .00	0.0	0.0
5	0.6122913 .02	0.34545190 .02	0.5377232 .02	0.5377232 .02	0.195950 .01	0.2152220 .00	0.290980 .00	0.1950220 .01	0.5500020 .00	0.0	0.0
6	0.7166530 .02	0.1671240 .02	0.5489329 .02	0.5489329 .02	0.1965180 .01	0.2436420 .00	0.3162420 .00	0.1760860 .01	0.5757150 .00	0.0	0.0
7	0.7054520 .02	0.11605810 .02	0.5920410 .02	0.5920410 .02	0.1769600 .01	0.4208310 .00	0.2782420 .00	0.1170760 .01	0.5887100 .00	0.0	0.0
STAR#	T01A		T02A		DEV		EPS2		RE2		F-AXIAL
1	J-5113030 J2	2.179000 .02	0.2354000 .02	0.2354000 .02	0.3558010 .01	0.0	0.1000000 .01	0.0	0.0	0.0	R-STRESS
2	0.5545013 J2	0.7048240 .02	0.3540710 .02	0.3540710 .02	0.3731920 .01	0.0	0.1000000 .01	0.0	0.0	0.0	0.0
3	0.5546660 .02	0.1752290 .02	0.47037361 .02	0.47037361 .02	0.5037760 .01	0.0	0.1000000 .01	0.0	0.0	0.0	0.0
4	0.5542290 .02	0.1522790 .02	0.4404403 .02	0.4404403 .02	0.6995040 .01	0.0	0.1000000 .01	0.0	0.0	0.0	0.0
5	0.55434970 .02	0.13545170 .02	0.4744460 .02	0.4744460 .02	0.5332770 .01	0.0	0.1000000 .01	0.0	0.0	0.0	0.0
6	0.5541930 .02	0.1185530 .02	0.5034790 .02	0.5034790 .02	0.6805320 .01	0.0	0.1000000 .01	0.0	0.0	0.0	0.0
7	0.5543010 .02	0.1054300 .02	0.5285000 .02	0.5285000 .02	0.61930970 .01	0.0	0.1000000 .01	0.0	0.0	0.0	0.0
STAR#	T01P		T02P		M1R		C1R		M2		CR?
1	0.1175810 .01	0.7120410 .00	0.1117810 .04	0.1117810 .04	0.8116080 .03	0.4545290 .03	0.6761860 .03	0.6455280 .03	0.102630 .04	0.0	0.0
2	0.10527810 .01	0.6644360 .00	0.11611870 .04	0.11611870 .04	0.7839270 .03	0.6322760 .03	0.6916860 .03	0.6052760 .03	0.0	0.0	0.0
1	0.10474710 .01	0.6844420 .00	0.12054720 .04	0.12054720 .04	0.5413070 .03	0.5655460 .03	0.5433070 .03	0.5033070 .03	0.0	0.0	0.0
4	0.1125730 .01	0.6101623 .01	0.1259760 .04	0.1259760 .04	0.4700640 .03	0.5812720 .03	0.4700640 .03	0.5032730 .03	0.0	0.0	0.0
5	0.1139210 .01	0.63034410 .00	0.1295140 .04	0.1295140 .04	0.4550750 .03	0.5827200 .03	0.4550750 .03	0.5032730 .03	0.0	0.0	0.0
6	0.1149340 .01	0.612170 .00	0.1304490 .04	0.1304490 .04	0.4983450 .01	0.557070 .00	0.4983450 .03	0.5032730 .03	0.0	0.0	0.0
7	0.1119111 .01	0.7552640 .00	0.14314490 .04	0.14314490 .04	0.49164940 .03	0.8193100 .03	0.49194940 .03	0.0	0.0	0.0	0.0
STAR#	P45		P55		P65		P7C		M2		M2
1	0.12255410 .01	0.1161130 .01	0.7121710 .00	0.7121710 .00	0.3221450 .01	0.1501350 .01	0.7825810 .00	0.598530 .00	0.1166090 .01	0.0	0.0
2	0.1252110 .01	0.1149060 .01	0.6551740 .00	0.6551740 .00	0.3095680 .01	0.1522670 .01	0.7294040 .00	0.5130520 .00	0.1060680 .01	0.0	0.0
3	0.120410 .01	0.1201690 .01	0.6236950 .00	0.6236950 .00	0.3032940 .01	0.1543110 .01	0.6871150 .00	0.4550690 .00	0.1032500 .01	0.0	0.0
4	0.1251490 .01	0.1220680 .01	0.5752200 .00	0.5752200 .00	0.2975800 .01	0.1578040 .01	0.6322120 .00	0.3873730 .00	0.9144010 .01	0.0	0.0
5	0.1251320 .01	0.1225190 .01	0.6144030 .00	0.6144030 .00	0.2935630 .01	0.1622850 .01	0.591340 .00	0.332620 .00	0.9948620 .00	0.0	0.0
6	0.1208350 .01	0.1205700 .01	0.7109450 .00	0.7109450 .00	0.4983450 .01	0.1637950 .01	0.557070 .00	0.4983450 .00	0.1214730 .01	0.0	0.0
7	0.11840470 .01	0.1184240 .01	0.6990060 .00	0.6990060 .00	0.2907540 .01	0.1637950 .01	0.5185050 .00	0.3865270 .00	0.1056710 .01	0.0	0.0
STAR#	PC42		NC92		MC/A2		P45A		TRSA		EFFCA
0.1669710 .01	0.44505050 .05	0.2828140 .32	0.1550680 .01	0.1208740 .01	0.640390 .00	0.3032150 .01	0.1505080 .01	0.6426400 .00	0.11490660 .03	0.3111210 .03	MPG
STAR#	PC2A		T02A		PH12		PS12		AREA2		AREG2
0.3411400 .02	0.6622630 .01	0.40122810 .00	0.3415540 .00	0.910970 .01	0.9234370 .01	0.140000 .01	0.140000 .01	0.140000 .01	0.140000 .01	0.3111210 .03	GAMMA
STAR#	CP		GAMMA		0.1400340 .00		0.1400340 .00		0.1400340 .00		0.1400340 .00

TABLE IV - Continued

***** STATOR *****											
***** STATOR *****											
STREAM	PO2A	PO3A	T023A	PS3	ZS	QPO/PD	PERL3	R3	P/R		
1	0.362500 02	0.3551620 02	0.6315810 03	0.2903950 02	0.6101180-01	0.2000000-01	0.15C3300-01	0.2143170 01	0.002638C 00		
2	0.3442640 02	0.3412490 02	0.6300000 03	0.2903950 02	0.4951460-02	0.2000000-01	0.1926310 01	0.1828000 01	0.0382360 00		
3	0.3412660 02	0.3343820 02	0.6465640 03	0.2903950 02	0.7666430-01	0.2000000-01	0.3620020 00	0.2372330 01	0.0721820 00		
4	0.334770 02	0.3280820 02	0.6612000 03	0.2903950 02	0.8502660-01	0.2000000-01	0.2611140 00	0.2461730 01	0.0505060 00		
5	0.3358160 02	0.3250990 02	0.64799750 03	0.2903950 02	0.880370-01	0.2000000-01	0.6843940 00	0.2547990 01	0.9367810 00		
6	0.3356380 02	0.3288250 02	0.6448721 03	0.2903950 02	0.9181740-01	0.2000005-01	0.8365860 00	0.2630940 01	0.9672510 00		
7	0.3270490 02	0.3205570 02	0.7072520 03	0.2903950 02	0.1050370 00	0.2000000-01	0.9850000 00	0.2711820 01	0.9969940 00		
STREAM	AL2	IMFTA	AL3	DAL2	SLO	DFACTS	DPQS	DEQUIV	DN3		
1	0.3893990 02	0.3934950 02	0.0	-0.7554980 01	0.2293500 01	0.4156310 00	0.3924360 00	0.1730100 01	0.0		
2	0.4397510 02	0.4391510 02	0.0	-0.2012370 01	0.2203670 01	0.4201850 00	0.4210380 00	0.1798380 01	0.7575610 00		
3	0.4712930 02	0.4712930 02	0.0	0.2206890 01	0.2118960 01	0.4817520 00	0.4201850 00	0.1826490 01	0.6829210 00		
4	0.5211440 02	0.5211440 02	0.0	0.7772200 01	0.20516940 C.	0.5113120 00	0.240 00	0.181910 01	0.6274650 00		
5	0.5294070 02	0.5290750 02	0.0	0.9270560 01	0.1951800 01	0.4892070 00	0.4029950 00	0.1807520 01	0.6048550 00		
6	0.4723830 02	0.4723830 02	0.0	0.4242940 01	0.1881710 01	0.4758580 00	0.3797380 00	0.1781900 01	0.6020320 00		
7	0.4583650 02	0.4583650 02	0.0	0.3434950 01	0.1800150 01	0.5019100 00	0.4092440 00	0.1886230 01	0.5651520 00		
STREAM	AL7*	IMETA*	AL3*	0EV	EPS3	RC3	F-TANG	F-AXIAL	R-STRESS		
1	0.4695910 02	0.4695900 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0		
2	0.4598720 02	0.4598720 02	0.0	0.0	0.0	0.1000000 01	0.1361310 02	0.2193970 01	0.2193970 01		
3	0.4512260 02	0.4512260 02	0.0	0.0	0.0	0.1057000 01	0.1245300 02	0.5550170 01	0.2296620 01		
4	0.44346210 02	0.4436220 02	0.0	0.0	0.0	0.1000000 01	0.1163790 02	0.5737950 01	0.2394820 01		
5	0.4336384 02	0.4361690 02	0.0	0.0	0.0	0.1000000 01	0.113890 02	0.5643290 01	0.2894600 01		
6	0.42494510 02	0.4249540 02	0.0	0.0	0.0	0.1000000 01	0.1084720 02	0.51175740 01	0.2380210 01		
7	0.42493030 02	0.4249300 02	0.0	0.0	0.0	0.1000000 01	0.9294370 01	0.4074970 01	0.2667940 01		
STREAM	AL2*	IM3A	C2A	C3A	CX3	LU3	CP3	U3			
1	0.7745980 03	0.7447670 00	0.9010910 00	0.6517640 03	0.6517640 03	0.0	0.6517640 03	0.0	0.1067470 04		
2	0.7129380 00	0.49463610 00	0.8410910 00	0.5884990 03	0.5884990 03	0.0	0.5884990 03	0.0	0.1114820 04		
3	0.6714670 00	0.4538840 00	0.8015920 03	0.5544960 03	0.5544960 03	0.0	0.5544960 03	0.0	0.1159960 04		
4	0.6331960 00	0.4216660 00	0.7654420 03	0.5223520 03	0.5223520 03	0.0	0.5223520 03	0.0	0.1203620 04		
5	0.6177610 03	0.42236640 00	0.7611870 03	0.5162610 03	0.5368610 03	0.0	0.5368610 03	0.0	0.125810 04		
6	0.60286180 00	0.42616660 00	0.75216660 03	0.5097470 03	0.5097470 03	0.0	0.5097470 03	0.0	0.1286410 04		
7	0.5576110 00	0.3749420 00	0.7354270 03	0.4871130 03	0.4871130 03	0.0	0.4871130 03	0.0	0.1325960 04		
STREAM	TR5	EFF5	PAC	TAC	EFF3	M3	CU2				
1	0.1124300 01	0.1181730 01	0.6911490 00	0.3157000 01	0.1503750 01	0.7687240 00	0.5444610 03	0.5721060 03			
2	0.1501390 01	0.12036630 01	0.6222510 00	0.2572290 01	0.1543110 01	0.6725500 00	0.5846010 03	0.5846010 03			
3	0.1503220 01	0.12036630 01	0.5925010 00	0.2572290 01	0.1543110 01	0.6725500 00	0.5893800 03	0.5893800 03			
4	0.1488610 01	0.1220680 01	0.5650080 00	0.2916780 01	0.1518040 01	0.6191010 00	0.4216660 00	0.6041170 03			
5	0.1542210 01	0.1222190 01	0.5453110 00	0.2925310 01	0.1622850 01	0.5764920 00	0.4227060 00	0.6071700 03			
6	0.1576110 01	0.1204700 01	0.6187140 00	0.2923860 01	0.1658410 01	0.5450490 00	0.4261450 00	0.5522250 03			
7	0.1510050 01	0.1186240 01	0.6651820 00	0.2849490 01	0.1687950 01	0.5071450 00	0.378920 00	0.5066240 03			
MCM3	MC2	MC/A3	PRSA	TASA	EFFSA	PCLA	TRCA	EFFCA			
0.1410410 01	0.4496710 05	0.3281420 02	0.1518400 01	C.1203920 01	0.6048000 00	0.2969120 01	0.158810 01	0.6271510 00			
PO2A	T03A	PHL3	PS13	AREA3	APCE3	CP	GAMMA				
0.3349190 02	0.6627770 03	0.4101140 00	0.3258310 00	0.3381060 01	0.8129630 01	0.2410400 00	0.1397500 01				

TABLE V
COMPUTER OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - ORIGINAL DESIGN-
TEST NUMBER 20

***** INLET *****									
STN	P11	T01	PS	T5	All	T051	PERL	R1	R/R7
1	0.1101330 02	0.5489000 03	0.9421330 01	0.5240790 03	0.0	0.0	0.5000000 -0.2	0.1346900 01	0.4951840 00
2	0.1101330 02	0.5489000 03	0.9421303 01	0.5240790 01	0.0	0.0	0.2857300 00	0.1655430 01	0.6086140 00
3	0.1101330 02	0.5489000 03	0.9421303 01	0.5240790 03	0.0	0.0	0.4555290 00	0.1919436 01	0.7034670 00
4	0.1101330 02	0.5489000 03	0.9421303 01	0.5240790 03	0.0	0.0	0.5810510 00	0.2141850 01	0.7814450 00
5	0.1101330 02	0.5489000 03	0.9421300 01	0.5240790 03	0.0	0.0	0.7054800 00	0.2349160 01	0.8632930 00
6	0.1101330 02	0.5489000 03	0.9421300 01	0.5240790 03	0.0	0.0	0.8671390 00	0.2536650 01	0.9325920 00
7	0.1101330 02	0.5489000 03	0.9421300 01	0.5240790 03	0.0	0.0	0.9950000 00	0.2713100 01	0.9974630 00
STN	C41	C41	C41	C41	U1	C41	C41	MIA	RC
1	0.3358990 03	0.0	0.0	0.3358990 03	0.7187520 03	0.5358990 03	0.4774860 00	0.1000000 01	
2	0.3358990 03	0.0	0.0	0.3358990 03	0.8833970 03	0.5358990 03	0.4774860 00	0.5255450 00	0.1000000 01
3	0.3358990 01	0.0	0.0	0.3358990 03	0.1021070 06	0.5358990 03	0.4774860 00	0.5222990 00	0.1000000 01
4	0.3358990 03	0.0	0.0	0.3358990 03	0.1142970 06	0.5358990 03	0.4774860 00	0.5255450 00	0.1000000 01
5	0.3358990 03	0.0	0.0	0.3358990 03	0.1253060 06	0.5358990 03	0.4774860 00	0.5255450 00	0.1000000 01
6	0.3358990 03	0.0	0.0	0.3358990 03	0.1353640 06	0.5358990 03	0.4774860 00	0.5222980 00	0.1000000 01
7	0.3358990 03	0.0	0.0	0.3358990 03	0.1447800 06	0.5358990 03	0.4774860 00	0.5255450 00	0.1000000 01
MCA1	MCA1	MC11	POA	TOA	PMI	MUR/TIP	AREA	AREA	
0.3317590 01	0.54949280 05	0.3532220 02	0.1101300 02	0.5488000 03	0.4947010 00	0.4926470 00	0.1760170 02	0.1742570 02	
CP	GA4MA								
0.2344640 00	0.1400390 01								

TABLE V - Continued

TABLE V - Continued

TABLE V - Continued

***** STATUS *****											
STR#	P1#	P2#	P3#	T0#	T1#	T2#	T3#	OPD/PO	PERL3	R3	R/R1
1	0.2220040 02	0.2181520 02	0.6684010 03	0.1877100 02	0.436610D-01	0.2000000-01	0.1500000-01	0.1932000 01	0.7102900 00	0.7102900 00	0.7102900 00
2	0.2221310 02	0.2178210 02	0.6843120 03	0.1877100 02	0.4854510-01	0.2000000-01	0.1500000-01	0.201810 01	0.7653710 00	0.7653710 00	0.7653710 00
3	0.2194770 02	0.2193010 02	0.6930310 03	0.1877100 02	0.5358170-01	0.2000000-01	0.3759110 00	0.220270 00	0.220270 00	0.220270 00	0.220270 00
4	0.2149740 02	0.2102920 02	0.6981510 03	0.1877100 02	0.4604520-01	0.2000000-01	0.540760 00	0.232220 01	0.232220 01	0.232220 01	0.232220 01
5	0.2111913 02	0.2096750 02	0.7035540 03	0.1877100 02	0.6658770-01	0.2000000-01	0.69592270 00	0.2446740 01	0.2446740 01	0.2446740 01	0.2446740 01
6	0.2127100 02	0.2096760 02	0.7157620 03	0.1877100 02	0.7122770-01	0.2000000-01	0.8435520 00	0.2554600 01	0.2554600 01	0.2554600 01	0.2554600 01
7	0.2139410 02	0.2096760 02	0.7152200 03	0.1877100 02	0.7610320-01	0.2000000-01	0.9850000 00	0.2708000 01	0.2708000 01	0.2708000 01	0.2708000 01
STR#	AL2*	AL2*	AL3*	AL2*	SLD	OFAC1	DP/QS	DEQULV	0W3		
1	0.5179360 02	0.519360 02	0.0	0.1855560 01	0.2286800 01	0.6553670 00	0.6553670 00	0.2414150 01	0.0		
2	0.46948170 02	C.489170 02	0.0	0.9644080 00	0.2186190 01	0.540760 00	0.6230550 00	0.234210 01	0.5947690 00		
3	0.4903946 02	C.4903640 02	0.0	0.2621310 01	0.1992220 01	0.634400 00	0.6087310 00	0.2287690 01	0.5772350 00		
4	0.5087600 02	0.5086600 02	0.0	0.5719680 01	0.1867780 01	0.6658100 00	0.6222810 00	0.2361680 01	0.5355470 00		
5	0.5563250 02	0.5563260 02	0.0	0.1155120 02	0.1743260 01	0.6950620 00	0.619380 00	0.2368640 01	0.4888970 00		
6	0.6700390 02	0.6700380 02	0.0	0.23855740 02	0.1625400 01	0.7101990 00	0.5815560 00	0.2190270 01	0.4715550 00		
7	0.7756130 02	0.7756330 02	0.0	0.3524330 02	0.1512000 01	0.7117620 00	0.532290 00	0.191410 01	0.470790 00		
STR#	AL2*	THETA*	AL3*	AL2*	DEV	EPS3	RC3	F-TANG	F-AXIAL	R-STRESS	
1	0.4449000 02	0.4994000 02	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
2	0.4801740 02	C.4801740 02	0.0	0.0	0.0	0.0	0.0	0.1589110 02	-0.9626720 01	0.1924600 01	
3	0.4644770 02	0.4644770 02	0.0	0.0	0.0	0.0	0.0	0.1422000 02	-0.8446080 01	0.2089220 01	
4	0.4717620 02	0.4717620 02	0.0	0.0	0.0	0.0	0.0	0.1256590 02	-0.7866480 01	0.2241980 01	
5	0.4600814 02	0.4600814 02	0.0	0.0	0.0	0.0	0.0	0.1131730 02	-0.7462220 01	0.2384950 01	
6	0.5131444 02	0.51314440 02	0.0	0.0	0.0	0.0	0.0	0.1151690 02	-0.8538720 01	0.2519310 01	
7	0.4252700 02	0.4252700 02	0.0	0.0	0.0	0.0	0.0	0.1242190 02	-1.033770 02	0.2646750 01	
STR#	M2A	M2A	C2A	C3A	C3A	CX3	CU3	CM3	U3		
1	0.977654 03	0.4697740 00	0.1151960 04	0.5911570 03	0.5911570 03	0.0	0.5911570 03	0.0	0.1030940 04		
2	0.4044950 00	0.4689460 00	0.0104950 00	0.5655080 03	0.5655080 03	0.0	0.5855080 03	0.0	0.1110930 04		
3	0.4455140 00	0.4455140 00	0.0	0.4456320 04	0.568370 03	0.0	0.568370 03	0.0	0.1185060 04		
4	0.7409610 00	0.4008840 00	0.9550470 03	0.5175630 03	0.5175630 03	0.0	0.5175630 03	0.0	0.1255220 04		
5	0.7327560 00	0.387030 00	0.9099210 03	0.4926870 03	0.4926870 03	0.0	0.4926870 03	0.0	0.1321670 04		
6	0.702013 00	C.1404450 03	0.881360 03	0.5101130 03	0.5101130 03	0.0	0.5306930 03	0.0	0.1384570 04		
7	0.6745100 00	0.40305640 00	0.86033360 03	0.5306930 03	0.5306930 03	0.0	0.5306930 03	0.0	0.1445080 04		
STR#	PRS	TRS	EFFS	PRC	TRC	EFFC	MX3	CU2			
1	0.198670 01	0.1226210 01	0.6436610 00	0.198670 01	0.1226210 01	0.8405390 00	0.4497790 00	0.9011920 03			
2	0.197667 01	0.1256150 01	0.8197210 00	0.197667 01	0.1244660 01	0.8186150 00	0.4444640 00	0.8104670 03			
3	0.195614 01	0.1244660 01	0.790500 00	0.195614 01	0.1244660 01	0.790500 00	0.4479280 00	0.7711230 03			
4	0.1909490 01	0.1240401 01	0.7413810 00	0.1909490 01	0.1240401 01	0.7413810 00	0.4060840 00	0.7411190 03			
5	0.1835710 01	0.1259272 01	0.611660 00	0.1835710 01	0.1259272 01	0.6687000 00	0.3827030 00	0.750810 03			
6	0.1692810 01	0.132630 01	0.5640970 00	0.1692810 01	0.132630 01	0.5619480 00	0.389450 00	0.8205060 03			
7	0.1904150 01	0.1312790 01	0.54234310 00	0.1904150 01	0.132790 01	0.5403460 00	0.4009640 00	0.8479600 03			
MCR3	NCR2	MC/A3	PRSA	PRSA	PRCA	PRCA					
0.251850 01	0.5201570 05	0.3134600 02	0.1930480 01	0.1288270 01	0.177680 00	0.1930480 01	0.1288270 01	0.7151320 00			
PU1A	TD3A	PM13	PS13	AREA3	AREA3	CP	GAMMA				
0.2126040 02	0.1097070 03	0.4260240 00	0.5045460 00	0.1166160 02	0.1166160 02	0.241910 00	0.1396110 01				

TABLE V - Continued

***** M070R 2*****											
STRM	PU1R	PD2R	IDIR	7D2R	PS2	2R	PERL2	R2	R3	R4	R5
1	J-3331720 02	0.3234010 02	0.776935D 03	0.7922230 03	0.2534720 02	0.2342740 00	0.1500000-01	0.209450 01	0.7718510 00	0.7718510 00	0.7718510 00
2	0.3552020 02	0.3811870 02	0.7911860 03	0.8045170 03	0.2593110 02	0.2448550 00	0.1956480 00	0.2213270 01	0.137310 00	0.137310 00	0.137310 00
3	0.3771750 02	0.3629200 02	0.8100860 03	0.8207120 03	0.2646470 02	0.2622220 00	0.3664840 00	0.2320890 01	0.0532670 00	0.0532670 00	0.0532670 00
4	0.3841180 02	0.3585950 02	0.829310 03	0.8374980 03	0.2697620 02	0.2648110 00	0.5308660 00	0.2424330 01	0.8912990 00	0.8912990 00	0.8912990 00
5	0.3946920 02	0.3239310 02	0.855815D 03	0.8613580 02	0.2247390 02	0.2594910 00	0.6481620 00	0.2523540 01	0.9277130 00	0.9277130 00	0.9277130 00
6	0.413290 02	C-3600810 02	0.8954370 03	0.8983610 03	0.2792340 02	0.2487440 00	0.8387860 00	0.2618440 01	0.9626500 00	0.9626500 00	0.9626500 00
7	0.4340580 02	0.3920983 02	0.9262260 03	0.9265150 03	0.2829720 02	0.3348790 00	0.9850000 00	0.2710550 01	0.9965260 00	0.9965260 00	0.9965260 00
STRM 81											
1	0.6016200 02	0.3013040 02	0.3031600 02	0.6631960 01	0.2190400 01	0.2363330 00	0.4524430 00	0.176760 01	0.0 0	0.0 0	0.0 0
2	0.6220870 02	0.2860770 02	0.3360000 02	0.6398600 01	0.2274770 01	0.4859390 02	0.4300960 00	0.186690 00	0.676010 00	0.676010 00	0.676010 00
3	0.6463730 02	0.2569320 02	0.3874400 02	0.670620 01	0.2165450 01	0.5351340 00	0.4182220 00	0.2019090 01	0.4270340 00	0.4270340 00	0.4270340 00
4	0.6759240 02	0.2274870 02	0.4484360 02	0.8220450 01	0.2063860 01	0.5971010 00	0.4117760 00	0.206050 01	0.3522660 00	0.3522660 00	0.3522660 00
5	0.6944820 02	0.1834470 02	0.3120550 02	0.8708510 01	0.1959580 01	0.6528180 00	0.4128870 00	0.202080 01	0.553020 00	0.553020 00	0.553020 00
6	0.6915300 02	0.1614350 02	0.5360940 02	0.7557740 01	0.1863180 01	0.6181920 00	0.4036670 00	0.221510 01	0.429680 00	0.429680 00	0.429680 00
7	0.6943470 02	0.8675370 01	0.6115530 02	0.646471n 01	0.1769600 01	0.5993360 00	0.3866990 00	0.2169800 01	0.4090610 00	0.4090610 00	0.4090610 00
STRM 81*											
1	0.5313030 02	0.2379000 02	0.2954000 02	0.4915990 00	0.0 0	EPS2	R2	R2	F-AXIAL	R-STRESS	
2	0.5583010 02	0.2644280 02	0.354033D 02	-1.8636350 01	0.0 0	0.1000000 01	0.0 0	0.0 0	0.0 0	0.0 0	
3	0.5764660 02	0.1757250 02	0.4007380 02	-1.329740 01	0.0 0	0.1000000 01	-1.1311880 02	-1.1311880 02	0.2081430 01	0.2081430 01	
4	0.5922140 02	0.1527790 02	0.4404640 02	0.7986130 00	0.0 0	0.1000000 01	-1.132020 02	-1.132020 02	0.209170 01	0.209170 01	
5	0.6088970 02	0.1139460 02	0.4744460 02	0.3758940 01	0.0 0	0.1000000 01	-1.1318140 02	-1.1318140 02	0.329420 01	0.329420 01	
6	0.6219320 02	0.1184530 02	0.3034790 02	0.3261520 01	0.0 0	0.1000000 01	-1.1319470 02	-1.1319470 02	0.244210 01	0.244210 01	
7	0.6343000 02	0.1058000 02	0.5285000 02	0.83093340 01	0.0 0	0.1000000 01	-1.059870 02	-1.059870 02	0.255330 01	0.255330 01	
STRM M1*											
1	0.9441850 0J	M2R	W1R	M2W	CR2	WU2	CM2	CR2	02	0.1120140 04	
2	0.9911870 00	0.6021100 00	0.1188140 03	0.8016160 03	0.6939970 03	0.4011970 03	0.6939970 03	0.0 0	0.1120140 04	0.1120140 04	
3	0.1018080 01	0.5683170 00	0.1313650 04	0.7793180 03	0.6606520 03	0.4389330 03	0.6606520 03	0.0 0	0.118080 04	0.118080 04	
4	0.1063200 01	0.5672810 00	0.1357140 04	0.7726460 03	0.6826250 03	0.4835340 03	0.6826250 03	0.0 0	0.123860 04	0.123860 04	
5	0.1055220 01	0.4914900 00	0.1410590 04	0.6897910 03	0.5156110 03	0.5128840 03	0.5156110 03	0.0 0	0.1293710 04	0.1293710 04	
6	0.1265000 01	0.53889310 00	0.1475760 04	0.76269120 03	0.4561185D 03	0.6189070 03	0.4561185D 03	0.0 0	0.1346650 04	0.1346650 04	
7	0.1163130 01	0.56833420 00	0.1539450 04	0.8220990 03	0.3960250 03	0.7191980 03	0.3960250 03	0.0 0	0.1397290 04	0.1397290 04	
STRM PRS											
1	0.166683C 01	TR5	EFFS	PRC	7RC	EFFC	MX2	MX2	LX2/CX1		
2	0.1712720 01	0.1211630 01	0.778966 00	0.33846460 01	0.1500490 01	0.9152320 00	0.5212760 00	0.173510 01			
3	0.1778420 01	-1.224320 01	-1.405190 01	0.362260 01	0.1521990 01	0.9420090 00	0.4920090 00	0.112830 01			
4	0.1744720 01	0.1240630 01	0.713810 00	0.3331530 01	0.1548350 01	0.7480380 00	0.4622580 00	0.106310 01			
5	0.1763310 01	0.1255110 01	0.6923170 00	0.3321380 01	0.1626950 01	0.7001710 00	0.3738610 00	0.9862240 00			
6	0.1722310 01	0.12460010 01	0.7012590 00	0.3316790 01	0.1672930 01	0.6466640 00	0.3059460 00	0.8768580 00			
7	0.16855240 01	0.1232930 01	0.681383D 00	0.3208950 01	0.1649560 01	0.601480 00	0.3191440 00	0.8332320 00	0.7462420 00		
WCR2											
0.1624370 01	0.4733050 05	MG/A2	PMSA	7RSA	EFFSA	PRCA	TRCA	EFFCA			
0.16630140 02	0.46658130 03	PH12	PS12	AREA2	AREE2	MPS	MPC	0.1579900 01	0.0 0.03030 00		
J-2416910 00	0.1196110 01	GAMMA		0.9519970 01	0.9234370 01	0.1720380 03	0.3423950 03				

TABLE V - Continued

••••• STATOR •••••											
STRM	PR1A	PU1A	PU2A	PU3A	PS1A	PS2A	PS3A	PS4A	PS5A	PS6A	A3
1	0.3494210 22	0.3529250 02	0.8222660 01	0.3141040 02	0.1341040 00	0.4184040 00	0.4184040 01	0.1500000D-01	0.2181170 01	0.0026300 00	P/R3
2	0.3494250 02	0.3494250 02	0.8222660 02	0.3141040 02	0.2058070 00	0.6243200 00	0.6243200 01	0.1922300 00	0.2280000 00	0.832300 00	
3	0.3494250 03	0.3494250 03	0.8446490 03	0.3141040 03	0.2071630 00	0.5910100 01	0.5910100 01	0.1620200 00	0.2312300 01	0.8721800 00	
4	0.3669010 02	0.3707000 02	0.8661660 02	0.3141040 02	0.2071630 00	0.5910100 01	0.5910100 01	0.1620200 00	0.2312300 01	0.8721800 00	
5	0.3657140 02	0.3657140 02	0.8492280 02	0.3141040 02	0.211640 00	0.5241140 00	0.5241140 00	0.1620200 00	0.2312300 01	0.8721800 00	
6	0.3652750 02	0.3652750 02	0.8103660 02	0.3141040 02	0.1654010 00	0.4526176 01	0.4526176 01	0.1620200 00	0.2312300 01	0.8721800 00	
7	0.3534010 02	0.3400100 02	0.9275230 03	0.3141040 02	0.1898440 00	0.3798159 01	0.3898159 01	0.1620200 00	0.2312300 01	0.8721800 00	
STRM	AL2	ME7A	AL3	AL2	AL3	AL2	AL3	AL2	AL3	AL2	AL3
1	0.4601910 32	0.4601910 32	0.4601910 32	0.4601910 32	0.2203370 00	0.2203370 00	0.2203370 00	0.2203370 00	0.2203370 00	0.2203370 00	0.0000000 00
2	0.4322420 02	0.4322420 02	0.4322420 02	0.4322420 02	0.2116810 01	0.2203370 01	0.2116810 01	0.2203370 01	0.2203370 01	0.2203370 01	0.0000000 00
3	0.5140240 02	0.5140240 02	0.5140240 02	0.5140240 02	0.2116810 01	0.2116810 01	0.2116810 01	0.2116810 01	0.2116810 01	0.2116810 01	0.0000000 00
4	0.5554420 02	0.5554420 02	0.5554420 02	0.5554420 02	0.2116810 01	0.2116810 01	0.2116810 01	0.2116810 01	0.2116810 01	0.2116810 01	0.0000000 00
5	0.6188810 02	0.6188810 02	0.6188810 02	0.6188810 02	0.1925180 02	0.1957800 01	0.1957800 01	0.1957800 01	0.1957800 01	0.1957800 01	0.0000000 00
6	0.5962480 02	0.5962480 02	0.5962480 02	0.5962480 02	0.1925180 02	0.1957800 01	0.1957800 01	0.1957800 01	0.1957800 01	0.1957800 01	0.0000000 00
7	0.6143060 02	0.6143060 02	0.6143060 02	0.6143060 02	0.1903060 02	0.1807500 01	0.1807500 01	0.1807500 01	0.1807500 01	0.1807500 01	0.0000000 00
STRM	AL2e	ME7Ae	AL3e	AL2e	AL3e	AL2e	AL3e	AL2e	AL3e	AL2e	AL3e
1	0.4695000 02	0.4695000 02	0.4695000 02	0.4695000 02	0.0	0.0	0.0	0.0	0.0	0.0	F-TANG
2	0.4598720 02	0.4598720 02	0.4598720 02	0.4598720 02	0.0	0.0	0.0	0.0	0.0	0.0	R-STRESS
3	0.4512200 02	0.4512200 02	0.4512200 02	0.4512200 02	0.0	0.0	0.0	0.0	0.0	0.0	F-AXIAL
4	0.4534220 02	0.4534220 02	0.4534220 02	0.4534220 02	0.0	0.0	0.0	0.0	0.0	0.0	
5	0.4636900 02	0.4636900 02	0.4636900 02	0.4636900 02	0.0	0.0	0.0	0.0	0.0	0.0	
6	0.4995490 02	0.4995490 02	0.4995490 02	0.4995490 02	0.0	0.0	0.0	0.0	0.0	0.0	
7	0.4244000 02	0.4244000 02	0.4244000 02	0.4244000 02	0.0	0.0	0.0	0.0	0.0	0.0	
STRM	M2A	M3A	C2A	C3A	C4A	C5A	C6A	C7A	C8A	C9A	C10A
1	0.706760 00	0.4119780 00	0.9949030 03	0.5688000 03	0.5688000 03	0.5688000 03	0.5688000 03	0.5688000 03	0.5688000 03	0.5688000 03	0.5688000 03
2	0.7794520 00	0.3936030 00	0.9935850 03	0.5480900 03	0.5480900 03	0.5480900 03	0.5480900 03	0.5480900 03	0.5480900 03	0.5480900 03	0.5480900 03
3	0.705180 00	0.4811680 00	0.9859740 03	0.5453730 03	0.5453730 03	0.5453730 03	0.5453730 03	0.5453730 03	0.5453730 03	0.5453730 03	0.5453730 03
4	0.685120 30	C.1405050 00	0.9351690 03	0.5408950 03	0.5408950 03	0.5408950 03	0.5408950 03	0.5408950 03	0.5408950 03	0.5408950 03	0.5408950 03
5	0.6335520 00	0.3926280 00	0.9172460 03	0.5453110 03	0.5453110 03	0.5453110 03	0.5453110 03	0.5453110 03	0.5453110 03	0.5453110 03	0.5453110 03
6	0.6232320 00	0.4022200 00	0.9021560 03	0.5369030 03	0.5369030 03	0.5369030 03	0.5369030 03	0.5369030 03	0.5369030 03	0.5369030 03	0.5369030 03
7	0.532760 00	0.3389690 00	0.8291180 03	0.4996630 03	0.4996630 03	0.4996630 03	0.4996630 03	0.4996630 03	0.4996630 03	0.4996630 03	0.4996630 03
STRM	PRS	TAS	EFFS	PAC	PAC	EFFC	EFFC	EFFC	EFFC	EFFC	CU2
1	0.1616310 01	0.1194460 01	0.7959200 00	0.3204420 01	0.1500490 01	0.7812290 00	0.41191490 00	0.7191490 00	0.7191490 00	0.7191490 00	
2	0.105910 01	0.1211630 01	0.6789090 00	0.3172700 01	0.1521990 01	0.7415470 00	0.3936030 00	0.7421250 00	0.7421250 00	0.7421250 00	
3	0.1017230 01	C.1224220 01	0.6514390 00	0.3163590 01	0.1543350 01	0.7038400 00	0.3861440 00	0.754950 00	0.754950 00	0.754950 00	
4	0.1020420 01	0.1240550 01	0.6376190 00	0.3151450 01	0.1586990 01	0.6421590 00	0.3860650 00	0.7609430 00	0.7609430 00	0.7609430 00	
5	0.1081410 01	0.155110 01	0.6228460 00	0.3171050 01	0.1626950 01	0.6170790 00	0.3926200 00	0.4059420 00	0.4059420 00	0.4059420 00	
6	0.1084040 01	0.1246010 01	0.6478200 00	0.3187560 01	0.1672930 01	0.5279560 00	0.4022280 00	0.7783200 00	0.7783200 00	0.7783200 00	
7	0.10221480 01	0.1232930 01	0.6310050 00	0.3087530 01	0.1692560 01	0.5425320 00	0.3389630 00	0.7272250 00	0.7272250 00	0.7272250 00	
STRM	MC2	MC3	PR1A	PR2A	PR3A	EFFC	EFFC	EFFC	EFFC	EFFC	CU2
0.1116160 01	0.4710860 05	0.2922040 02	0.1641270 01	0.1234020 01	0.6449790 00	0.3168440 01	0.158740 01	0.6554650 00	0.6554650 00	0.6554650 00	
PU3A	T03A	PM13	PS13	AREA3	AREA3	CP	CP	GAMA	GAMA	GAMA	
0.34949410 02	0.07110100 03	0.4131320 00	0.4264430 00	0.9341060 01	0.8129630 01	0.2450520 00	0.1386560 01	0.1386560 01	0.1386560 01	0.1386560 01	

TABLE VI
COMPUTER OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - ORIGINAL DESIGN -
TEST NUMBER 21

***** INLET *****

STATION	PULS	T ₁₁	PS	T ₅	T ₆	AL1	EPSI	PEAL	R1	R/RAT
1	0.109900 02	0.516000 03	0.9364190 01	0.5269240 03	0.0	0.0	0.500000D-02	0.1346900 01	0.4951800 00	
2	0.109900 02	0.516000 03	0.9364190 01	0.5269240 03	0.0	0.0	0.2285730 00	0.1655430 01	0.4086140 00	
3	0.109900 02	0.516000 03	0.9364190 01	0.5269240 03	0.0	0.0	0.4155200 00	0.1913430 01	0.7034670 00	
4	0.109900 02	0.516000 03	0.9364190 01	0.5269240 03	0.0	0.0	0.5810510 00	0.2141890 01	0.7874450 00	
5	0.109900 02	0.516000 03	0.9364190 01	0.5269240 03	0.0	0.0	0.7305400 00	0.2398160 01	0.8632930 00	
6	0.109900 02	0.516000 03	0.9364190 01	0.5269240 03	0.0	0.0	0.8471300 00	0.2536450 01	0.9125920 00	
7	0.109900 02	0.516000 03	0.9364190 01	0.5269240 03	0.0	0.0	0.9950000 00	0.2713100 01	0.9714430 00	
STATION	CA1	CJ1	CRI	CM1	UI	CA1	CA1	MIA	PC	
1	0.5443300 01	0.0	0.0	0.5443300 03	0.7209850 03	0.5443300 03	0.4836900 00	0.0	0.1000000 01	
2	0.5443300 03	0.0	0.0	0.5443300 03	0.8861000 03	0.5443300 03	0.4836900 00	0.5227130 00	0.1000000 01	
3	0.5443300 01	0.0	0.0	0.5443300 03	0.1024240 04	0.5443300 03	0.4836900 00	0.5245530 00	0.1000000 01	
4	0.5443300 03	0.0	0.0	0.5443300 03	0.1146120 04	0.5443300 03	0.4836900 00	0.5227130 00	0.1000000 01	
5	0.5443300 03	0.0	0.0	0.5443300 03	0.1256950 04	0.5443300 03	0.4836900 00	0.5227130 00	0.1000000 01	
6	0.5443300 03	0.0	0.0	0.5443300 03	0.1357550 04	0.5443300 03	0.4836900 00	0.5245530 00	0.1000000 01	
7	0.5443300 03	0.0	0.0	0.5443300 03	0.1452300 04	0.5443300 03	0.4836900 00	0.5227130 00	0.1000000 01	
WC/AL	WC/AL	POA	POA	POA	POA	PHI	HUB/TIP	AREA	AREA	
J.435074U 01	0.5151H260 05	0.3565840 02	0.1099000 02	0.5516000 03	0.5009200 00	0.4926410 00	0.1760170 02	0.1742570 02		
CP	GAMA									
0.2304670 00	C.1400330 01									

TABLE VI - Continued

TABLE VI - Continued

***** ROTOR 1*****													
STHM	PULS	T01R			T02R			T03R			PERL2	R/R1	
		R12	R13	R14	R21	R22	R23	R31	R32	R33			
1	0.14314600	0.2	0.15179000	0.2	0.54949200	0.3	0.62425100	0.3	0.12111200	0.2	-0.22316660	0.0	
2	0.16263200	0.2	0.17076000	0.2	0.61613970	0.3	0.61303750	0.2	0.22406560	0.0	-0.10000000	0.1	
3	0.14161440	0.2	0.16169400	0.2	0.63993700	0.3	0.65472600	0.3	0.17000000	0.2	0.249370	0.0	
4	0.21024000	0.2	0.18123000	0.2	0.67556400	0.3	0.68318100	0.3	0.14467510	0.2	0.309630	0.0	
5	0.23273000	0.2	0.19023000	0.2	0.68318100	0.3	0.69270300	0.3	0.14675100	0.2	0.3863760	0.0	
6	0.25947100	0.2	0.18525400	0.2	0.70515400	0.3	0.70973800	0.3	0.15119100	0.2	0.499370	0.0	
7	0.26905500	0.2	0.16611100	0.2	0.72725900	0.3	0.72687700	0.3	0.15569000	0.2	0.52456600	0.0	
STHM	B1	R2	T01EA	R21	D81	S80	D82	F80	D83	DEQIV	OP/QR	DM 2	
1	0.15294710	0.2	0.48893800	0.2	0.40595060	0.1	0.84578800	0.1	0.23940000	0.1	0.33351500	0.0	
2	0.56433440	0.2	0.39286000	0.2	0.19123200	0.2	0.81646970	0.1	0.22752200	0.1	0.4076430	0.0	
3	0.62111000	0.2	0.32210000	0.2	0.24970500	0.2	0.78473700	0.1	0.21680500	0.1	0.49980100	0.0	
4	0.68630100	0.2	0.18849700	0.2	0.34637500	0.2	0.75848400	0.1	0.20685100	0.1	0.42866100	0.0	
5	0.68849700	0.2	0.18849700	0.2	0.47735200	0.2	0.73253500	0.1	0.56378500	0.0	0.38096000	0.0	
6	1.61555700	0.2	0.20530100	0.1	0.58992000	0.2	0.71095000	0.1	0.18887000	0.1	0.20940000	0.1	
7	1.64953700	0.2	0.16970900	0.1	0.7111680	0.2	0.69337400	0.1	0.18060000	0.1	0.238420	0.0	
STHM	B1*	R2*	T01EA*	R21*	D81	S80	D82	F80	D83	AC2	F-TANG	F-AXIAL	
1	0.44440000	0.2	0.55159400	0.1	-0.51159400	0.1	0.0	0.0	0.0	0.0	0.0	R-STRESS	
2	0.50271400	0.2	0.27843000	0.2	0.22460900	0.2	-0.32088900	0.1	0.10000000	0.1	-1.1717520	0.2	
3	0.541640	0.2	0.21650000	0.2	0.32513600	0.2	-0.2722400	0.1	0.10000000	0.1	-1.1564080	0.2	
4	0.170330	0.2	0.170330	0.2	0.40000130	0.2	-0.3687970	0.0	0.10000000	0.1	-1.407140	0.2	
5	0.5925930	0.2	0.13571900	0.2	0.45658700	0.2	0.20173600	0.1	0.10000000	0.1	-1.211180	0.2	
6	0.61045600	0.2	0.089600	0.2	0.501910	0.2	0.80009400	0.1	0.10000000	0.1	-0.9755450	0.1	
7	0.62330000	0.2	0.07800000	0.1	0.51750000	0.2	0.17400800	0.2	0.10000000	0.1	-1.257720	0.2	
STHM	M14	M26	WIR	M21	C12	M22	WU2	C12	M22	CR2	CR2	0.2	
1	0.07045740	0.0	0.02717400	0.0	0.90339100	0.3	0.74026600	0.3	0.7384140	0.3	0.7323510	0.2	
2	0.92613100	0.0	0.03232000	0.0	0.61303970	0.4	0.76463900	0.3	0.145710	0.3	0.2481690	0.3	
3	0.10107000	0.0	0.64777400	0.0	0.11159000	0.3	0.7886300	0.3	0.1792070	0.3	0.6792070	0.3	
4	0.11278000	0.0	0.64543400	0.0	0.1269170	0.4	0.7901470	0.3	0.0805530	0.3	0.5040040	0.3	
5	0.12718100	0.0	0.62208000	0.0	0.1369750	0.4	0.7711820	0.3	0.1866600	0.3	0.5707080	0.3	
6	0.12997500	0.0	0.25290000	0.0	0.14648800	0.4	0.66866700	0.3	0.2448550	0.3	0.3448550	0.3	
7	0.13182000	0.0	0.51064900	0.0	0.15059600	0.4	0.65198900	0.3	0.212580	0.3	0.212580	0.3	
STHM	PRS	TAS	PRC	PRF	7RC	EFFS	M22	M22	M22	EFFCA	EFFCA	0.2	
1	0.20273100	0.1	0.50317900	0.0	0.20273100	0.1	0.1049860	0.1	0.8971920	0.0	0.6261690	0.0	
2	0.19885700	0.1	0.12477500	0.1	0.8767860	0.0	0.19885700	0.1	0.247750	0.0	0.59818610	0.1	
3	0.14559400	0.1	0.1254350	0.1	0.8381800	0.0	0.1965990	0.1	0.1254350	0.1	0.5621420	0.0	
4	0.11161600	0.1	0.1262790	0.1	0.7714540	0.0	0.1911620	0.1	0.1263790	0.1	0.4910780	0.0	
5	0.18475900	0.1	0.1287200	0.1	0.6932190	0.0	0.1887780	0.1	0.128720	0.1	0.6917640	0.0	
6	0.1899790	0.1	0.1335010	0.1	0.5956350	0.0	0.1889790	0.1	0.133501	0.0	0.5928460	0.0	
7	0.19342400	0.1	0.1362250	0.1	0.5959910	0.0	0.1903420	0.1	0.1362250	0.0	0.5959970	0.0	
STHM	MC2	MC2	PRSA	PRSA	7RSA	EFFSA	AREE2	AREE2	AREE2	PRCA	PRCA	0.2	
0.02286200	0.1	0.52748600	0.5	0.2641270	0.2	0.19438620	0.1	0.171620	0.1	0.1943820	0.1	0.171620	0.0
0.02136260	0.7	0.7014200	0.3	0.5315140	0.0	0.5869320	0.0	0.137850	0.2	0.1351010	0.2	0.1616940	0.3
L.P.	GAMMA	L.P.	GAMMA	GAMMA	MPS	MPS	HPC	HPC	HPC	EFFCA	EFFCA	0.2	

TABLE VI - Continued

***** STATOR *****									
STRN	P02A	P03A	T023A	PS3	TS	PD/PD	PEML3	R3	R/R/T
1	0.27728020	0.2	0.2103460	0.02	0.6687620	0.03	0.4381960-01	0.1932000	0.7102940 00
2	0.2185660	0.02	0.2142140	0.02	0.6682600	0.03	0.4495960-01	0.2026200	0.761311D 00
3	0.2160820	0.02	0.2117410	0.02	0.6916890	0.03	0.2050000-01	0.2081800	0.741644D 00
4	0.2100810	0.02	0.2038450	0.02	0.6971010	0.03	0.546620-02	0.375911D 00	0.816444D 00
5	0.2074450	0.02	0.2029270	0.02	0.7007110	0.03	0.1825560	0.02	0.2220730
6	0.2076880	0.02	0.2053460	0.02	0.7164D0	0.03	0.1825560	0.02	0.5467470 00
7	0.2091860	0.02	0.205020	0.02	0.7616840	0.03	0.1825560	0.02	0.7594600
8	0.2091860	0.02	0.205020	0.02	0.7616840	0.03	0.1825560	0.02	0.9538980 00
STRN	AL2	THETA	AL3	DAL2	SLO	DEFAULTS	DP/QS	DEQULV	DM3
1	0.5005320	0.02	0.5005320	0.02	0.0	0.1113240	0.00	0.5116910	0.0
2	0.478920	0.02	0.4787620	0.02	0.0	0.2288000	0.01	0.4011810	0.0
3	0.475960	0.02	0.479960	0.02	0.0	0.1123320	0.01	0.5944940	0.0
4	0.4963940	0.02	0.4965980	0.02	0.0	0.1899210	0.01	0.6347770	0.0
5	0.5964670	0.02	0.5664670	0.02	0.0	0.1867780	0.01	0.6417840	0.0
6	0.5668140	0.02	0.4903140	0.02	0.0	0.1055930	0.02	0.1743260	0.0
7	0.5668140	0.02	0.4903140	0.02	0.0	0.2366990	0.02	0.1625560	0.0
8	0.5668140	0.02	0.4903140	0.02	0.0	0.1625560	0.01	0.4984430	0.0
STRN	AL2*	THETA*	AL3*	OEV	EP3	AC3	F-TANG	F-AXIAL	R-STRESS
1	0.4994400	0.02	0.4994400	0.02	0.0	0.0	0.1000000	0.01	0.0
2	0.4901740	0.02	0.480140	0.02	0.0	0.0	0.1000000	0.01	0.1924600 01
3	0.4644720	0.02	0.4644720	0.02	0.0	0.0	0.1000000	0.01	0.209520 01
4	0.4517620	0.02	0.4517620	0.02	0.0	0.0	0.1000000	0.01	0.2278840
5	0.44004140	0.02	0.44004140	0.02	0.0	0.0	0.1000000	0.01	0.5362750 00
6	0.4314440	0.02	0.4314440	0.02	0.0	0.0	0.1000000	0.01	0.2384950 01
7	0.4232070	0.02	0.4232070	0.02	0.0	0.0	0.1000000	0.01	0.2519310 01
8	0.4232070	0.02	0.4232070	0.02	0.0	0.0	0.1000000	0.01	0.2656750 01
STRN	M2A	M3A	C2A	C3A	C4A	CU3	CM3	CR3	U3
1	0.4944400	0.02	0.5097790	0.00	0.1150040	0.04	0.6394680	0.03	0.104190 04
2	0.4918140	0.00	0.4905350	0.00	0.1065520	0.04	0.6046520	0.03	0.1114380 04
3	0.4936010	0.00	0.4855210	0.00	0.1033700	0.04	0.5898660	0.03	0.5806660
4	0.41211190	0.00	0.41211190	0.00	0.5968860	0.03	0.5282900	0.03	0.1188740 04
5	0.1208650	0.03	0.39144970	0.00	0.4162550	0.03	0.5043340	0.03	0.125130 04
6	0.1647660	0.00	0.3941640	0.00	0.41591210	0.03	0.5164410	0.03	0.125780 04
7	0.0934450	0.00	0.4074000	0.00	0.53487100	0.03	0.5387100	0.03	0.1388870 04
STRN	PHS	TR5	EFFS	PHC	REC	EFFC	MX3	CU2	
1	0.1946870	0.01	0.124750	0.01	0.8320340	0.00	0.1986770	0.01	0.8816700 03
2	0.1946870	0.01	0.124750	0.01	0.4454490	0.00	0.1949170	0.01	0.7901700 03
3	0.1926810	0.01	0.1254350	0.01	0.9107110	0.00	0.1926670	0.01	0.40265210
4	0.1873370	0.01	0.1263790	0.01	0.7518100	0.00	0.1873390	0.01	0.7417220 03
5	0.1849630	0.01	0.1282790	0.01	0.6691810	0.00	0.1849830	0.01	0.4151210
6	0.1851990	0.01	0.1335030	0.01	0.5150160	0.00	0.1851990	0.01	0.3919970
7	0.1865150	0.01	0.1362730	0.01	0.5378670	0.00	0.1862730	0.01	0.5359220
STRN	NCR2	NC/A	PSA	PSA	PSA	PSA	PMCA	TRCA	EFFCA
1	0.5291930	0.05	0.3203340	0.02	0.1900080	0.01	0.1274180	0.01	0.7157140 00
2	0.5291930	0.02	0.7054130	0.03	0.44343640	0.00	0.5692110	0.02	0.1166160
3	0.2044190	0.02	0.7054130	0.03	0.5692110	0.00	0.1131170	0.02	0.2416820

TABLE VI - Continued

***** RUTUR 2 *****											
ITEM	P61R	P62R	F614	F62R	P52	F62R	P52	R1	P61L2	R2	R/RAT
1	0.3341210 02	0.1139160 02	0.77763170 03	0.79314240 01	0.24740270 02	0.29714310 00	0.15050000 01	0.70133450 01	0.7118510 00	0.2213270 01	0.6137030 00
2	0.3405550 02	0.12446190 02	0.71715830 03	0.60515360 03	0.25419460 02	0.27712800 00	0.19536850 00	0.2213270 01	0.7118510 00	0.2213270 01	0.6137030 00
3	0.3669070 02	0.32192760 02	0.4203590 03	0.4203590 03	0.25419460 02	0.27712800 00	0.19536850 00	0.2213270 01	0.7118510 00	0.2213270 01	0.6137030 00
4	0.3777610 02	0.12555910 02	0.6173010 03	0.6173010 03	0.24740270 02	0.35420300 00	0.51061600 00	0.24243310 01	0.8912990 00	0.24243310 01	0.8912990 00
5	0.3916310 02	0.12266920 02	0.4566573 03	0.46119230 03	0.2676340 02	0.33420300 00	0.6681620 00	0.2523540 01	0.8912990 00	0.2523540 01	0.8912990 00
6	0.405910 02	0.1461010 02	0.6999470 03	0.6999470 03	0.2676340 02	0.26920200 00	0.6681620 00	0.2523540 01	0.8912990 00	0.2523540 01	0.8912990 00
7	0.422910 02	0.3570110 02	0.9266830 03	0.9270100 03	0.2743700 02	0.2666960 00	0.9851000 00	0.2666960 01	0.9851000 01	0.2666960 01	0.9851000 01
ITEM	M1	M1	M2	M2	M1	M2	M1	M2	M1	M2	M1
1	0.5427020 02	0.2609040 02	0.3217990 02	0.3217990 02	0.5427020 01	0.23940200 01	0.43174200 00	0.43174200 01	0.180880 01	0.180880 01	0.0
2	0.6151610 02	0.2514620 02	0.2273860 02	0.4109490 02	0.6156460 01	0.2164450 01	0.5036270 00	0.4728310 00	0.180880 01	0.180880 01	0.0
3	0.6363160 02	0.2061860 02	0.62061860 02	0.62061860 02	0.7916780 01	0.2060361 01	0.5611200 03	0.4322020 00	0.180880 01	0.180880 01	0.0
4	0.6723860 02	0.501970 02	0.1615990 02	0.501970 02	0.7916780 01	0.2060361 01	0.5611200 03	0.4322020 00	0.180880 01	0.180880 01	0.0
5	0.6917070 02	0.1615990 02	0.6917070 02	0.6917070 02	0.7916780 01	0.2060361 01	0.5611200 03	0.4322020 00	0.180880 01	0.180880 01	0.0
6	0.6960270 02	0.1448890 02	0.5511290 02	0.7409500 01	0.1463140 01	0.5695500 00	0.3965310 00	0.2033460 01	0.180880 01	0.180880 01	0.0
7	0.6961120 02	C.9504180 01	0.6010500 02	0.6113230 01	0.1769600 01	0.5614510 00	0.3759250 00	0.2170550 01	0.180880 01	0.180880 01	0.0
ITEM	M1*	M1*	M1*								
1	0.5113000 02	D.2379000 02	0.2394400 02	0.2394400 02	0.2631460 01	0.3	E.P52	RC2	F-TANG	F-AXIAL	R-STRESS
2	0.5556510 02	0.2044280 02	0.1540710 02	0.1540710 02	0.967410 00	0.0	P61R	0.1000000 01	-0.43174200 02	-0.180880 02	D.O.
3	0.5764660 02	0.1751280 02	0.15227790 02	0.44016400 02	0.2021070 01	0.0	P62R	0.1000000 01	-0.43174200 02	-0.180880 02	D.2081630 01
4	0.592190 02	0.1643510 02	0.3119210 02	0.4764460 02	0.257900 01	0.0	P52	0.1000000 01	-0.43174200 02	-0.180880 02	D.2209170 01
5	0.603970 02	0.3119210 02	0.603970 02	0.4764460 02	0.5571190 01	0.0	P61R	0.1000000 01	-0.43174200 02	-0.180880 02	D.2293540 01
6	0.6219320 02	0.1643510 02	0.6219320 02	0.4764460 02	0.5571190 01	0.0	P62R	0.1000000 01	-0.43174200 02	-0.180880 02	D.2444210 01
7	0.6343000 02	0.1058900 02	D.5245000 02	D.7255000 02	0.7255000 01	0.0	P52	0.1000000 01	-0.43174200 02	-0.180880 02	D.2553330 01
ITEM	M1R	M1R	M2R	M2R	M1R	M2R	CX2	CM2	CM2	CM2	CM2
1	0.96931210 00	0.14856290 00	0.1715920 00	0.1715920 00	0.1615180 01	0.41615180 01	0.41615180 01	0.6615180 01	0.6615180 01	0.11220 01	0.11220 01
2	0.1004310 01	0.6022240 00	0.1201920 01	0.1201920 01	0.1214780 01	0.6506020 01	0.4791410 01	0.6506020 01	0.6506020 01	0.1184750 01	0.1184750 01
3	0.1049850 01	0.5971220 00	0.1324480 01	0.4091110 01	0.60917641 01	0.5319380 01	0.5590720 01	0.5284280 01	0.5284280 01	0.1242550 01	0.1242550 01
4	0.1072950 01	0.5559053 00	0.1365440 01	0.7491610 01	0.5242460 01	0.4055090 01	0.6940960 01	0.326670 00	0.326670 00	0.9992110 00	0.1297730 01
5	0.1102400 01	0.3420870 00	0.1418490 01	0.7573910 01	0.4555190 01	0.4693040 01	0.4876080 01	0.4477060 01	0.4477060 01	0.1350830 01	0.1406330 01
6	0.1131000 01	0.60309280 00	0.1461780 01	0.5522510 01	0.4522510 01	0.4693040 01	0.4876080 01	0.4477060 01	0.4477060 01	0.1406330 01	0.1406330 01
7	0.1169490 01	D.6258620 00	0.15466443 01	0.4993520 01	0.447630 01	0.447630 01	0.447630 01	0.447630 01	0.447630 01	0.1450940 01	0.1450940 01
ITEM	PRS	PRS	TRS	TRS	PRS	TRS	PRS	EFFC	EFFC	EFFC	EFFC
1	0.1616100 01	0.119130 01	0.7627190 00	0.1214780 01	0.1481190 01	0.4162550 00	0.4162550 01	0.4956650 00	0.4956650 01	0.1044880 01	0.1044880 01
2	0.1667100 01	0.1201920 01	0.7734440 01	0.1250600 01	0.1493700 01	0.47942190 00	0.47942190 01	0.48486560 00	0.48486560 01	0.1059900 01	0.1059900 01
3	0.1681160 01	0.1212180 01	0.7494850 01	0.1239010 01	0.1520500 01	0.7597620 00	0.4500400 00	0.4500400 00	0.4500400 01	0.1044000 01	0.1044000 01
4	0.1713410 01	D.1228140 01	0.7216850 01	0.3209410 01	0.15981230 01	0.7088110 00	0.3843280 00	0.3843280 00	0.3843280 01	0.9992110 00	0.9992110 00
5	0.1712660 01	D.1236100 01	0.6955490 00	0.3168110 01	0.15981230 01	0.6540960 00	0.326670 00	0.326670 00	0.326670 00	0.9992220 00	0.9992220 00
6	0.1702820 01	D.1222620 01	0.7323050 00	0.315320 01	0.1622250 01	0.6088110 00	0.3437070 00	0.3437070 00	0.3437070 01	0.9411690 00	0.9411690 00
7	0.1658030 01	0.1216160 01	0.7130730 00	0.3092810 01	0.165320 01	0.57400070 00	0.3119370 00	0.3119370 00	0.3119370 01	0.8913420 00	0.8913420 00
ITEM	MC/A2	MC/A2	PRSA	PRSA	TRSA	TRSA	PRCA	EFFCSA	EFFCSA	TRCA	EFFCA
0.169560 01	0.4772480 05	0.74584720 02	D.16864740 01	0.1214710 01	0.7442960 00	0.3202000 01	0.1553450 01	0.1553450 01	0.1553450 01	D.7057900 00	D.7057900 00
P02A	102A	P012	P512	A8E2	A8E2	MP5	MP5	MP5	MP5	CP	GAMMA
0.35521190 02	0.85686690 03	D.4218160 00	D.44211720 00	0.95119970 01	0.9234370 01	0.1636120 03	0.39301510 03	0.39301510 03	0.39301510 03		

TABLE VI - Continued

***** STATION *****											
STATION	P01A	P01A	T021A	P53	T5	OPD/P0	P01L3	R3	R/R/T		
1	0.3513140 02	0.3513140 02	0.3508440 03	0.2975920 02	0.1693310 00	0.5189590-01	0.1500000-01	0.21183170 01	0.8026380 00		
2	0.3572470 02	0.3572470 02	0.3572330 03	0.2975920 02	0.2007250 00	0.5189590-01	0.1926430 00	0.2240000 01	0.8182360 00		
3	0.3572470 02	0.3572470 02	0.3572330 02	0.2975920 02	0.2007250 00	0.5189590-01	0.1926430 00	0.2240000 01	0.8182360 00		
4	0.3572630 02	0.3572630 02	0.3565650 03	0.2975920 02	0.1601960 00	0.4566660-00	0.5261140 00	0.2661730 01	0.9050480 00		
5	0.3572770 02	0.3572770 02	0.3577220 03	0.2975920 02	0.1877070 00	0.4342200-01	0.6463940 00	0.2447900 01	0.936730 00		
6	0.3572810 02	0.3572810 02	0.3503460 03	0.2975920 02	0.2032460 00	0.4418200-01	0.8365860 00	0.2610490 01	0.9672570 00		
7	0.3572920 02	0.3572920 02	0.9141660 03	0.2975920 02	0.2330260 00	0.4492900-01	0.9850000 00	0.2711820 01	0.9469940 00		
STATION	AL2*	AL2*	AL1A	AL2	AL2	OFACIS	OP/US	OEQUIV	OM1		
1	0.4692630 02	0.4692630 02	0.4692630 02	0.2366250-01	0.2292500 01	0.5636260 00	0.4651270 00	0.2103000 01	0.0		
2	0.4732250 02	0.4732250 02	0.4732250 02	0.4732250 02	0.223670 01	0.5562310 00	0.4210980 00	0.5541360 00			
3	0.4736190 02	0.4736190 02	0.4935460 02	0.4935460 02	0.2118960 01	0.5508940 00	0.3986580 00	0.2009440 01	0.5492180 00		
4	0.5454260 02	0.5454260 02	0.5454260 02	0.5454260 02	0.2036940 02	0.5422250 00	0.382370 00	0.1919190 01	0.5508020 00		
5	0.5454170 02	0.5454170 02	0.5454170 02	0.5454170 02	0.1957800 01	0.5467920 00	0.3719150 00	0.1903650 01	0.5297320 00		
6	0.5527450 02	0.5527450 02	0.5527450 02	0.5527450 02	0.1223320 02	0.5501140 00	0.3491200 00	0.1903550 01	0.5011200 00		
7	0.5631490 02	0.5631490 02	0.5631490 02	0.5631490 02	0.1007500 01	0.5627250 00	0.3545710 00	0.1884230 01	0.4701220 00		
STATION	AL2*	AL2*	AL1A	AL2	REV	EPS3	RC3	F-ANG	F-AXIAL		
1	0.4670700 02	0.4670700 02	0.4670700 02	0.4670700 02	0.0	0.0	0.0	0.0	0.0		
2	0.4750720 02	0.4750720 02	0.4750720 02	0.4750720 02	0.0	0.0	0.1000000 01	0.1216960 02	-0.5115140 01	0.0	
3	0.4712260 02	0.4712260 02	0.4712260 02	0.4712260 02	0.0	0.0	0.1000000 01	0.1204680 02	-0.4980450 01	0.2249620 01	
4	0.4835620 02	0.4835620 02	0.4835620 02	0.4835620 02	0.0	0.0	0.1000000 01	0.1204680 02	-0.4980450 01	0.2249620 01	
5	0.4357690 02	0.4357690 02	0.4357690 02	0.4357690 02	0.0	0.0	0.1000000 01	0.122270 02	-0.622390 01	0.2489400 01	
6	0.4229540 02	0.4229540 02	0.4229540 02	0.4229540 02	0.0	0.0	0.1000000 01	0.1116800 02	-0.5613910 01	0.2580230 01	
7	0.4249300 02	0.4249300 02	0.4249300 02	0.4249300 02	0.0	0.0	0.1000000 01	0.100040 02	-0.4705570 01	0.2667940 01	
STATION	AL2*	AL2*	AL1A	C7A	C3A	CG3	CU3	CM3	CR3		
1	0.4670700 20	0.4670700 20	0.4670700 20	0.3646350 03	0.3770080 03	0.5770003 03	0.0	0.5770080 03	0.0	0.116640 04	
2	0.4750720 02	0.4750720 02	0.4750720 02	0.4750720 03	0.5800150 03	0.5600150 03	0.0	0.5600150 03	0.0	0.1220470 04	
3	0.4712260 02	0.4712260 02	0.4712260 02	0.4712260 03	0.5881510 03	0.5681510 03	0.0	0.5881510 03	0.0	0.1269890 04	
4	0.4835620 02	0.4835620 02	0.4835620 02	0.4835620 03	0.5900940 03	0.5690940 03	0.0	0.5900940 03	0.0	0.1317750 04	
5	0.4357690 02	0.4357690 02	0.4357690 02	0.4357690 03	0.5778210 03	0.5778210 03	0.0	0.5778210 03	0.0	0.1363920 04	
6	0.4229540 02	0.4229540 02	0.4229540 02	0.4229540 03	0.5712700 03	0.5712700 03	0.0	0.5712700 03	0.0	0.1408820 04	
7	0.4249300 02	0.4249300 02	0.4249300 02	0.4249300 03	0.5191780 03	0.5191780 03	0.0	0.5191780 03	0.0	0.1451620 04	
STATION	AL2*	AL2*	AL1A	PPC	TRC	EFFC	MAB	CL12			
1	0.1513991 01	0.1513991 01	0.1513991 01	0.6741540 00	0.3051640 01	0.148180 01	0.7625740 00	0.4145490 03	0.2075630 03		
2	0.1511170 01	0.1511170 01	0.1511170 01	0.6733617 00	0.3062440 01	0.149700 01	0.7472550 00	0.4252650 03	0.2056060 03		
3	0.1510210 01	0.1510210 01	0.1510210 01	0.6610460 00	0.3059560 01	0.120500 01	0.7167810 03	0.4221380 03	0.2105160 03		
4	0.1615190 01	0.1615190 01	0.1615190 01	0.64247810 00	0.3061330 01	0.1552870 01	0.6755640 00	0.4206460 03	0.2386550 03		
5	0.1613910 01	0.1613910 01	0.1613910 01	0.6167910 00	0.3039560 01	0.1591230 01	0.6248330 00	0.4059360 03	0.2458250 03		
6	0.1623550 01	0.1623550 01	0.1623550 01	0.6057930 00	0.301260 01	0.162250 01	0.5808340 00	0.3989390 03	0.2032620 03		
7	0.1591540 01	0.1591540 01	0.1591540 01	0.64444810 00	0.2953860 01	0.1657300 01	0.5466090 00	0.3551400 03	0.2719200 03		
STATION	AL2*	AL2*	AL1A	PPC	TRSA	EFFSA	PRCA	PRCA	EFFCA		
1	0.17595640 01	0.17595640 01	0.17595640 01	0.37717170 02	0.1601090 01	0.1216660 01	0.6515450 00	0.15559490 01	0.6639750 00		
2	0.17595640 01	0.17595640 01	0.17595640 01	0.37717170 02	0.1601090 01	0.1216660 01	0.6515450 00	0.15559490 01	0.6639750 00		
3	0.17595640 01	0.17595640 01	0.17595640 01	0.37717170 02	0.1601090 01	0.1216660 01	0.6515450 00	0.15559490 01	0.6639750 00		
4	0.17595640 01	0.17595640 01	0.17595640 01	0.37717170 02	0.1601090 01	0.1216660 01	0.6515450 00	0.15559490 01	0.6639750 00		
5	0.17595640 01	0.17595640 01	0.17595640 01	0.37717170 02	0.1601090 01	0.1216660 01	0.6515450 00	0.15559490 01	0.6639750 00		
6	0.17595640 01	0.17595640 01	0.17595640 01	0.37717170 02	0.1601090 01	0.1216660 01	0.6515450 00	0.15559490 01	0.6639750 00		
7	0.17595640 01	0.17595640 01	0.17595640 01	0.37717170 02	0.1601090 01	0.1216660 01	0.6515450 00	0.15559490 01	0.6639750 00		

TABLE VII
COMPUTER OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - ORIGINAL DESIGN-
TEST NUMBER 22

***** INLET *****											
STAN	ρ ₀₁	P ₀₁	T ₀₁	ρ ₅	P ₅	T ₅	A ₁	ε _{P1}	PERL	R ₁	R/R ₁
1	0.1096900	0.02	0.1552000	0.03	0.937170	0.01	0.5271590	0.03	0.306000D-02	0.1346900	0.0
2	0.1096900	0.02	0.1552000	0.03	0.937170	0.01	0.5271590	0.03	0.22285730	0.1655430	0.0
3	0.1096900	0.02	0.1552000	0.03	0.937170	0.01	0.5271590	0.03	0.41553290	0.1913430	0.0
4	0.1096900	0.02	0.1552000	0.03	0.937170	0.01	0.5271590	0.03	0.5810210	0.2141630	0.0
5	0.1096900	0.02	0.1552000	0.03	0.937170	0.01	0.5271590	0.03	0.7474450	0.2744630	0.0
6	0.1096900	0.02	0.1552000	0.03	0.937170	0.01	0.5271590	0.03	0.2348160	0.08632930	0.0
7	0.1096900	0.02	0.1552000	0.03	0.937170	0.01	0.5271590	0.03	0.2346630	0.07325920	0.0
							0.0	0.0	0.2713100	0.0	0.9974450
STAN	C _{x1}	C _{y1}	C _{z1}	C _{x1}	C _{y1}	C _{z1}	U ₁	C ₁	M _{1A}	M ₁	R _C
1	0.5461480	0.0	0.0	0.0	0.5461480	0.03	0.7212210	0.03	0.5461480	0.03	0.1000000
2	0.5461480	0.0	0.0	0.0	0.5461480	0.03	0.8464280	0.03	0.5461480	0.03	0.1000000
3	0.5461480	0.0	0.0	0.0	0.5461480	0.03	0.1024580	0.04	0.5461480	0.03	0.1000000
4	0.5461480	0.0	0.0	0.0	0.5461480	0.03	0.1146890	0.04	0.5461480	0.03	0.1000000
5	0.5461480	0.0	0.0	0.0	0.5461480	0.03	0.1257260	0.04	0.5461480	0.03	0.1000000
6	0.5461480	0.0	0.0	0.0	0.5461480	0.03	0.1358290	0.04	0.5461480	0.03	0.1000000
7	0.5461480	0.0	0.0	0.0	0.5461480	0.03	0.1492780	0.04	0.5461480	0.03	0.1000000
	M _{ER1}	M _{ER1}	M _{ER1}	M _{C/A1}	P ₀₁	T ₀₁	P _{M1}	M ₀₁ /T _{IP}	AREA		
	3.4366470	0.01	0.1946040	0.03	0.1554010	0.02	0.1096900	0.02	0.5024370	0.0	0.1760170
	CP	GAMMA									0.1762570
	0.2398700	0.00	0.1400320	0.01							

TABLE VII - Continued

***** ROTOR *****											
SPIN	P01A	P02A	T01R	T02R	P52	ZR	P612	R2	R/R/T		
1	0.1428100 02	0.1553820 02	0.5953200 03	0.4244690 03	0.1205580 02	0.22769310 00	0.100000D-01	0.1744850 01	0.4614890 00		
2	0.1623170 02	0.17174390 02	0.4418650 02	0.1299210 03	0.1299210 02	0.2078700 00	0.1939760 01	0.7131470 00			
3	0.1814510 02	0.1811510 02	0.4394240 03	0.4588490 03	0.1366440 02	0.2259080 00	0.3865920 00	0.2115180 01	0.7778610 00		
4	0.2066250 02	0.1891510 02	0.6115450 03	0.6760350 03	0.1416180 02	0.2980120 00	0.9524770 00	0.2277910 01	0.8193980 00		
5	0.2318180 02	0.1896600 02	0.48366450 03	0.4931930 03	0.1460640 02	0.3801130 00	0.2431640 01	0.8939860 00			
6	0.2589610 02	0.1812450 02	0.7056520 03	0.7102600 03	0.1565710 02	0.5051880 00	0.8520270 01	0.2574250 01	0.9844140 00		
7	0.2864450 02	0.1854730 02	0.7277710 03	0.7277380 03	0.1549440 02	0.5232480 00	0.9900000 00	0.2710150 01	0.9437790 00		
STRM	B1	TWT7A	82	0.81	S10	0.04ACTR	0.04OP/QR	0.EQUIV	Dm2		
1	0.52766500 02	0.5030620 02	0.25586770 01	0.8374470 01	0.239600 01	0.3542000 00	0.5492310 00	0.1542450 01	0.0		
2	0.52041400 02	0.3466220 02	0.1990960 02	0.60927950 01	0.2275270 01	0.3501230 00	0.444460 01	0.6595550 00			
3	0.6194030 02	0.5216840 02	0.2977180 02	0.7775860 01	0.2166050 01	0.4472060 00	0.4781120 00	0.1770090 01	0.6598150 00		
4	0.6653620 02	0.2511360 02	0.3942220 02	0.7501860 01	0.2058510 01	0.4991840 00	0.4280010 00	0.1882260 01	0.4280020 00		
5	0.6652170 02	0.1471450 02	0.4707120 02	0.7262430 01	0.1975650 01	0.5310780 00	0.3805980 00	0.2092200 01	0.5555240 00		
6	0.68049370 02	0.8466630 01	0.5962910 02	0.1044910 01	0.1888780 01	0.6418920 00	0.3448260 00	0.2544120 01	0.3995690 00		
7	0.6939700 02	-0.100770 01	0.7004680 02	0.6967030 01	0.1808000 01	0.7216950 00	0.3155710 00	0.2612110 01	0.2587410 00		
STRM	B1*	TME1A	B2*	DEV	EPS2	RC2	F-TANG	F-AXIAL	R-STRESS		
1	0.4449000 02	0.4532000 02	0.9170000 01	-0.4611230 01	0.0	0.1000000 01	0.0	0.0	0.0		
2	0.5027390 02	0.2783000 02	0.2244090 02	-0.2931290 01	0.0	0.1900000 01	-0.1723510 02	-0.121530 02	0.1671740 01		
3	0.5216840 02	0.2168000 02	0.3211360 02	-0.2741790 01	0.0	0.1900000 01	-0.1256240 02	-0.171870 02	0.1906100 01		
4	0.5703470 02	0.1703130 02	0.40001130 02	-0.57791020 00	0.0	0.1900000 01	-0.1417360 02	-0.132890 02	0.212564 01		
5	0.5922530 02	0.11957150 02	0.4568780 02	0.2119410 01	0.0	0.1900000 01	-0.1245320 02	-0.130820 02	0.2300210 01		
6	0.6104490 02	0.1088600 02	0.5014910 02	0.9486020 01	0.0	0.1900000 01	-0.9530320 01	-0.1241810 02	0.242670 01		
7	0.5253030 02	0.8760000 01	0.53175000 02	0.1665480 02	0.0	0.1900000 01	-0.6565760 01	-0.1311660 02	0.2633540 01		
STRM	M1R	M2R	M1R	M2P	CR2	CM2	CR2	U2			
1	0.80317240 00	0.6131070 00	0.3046750 03	0.72744880 03	0.7231660 03	0.3234410 02	0.7237660 03	0.9343100 03			
2	0.921920 00	0.6437320 00	0.1017000 04	0.7241820 04	0.7241820 03	0.6425180 03	0.7241820 03	0.1038660 04			
3	0.10311300 01	0.65222100 00	0.1161050 04	0.7678860 03	0.66389940 03	0.3922240 03	0.6838940 03	0.1122930 04			
4	0.1128550 01	0.6566650 00	0.1270290 04	0.4028700 03	0.6202070 03	0.5098470 03	0.6202070 03	0.1220430 04			
5	0.1217890 01	0.821064 01	0.1318740 04	0.7723490 03	0.5187310 03	0.722250 03	0.5187310 03	0.1302060 04			
6	0.1300820 01	0.5222540 00	0.1461960 04	0.66446790 03	0.3366950 03	0.5734660 03	0.3366950 03	0.1378420 04			
7	0.1378860 01	0.51343030 00	0.1592040 04	0.6615910 03	0.22116800 03	0.6232760 03	0.22116800 03	0.1451200 04			
STRM	PAS	TR5	EFF5	PRC	TRC	EFFC	M2Z	C4Z/CX1			
1	0.298930 01	0.1254280 01	0.8822140 00	0.2029860 01	0.1254280 01	0.8790960 00	0.6174960 00	0.132220 01			
2	0.19346870 01	0.1245120 01	0.8558460 00	0.1988470 01	0.1245120 01	0.8827270 00	0.6067730 00	0.1325990 01			
3	0.1944810 01	0.1253540 01	0.4399730 00	0.1944810 01	0.1253540 01	0.8310180 00	0.5661240 00	0.1252210 01			
4	0.1913440 01	0.1261580 01	0.71789240 00	0.1913440 01	0.1261580 01	0.7719460 00	0.5071110 00	0.113560 01			
5	0.1943940 01	0.1286150 01	0.8902560 00	0.1890840 01	0.1286150 01	0.6718420 00	0.4171100 00	0.9497860 01			
6	0.1878900 01	0.1336810 01	0.5901110 00	0.1878900 01	0.1336810 01	0.5880420 00	0.2641510 00	0.6153260 00			
7	0.1900680 01	0.1362540 01	0.5558780 00	0.1900680 01	0.1362540 01	0.5559310 00	0.1721810 00	0.4062230 00			
NCR2	NCR2	WC/A2	PASA	TRSA	EFFSA	TRCA	EFFCA				
U.2556030 01	0.5276800 05	0.2659010 02	0.1941770 01	0.1270590 01	0.71719900 00	0.1941770 01	0.1270590 01	0.7092790 00			
PO2A	702A	PH12	PS12	AREA2	ANEE2	MP5	MP6				
0.2129940 02	0.7013680 03	0.5410980 00	0.5059510 00	0.1376590 02	0.1351010 02	0.1602050 03	0.16021210 03				
CP	GAMMA										
0.23988100 00	0.1400320 01										

TABLE VII - Continued

***** STATION 10000*****											
STATION	P01A	T023A	R53	LS	OPO/P0	P0AL3	R3	R/R/T			
1	0.7226590 02	0.7192050 02	0.6923660 02	0.1619650 02	0.4361530-01	0.1500000-01	0.1932000 01	0.7102940 00			
2	0.2191150 02	0.2131750 02	0.4973050 03	0.1619650 02	0.4966260-01	0.2026220 00	0.2018110 01	0.7653710 00			
3	0.2152220 02	0.2121100 02	0.6919630 03	0.1619650 02	0.541070-01	0.2000000-01	0.3759110 00	0.8164440 00			
4	0.2098690 02	0.2056870 02	0.6944460 02	0.1619650 02	0.6188920-01	0.2000000-01	0.540760 00	0.8647870 00			
5	0.2056950 02	0.2021830 02	0.7102860 03	0.1619650 02	0.6688970-01	0.2000000-01	0.6952270 00	0.9105670 00			
6	0.2060260 02	0.2019740 02	0.71668140 03	0.1619650 02	0.7410210-01	0.2000000-01	0.8433520 00	0.9538980 00			
7	0.2088860 02	0.2031660 02	0.7521220 03	0.1619650 02	0.7761730-01	0.2000000-01	0.9850000 00	0.9955860 00			
STATION	AL7	TMFTA	AL3	SLG	OFAC1	OFJS	OFQUIV	DM3			
1	0.5122530 02	0.425530 02	0.0	0.1315140 01	0.2268000 01	0.604590 00	0.6012470 00	0.2229480 01			
2	0.4720150 02	0.470150 02	0.0	0.159920 00	0.2138190 01	0.599750 00	0.599950 00	0.2273860 01			
3	0.4715230 02	0.4732210 02	0.0	0.4944050 00	0.199270 01	0.601350 00	0.594750 00	0.2179200 01			
4	0.4948510 02	0.488510 02	0.0	0.370970 01	0.1867780 01	0.6325620 00	0.590310 00	0.2222240 01			
5	0.5459690 02	0.5459680 02	0.0	0.1051540 02	0.1743260 01	0.616920 00	0.5958640 00	0.2266510 01			
6	0.6671010 02	0.6734010 02	0.0	0.2419580 02	0.1625400 01	0.6990550 00	0.5659260 00	0.2163280 01			
7	0.7499750 02	0.7499750 02	0.0	0.3267750 02	0.1512000 01	0.6663070 00	0.504364 00	0.1928380 01			
STATION	AL2*	MFTA	AL3*	OFV	EPS3	RC3	F-TANG	F-AXIAL			
1	0.4949000 02	0.4994000 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0			
2	0.4801740 02	0.4801740 02	0.0	0.0	0.0	0.1000000 01	0.1612690 02	0.1924600 01			
3	0.4644270 02	0.4642720 02	0.0	0.0	0.0	0.1000000 01	0.138740 02	0.1924600 01			
4	0.4517620 02	0.4517620 02	0.0	0.0	0.0	0.1000000 01	0.122390 02	0.2089320 01			
5	0.4400140 02	0.4408140 02	0.0	0.0	0.0	0.1000000 01	0.1094100 02	0.2241980 01			
6	0.4314460 02	0.4314460 02	0.0	0.0	0.0	0.1000000 01	0.1094020 02	0.2384950 01			
7	0.4232000 02	0.4232000 02	0.0	0.0	0.0	0.1000000 01	0.1186320 02	0.2646750 01			
STATION	M2A	M3A	C2A	CIA	CG3	CR3	CU3	U3			
1	0.9706610 00	0.5161520 00	0.1156450 04	0.64461490 03	0.64461490 03	0.64461490 03	0.64461490 03	0.1034520 04			
2	0.8930170 00	0.4652750 00	0.1365890 04	0.6095000 03	0.6095000 03	0.6095000 03	0.6095000 03	0.1114740 04			
3	0.8351480 00	0.4665030 00	0.1088860 04	0.4865010 03	0.4865010 03	0.4865010 03	0.4865010 03	0.1189130 04			
4	0.7710680 00	0.4227360 00	0.9331790 03	0.53867420 03	0.53867420 03	0.53867420 03	0.53867420 03	0.1259540 04			
5	0.7199300 00	0.3910610 00	0.9954020 03	0.5031990 03	0.5031990 03	0.5031990 03	0.5031990 03	0.1326210 04			
6	0.6854530 00	0.3891100 00	0.8722920 03	0.5101310 03	0.5101310 03	0.5101310 03	0.5101310 03	0.1389320 04			
7	0.6651490 00	0.4103650 00	0.4571360 03	0.54226610 03	0.54226610 03	0.54226610 03	0.54226610 03	0.1450040 04			
STATION	PAS	RA5	EFS	PNC	FAC	EFFFC	MA3	CU2			
1	0.1982490 01	0.1254280 01	0.8544860 00	0.1982490 01	0.154280 01	0.8513720 00	0.5161520 00	0.919660 03			
2	0.1943700 01	0.1255120 01	0.8572530 00	0.1943700 01	0.1255120 01	0.8541360 00	0.48575750 00	0.780920 03			
3	0.1925220 01	0.1253560 01	0.8122420 00	0.1925220 01	0.1253560 01	0.8094760 00	0.466030 00	0.7417080 03			
4	0.1979170 01	0.1261680 01	0.7524310 00	0.1879170 01	0.1261680 01	0.7497120 00	0.4222360 00	0.7165840 03			
5	0.1843220 01	0.1266750 01	0.6661960 00	0.1843220 01	0.1266750 01	0.6437960 00	0.391610 00	0.7298380 03			
6	0.1843220 01	0.1334810 01	0.2695130 00	0.1843220 01	0.1334810 01	0.2674590 00	0.3891100 00	0.8049580 03			
7	0.1862670 01	0.1362540 01	0.5367920 00	0.1862670 01	0.1362540 01	0.5348550 00	0.4103590 00	0.8229200 03			
STATION	MCA2	MC/A3	PASA	TRSA	EFFSA	PICA	TACA	EFFCA			
1	0.5261790 05	0.3213660 02	0.1897950 01	0.1277850 01	0.1277850 01	0.1277850 01	0.7206460 00				
2	0.2041430 02	0.7053760 03	0.4410920 00	0.5679520 00	0.1166160 02	0.1166160 02	0.1396130 01				

TABLE VII - Continued

***** MOTOR 2 *****											
STRM	PRUR	PO2R	TOLR	T02R	ZR	PS2	PERL2	R2	R/R1		
1 0.332297U 02	0.3163385U 02	0.781455D 03	0.79493D 03	D.242093D 02	D.274759D 00	D.150000D-01	0.205945D D1	0.771853D 00			
2 0.349133D 02	0.318075D 02	0.790756D 03	0.800176D 03	D.246703D 02	D.213063D 00	0.195668D 00	0.221327D 01	0.813703D 00			
3 0.365991U 02	0.321422D 02	0.809726D 03	0.820505D 03	D.250885D 02	D.337048D 00	0.366484D 00	0.232089D 01	0.853264D 00			
4 0.377651U 02	0.319272D 02	0.828561D 03	0.836130D 03	D.254853D 02	D.366198D 00	0.530646D 00	0.244333D 01	0.891299D 00			
5 0.385669U 02	0.322115D 02	0.856764D 03	0.862209D 03	D.258609D 02	D.368046D 00	0.681626D 00	0.252354D 01	0.927773D 00			
6 0.404815U 02	0.350068D 02	0.897567D 03	0.900511D 03	D.261745D 02	D.259992D 00	0.838786D 00	0.261844D 01	0.942660D 00			
7 0.422887U 02	0.366812D 02	0.927233D 03	0.927560D 03	D.26175D 02	D.261228D 00	0.985000D 00	0.271055D 01	0.948526D 00			
***** R-S T-S S *****											
STRM	BL	THETA	B2	081	SLO	DFACTR	DP/QR	DEQUIV	DR2	DR1	
1 0.5700820 02	0.2550150 02	0.3240610 02	0.455617U 01	D.239040D 01	D.412225D 00	0.397010 00	0.172671D 01	0.0	0.0		
2 0.613317D 02	0.231503D 02	0.381815D 02	0.548461D 01	D.227677D 01	D.457430D 00	0.387235D 00	0.182922D 01	0.443685D 00			
3 0.636532D 02	0.203199D 02	0.413334D 02	0.600559D 01	D.216545D 01	D.490275D 00	0.374519D 00	0.190697D 01	0.590083D 00			
4 0.669176U 02	0.181348D 02	0.486030D 02	0.759366D 01	D.206348D 01	D.501938D 00	0.372524D 00	0.201930D 01	0.527915D 00			
5 0.692142D 02	0.152167D 02	0.540034D 02	0.837851D 01	D.195958D 01	D.563613D 00	0.369244D 00	0.205949D 01	0.450560D 00			
6 0.694171D 02	0.151518D 02	0.554718D 02	0.764645D 01	D.184311D 01	D.486895D 00	0.361293D 00	0.186584D 01	0.464501D 00			
7 0.694823D 02	0.103723D 02	0.591106D 02	0.605227D 01	D.176980D 01	D.462961D 00	0.338414D 00	0.180153D 01	0.463355D 00			
***** F-A XIAL *****											
STRM	BL*	THETA	H2*	DEV	EPS2	RC2	F-TANG	F-AXIAL	R-STRESS	R-STRESS	
1 0.533300D 02	0.237900D 02	0.295400D 02	0.286670D 01	0.0	D.100000D 01	0.0	0.0	0.0	0.0	0.0	
2 0.558501D 02	0.206428D 02	0.254031D 02	0.27130D 01	0.0	D.100000D 01	-1.351100D 02	-1.11240D 02	-0.208130D 01	-0.208130D 01		
3 0.576666D 02	0.175292D 02	0.325958D 02	0.455980D 01	0.0	D.100000D 01	-1.48802D 02	-1.220910D 01	-0.232950D 01	-0.232950D 01		
4 0.592190U 02	0.152277D 02	0.440640D 02	0.458970D 01	0.0	D.100000D 01	-1.13510D 02	-1.10777D 02	-0.232950D 01	-0.232950D 01		
5 0.608397D 02	0.133951D 02	0.474446D 02	0.655688D 01	0.0	D.100000D 01	-9.89512D 01	-1.23170D 02	-0.24442D 01	-0.24442D 01		
6 0.621932D 02	0.118453D 02	0.533459D 02	0.437114D 01	0.0	D.100000D 01	-9.76080D 01	-1.31779D 01	-0.255333D 01	-0.255333D 01		
7 0.634300U 02	0.105800D 02	0.528500U 02	0.626000U 01	0.0	D.100000D 01	-9.29940D 01	-1.38464D 02	-0.265790D 01	-0.265790D 01		
***** M2R *****											
STRM	M1R	M2R	M1H	M2H	W2R	CX2	CW2	CR2	CR1	CR2	
1 0.971330U 00	0.611143D 00	0.122111D 00	0.83706690 03	D.709157D 03	D.450161D 03	0.709157D 03	0.0	0.0	0.112419D 04		
2 0.101174U 01	0.614422D 00	0.127009D 04	0.822844D 03	D.664598D 03	D.508464D 03	0.646598D 03	0.0	0.118513D 04			
3 0.105115D 01	0.606339D 00	0.132697D 04	0.820485D 03	D.567089D 03	D.563326D 03	0.597089D 03	0.0	0.124276D 04			
4 0.107694D 01	0.577387D 00	0.136915D 04	0.791840D 03	D.536939D 03	D.526220D 03	0.526220D 03	0.0	0.129815D 04			
5 0.110217D 01	0.569718D 00	0.141850D 04	0.793824D 03	D.466582D 03	D.662229D 03	0.466582D 03	0.0	0.135122D 04			
6 0.112249D 01	0.658931D 00	0.148002D 04	0.928825D 03	D.536476D 03	D.758220D 03	0.536476D 03	0.0	0.14020D 04			
7 0.117091D 01	0.70200000 00	0.1544826D 04	0.948858D 03	D.512856D 03	D.857260D 03	0.512856D 03	0.0	0.145141D 04			
***** PRS *****											
STRM	PRS	FMS	EFFF	PRC	TRC	EFFF	MX2	MX1	CX2/CX1	CR2	
1 0.1547700 01	0.1187189U 01	0.770270 00	0.315338D 01	D.148242D 01	D.799368D 00	0.532552D 00	0.109311D 01	0.109311D 01	0.112419D 04		
2 0.159423D 01	0.1174010 01	0.133451D 00	0.311446D 01	D.168665D 01	D.810170D 00	0.482892D 00	0.100887D 01	0.100887D 01	0.118513D 04		
3 0.160122D 01	0.120300D 01	0.105955D 00	0.308317D 01	D.150603D 01	D.740492D 00	0.441046D 00	0.101389D 01	0.101389D 01	0.124276D 04		
4 0.163089D 01	0.121840D 01	0.168165D 00	0.305022D 01	D.153723D 01	D.694364D 00	0.381811D 00	0.975485D 00	0.975485D 00	0.129815D 04		
5 0.164421D 01	0.122455D 01	0.67315D 00	0.3022715D 01	D.157567D 01	D.641002D 00	2.334860D 00	0.921046D 00	0.921046D 00	0.135122D 04		
6 0.164449D 01	0.120418D 01	0.742674D 00	0.302889D 01	D.160793D 01	D.605024D 00	0.380591D 00	0.103164D 01	0.103164D 01	0.14020D 04		
7 0.1544904D 01	0.119129D 01	0.734108D 00	0.295993D 01	D.162318D 01	D.578264D 00	0.360401D 00	0.945077D 00	0.945077D 00	0.145141D 04		
***** MCQ? *****											
0.1756191 01	C.477444HU 05	0.267156D 02	0.161715D 01	0.120444D 01	0.714736D 00	0.306663D 01	0.153910D 01	0.694390D 00	0.694390D 00	0.694390D 00	
0.336532D 02	0.R95813D 03	0.416421D 00	0.404019D 00	0.921997D 01	0.923437D 01	0.155036D 03	0.321750D 03	0.321750D 03	0.321750D 03		
CP	GAMMA	0.246510 00	0.19813D 01								

TABLE VII - Continued

***** STATOR *****											
STRM	PI12A	PI13A	TU22A	PS13	PS15	PS17	PS19	PS20	PS21	PS23	PS27
1	0.3464410 02	0.3270150 02	0.3182950 03	0.2831000 02	0.1461140 00	0.5607660 01	0.1500000 01	0.218170 01	0.8026380 00	0.8026380 00	0.8026380 00
2	0.3616270 02	0.3275470 02	0.3206490 03	0.2815000 02	0.1660640 00	0.420711D-01	0.1926680 00	0.1927850 00	0.2260820 00	0.2372330 01	0.8302360 00
3	0.3319190 02	0.3236940 02	0.326320 03	0.2831000 02	0.1459940 00	0.3822940-01	0.1261140 00	0.2461130 01	0.2372330 01	0.8721820 00	0.8721820 00
4	0.3154540 02	0.3222580 02	0.3455503 03	0.2831000 02	0.1459940 00	0.3822940-01	0.1261140 00	0.2461130 01	0.2372330 01	0.8721820 00	0.8721820 00
5	0.3120460 02	0.3116300 02	0.3454720 03	0.2831000 02	0.1815530 00	0.40109E-01	0.1843940 00	0.2461130 01	0.2372330 01	0.8721820 00	0.8721820 00
6	0.3172440 02	0.3117640 02	0.3882570 03	0.2831000 02	0.2659550 00	0.4391460-01	0.8165860 00	0.22630940 01	0.2630940 01	0.9672570 00	0.9672570 00
7	0.3246770 02	0.3092120 02	0.8939950 03	0.2831000 02	0.2535810 00	0.476250D-01	0.9850000 00	0.2271182D 01	0.9989940 00	0.9989940 00	0.9989940 00
STRM	AL2	THE1A	AL3	AL4	AL5	SL0	OFACIS	OP105	DISCIV	OM3	R-STRESS
1	0.4354510 02	0.4154510 02	0.4631010 02	0.0	-0.304940 01	-0.229750 01	0.503390 00	0.392480 00	0.1945700 01	0.0	0.0
2	0.4631010 02	0.4631010 02	0.4631010 02	0.0	0.311810 00	0.220387 01	0.5008610 00	0.383144 00	0.1897120 01	0.5172445D 00	0.5172445D 00
3	0.4869010 02	0.4869010 02	0.4869010 02	0.0	0.316810 01	0.2110960 01	0.4995920 00	0.3688980 00	0.1863610 01	0.555445D 00	0.555445D 00
4	0.5236480 02	0.5336480 02	0.5336480 02	0.0	0.9022590 01	0.2030940 01	0.5008350 00	0.3504560 00	0.1819860 01	0.5646440 00	0.5646440 00
5	0.2665340 02	0.5465340 02	0.5465340 02	0.0	0.310160 02	0.1951800 01	0.5182940 00	0.334810 00	0.1817250 01	0.5201520 00	0.5201520 00
6	0.5019480 02	0.5019480 02	0.5019480 02	0.0	0.7202830 01	0.1881110 01	0.5012120 00	0.1825130 00	0.1805800 00	0.5001800 00	0.482740 00
7	0.4920030 02	0.4920030 02	0.4920030 02	0.0	0.6800020 01	0.18019500 01	0.55348500 00	0.3128180 00	0.1951210 01	0.482740 00	0.482740 00
STRM	AL2*	THE1A*	AL3*	DEV	TPSS	RC3	F-TANG	F-AXIAL	R-STRESS		
1	0.4649500 02	0.4649500 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0		
2	J-459872D 02	0.4598720 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0		
3	0.4512260 02	0.4512260 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0		
4	0.4614220 02	0.4614220 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0		
5	0.4161610 02	0.4161610 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0		
6	0.4547460 02	0.4547460 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0		
7	0.4246000 02	0.4246000 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0		
STRM	M2A	M2A	C2A	C3A	CR3	C4A	CM3	CM3	U3		
1	0.7151510 00	0.45459870 00	0.9179710 03	0.6229990 03	0.6229990 03	0.0	0.6229990 03	0.6229990 03	0.0		
2	0.6164820 00	0.45145260 00	0.93591190 03	0.6206810 03	0.6206810 03	0.0	0.6206810 03	0.6206810 03	0.0		
3	0.668156D 00	0.44623260 00	0.9055130 00	0.6122940 03	0.6122940 03	0.0	0.6122940 03	0.6122940 03	0.0		
4	0.619H510 00	0.4364000 00	0.8775030 03	0.6108640 03	0.6108640 03	0.0	0.6108640 03	0.6108640 03	0.0		
5	0.6191610 00	0.4195780 00	0.8468380 03	0.5699440 03	0.5699440 03	0.0	0.5699440 03	0.5699440 03	0.0		
6	0.4947460 00	0.4049580 00	0.8474270 03	0.54874270 03	0.54874270 03	0.0	0.54874270 03	0.54874270 03	0.0		
7	0.5515150 00	0.4577750 00	0.7848800 03	0.5176700 03	0.5176700 03	0.0	0.5176700 03	0.5176700 03	0.0		
STRM	PRS5	TRS	EFF3	PRC	TRC	EFFC	PRS4	PRS4	CU2		
1	0.1549460 01	0.1181890 01	0.6661670 00	0.2981120 01	0.148220 01	0.752020 00	0.459200 00	0.6740250 00	0.0		
2	0.1527270 01	0.1149401 01	0.65230960 00	0.2981120 01	0.148220 01	0.743350 00	0.451460 00	0.676100 00	0.0		
3	0.1522570 01	0.1203000 01	0.6363930 00	0.2950990 01	0.1508630 01	0.7070010 00	0.442320 00	0.679422D 03	0.0		
4	0.1566220 01	0.1218400 01	0.6233920 00	0.2940680 01	0.1531230 01	0.660630 00	0.336400D 00	0.704154D 03	0.0		
5	0.1576640 01	0.1224540 01	0.6139520 00	0.2905710 01	0.1575670 01	0.6155990 00	0.4155780 00	0.709050 03	0.0		
6	0.1572760 01	0.1204160 01	0.6174670 00	0.2895940 01	0.16017350 01	0.5794820D 00	0.4095050 00	0.643859D 03	0.0		
7	0.1514940 01	0.119129D 01	0.652193D 00	0.2819490 01	0.1623180 01	0.59482350 00	0.357745D 00	0.5941500 03	0.0		
STRM	MCW2	MCW3	MCWA3	PRSA	PRSA	EFFSA	PRCA	PRCA	EFFCA		
J-1515150 01	0.47471580 05	0.31747110 02	0.1544730 01	0.120614D 01	0.6370150 00	0.2931210 01	0.1541720 01	0.6587910 00	0.0		
P11A	TU3A	PH13	PS13	AREA3	AREA3	CP	GAMA	GAMA	0.0		
0.1515150 02	0.45578460 03	0.4673830 00	0.3674220 00	0.3331060 01	0.6129630 01	0.2445640 00	0.136964D 01	0.6587910 00	0.0		

APPENDIX III

COMPUTOR OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - REDESIGN

TABLE VIII
COMPUTER OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - REDESIGN -
TEST NUMBER 15

••••• INLET •••••										
STAN	P01	T01	PS	T'S	A/L	EPS1	PERL	R/R1	R/R2	
1	0.1258700	02	0.4600000	03	0.1083610	02	0.4463550	03	0.1346900	01
2	0.1268700	02	0.4670000	03	0.1083610	02	0.4463550	03	0.1355430	01
3	0.1248700	02	0.4670000	03	0.1083610	02	0.4463550	03	0.1355430	00
4	0.1268700	02	0.4670000	03	0.1083610	02	0.4463550	03	0.1355430	00
5	0.1268700	02	0.4670000	03	0.1083610	02	0.4463550	03	0.1355430	00
6	0.1268700	02	0.4670000	03	0.1083610	02	0.4463550	03	0.1355430	00
7	0.1268700	02	0.4670000	03	0.1083610	02	0.4463550	03	0.1355430	00
STAN	CRI	CUI	CRI	CUI	U/L	C/L	MIA	RC	RC	
1	0.4974100	03	0.0	0.0	0.4974100	03	0.4974100	03	0.4974100	00
2	0.4974100	03	0.0	0.0	0.4974100	03	0.4974100	03	0.4974100	00
3	0.4974100	03	0.0	0.0	0.4974100	03	0.4974100	03	0.4974100	00
4	0.4974100	03	0.0	0.0	0.4974100	03	0.4974100	03	0.4974100	00
5	0.4974100	03	0.0	0.0	0.4974100	03	0.4974100	03	0.4974100	00
6	0.4974100	03	0.0	0.0	0.4974100	03	0.4974100	03	0.4974100	00
7	0.4974100	03	0.0	0.0	0.4974100	03	0.4974100	03	0.4974100	00
WCRI	WCRI	WC/AI	POA	TDA	PHL	HUB/TIP	AREA	AREA	AREA	
0.4336000	01	0.5649220	05	0.3547340	02	0.1268700	03	0.4974100	00	
CP	Gamm									
0.2394120	00	0.1401390	01							

TABLE VIII - Continued

STRM 10000 6DIGR 10000									
STRM	PR1A	PU2A	T01W	T02R	P52	J_R	PERL2	R2	R/A/I
1	0.162460 02	0.179750 02	0.5037210 03	0.5286240 03	0.1479490 02	0.2277910 00	0.100000-0.01	0.174850 01	0.441490 00
2	0.187360 02	0.195130 02	0.5227720 03	0.5431620 03	0.1570430 02	0.2454190 00	0.2078790 00	0.193760 01	0.7111470 00
3	0.212750 02	0.2054290 02	0.5411090 03	0.5574120 03	0.1658550 02	0.2909410 00	0.3865920 00	0.2115780 01	0.7778610 00
4	0.239710 02	0.2171890 02	0.5586460 03	0.5721490 03	0.1717860 02	0.3108270 00	0.3574770 00	0.2227490 01	0.8379380 00
5	0.260980 02	0.2194950 02	0.5786100 03	0.5866860 03	0.1764930 02	0.3385960 00	0.4072490 00	0.2431640 01	0.8939860 00
6	0.299780 02	0.2424630 02	0.5972480 03	0.6017370 03	0.1819880 02	0.33320840 00	0.4520700 00	0.2574250 01	0.9464140 00
7	0.4336070 02	0.22321890 02	0.6159980 03	0.6156740 03	0.1867780 02	0.4475020 00	0.4900000 00	0.2710150 01	0.9363700 00
STRM	B1	IMETIA	B2	SLO	OP/CTR	OP/QR	Dm2		
1	0.5313750 02	0.5050090 02	0.2636570 01	0.8467490 01	0.2394000 01	0.4217310 00	0.4492730 00	0.167980 01	0.0
2	0.5881450 02	0.5071770 02	0.7489580 02	0.8340610 01	0.2277270 01	0.4462700 00	0.1346060 00	0.1855230 01	0.7763210 00
3	0.6217500 02	0.5943450 02	0.3275660 02	0.8010600 01	0.2146050 01	0.5323480 00	0.5953310 00	0.2420860 01	0.7420860 00
4	0.6447570 02	0.4954360 02	0.4521210 02	0.7720480 01	0.204510 01	0.540610 00	0.4855340 00	0.206160 01	0.6114510 00
5	1.6672820 02	0.1131030 02	0.5544800 02	0.7488930 01	0.1973650 01	0.4610720 00	0.2245380 01	0.5403630 00	
6	0.6829130 02	0.2004180 02	0.4819940 02	0.7245470 01	D.1688780 01	0.5728790 00	0.3853530 00	0.2101930 01	0.6488610 00
7	0.6938310 02	-1.1337660 00	0.6971690 02	0.7053110 01	0.1600000 01	0.4702340 00	0.3686350 00	0.2397700 01	0.5550150 00
STRM	di*	IMETIA	H2*	0/EV	E/S2	RC2	F-TANG	F-AXIAL	H-STRESS
1	J.4449000 02	0.5532000 02	0.9170000 01	-6333330 01	D.0	0.1000000 01	0.0	0.0	0.0
2	0.5027330 02	0.2781300 02	0.2246090 02	-4545090 01	D.0	0.1000000 01	-1.1922180 02	-0.115200 02	0.1671740 01
3	0.5416440 02	0.2165040 02	0.3251360 02	0.2229260 00	D.0	0.1000000 01	-1.685410 02	-0.1394830 02	0.1906100 01
4	0.5703470 02	0.1703130 02	0.4009130 02	0.521070 01	D.0	0.1000000 01	-1.427660 02	-0.1498640 02	0.2112560 01
5	0.5925930 02	0.1357150 02	0.4568780 02	0.9730150 01	D.0	0.1000000 01	-1.100000 02	-0.1534490 02	0.2300210 01
6	0.6106440 02	0.1089480 02	0.5014910 02	-1.9494630 01	D.0	0.1000000 01	-1.377200 02	-0.168104 02	0.2472810 01
7	0.6293000 02	0.81863000 01	0.53175000 02	0.1936630 02	D.0	0.1000000 01	-1.1219270 02	-0.1739840 02	0.2633550 01
STRM	M1W	M2R	WIR	M2R	CX2	MU2	CM2	CR2	U2
1	0.6002370 00	0.15596680 00	0.62151590 03	0.6111010 03	0.2815920 02	0.6111010 03	0.5550930 00	0.5550930 03	
2	0.9217450 00	0.5680850 00	0.9551000 03	0.6292550 03	0.5981130 03	0.1933430 03	0.5988130 03	0.4953390 03	
3	0.1028470 01	0.3642110 00	0.6366410 04	0.6334880 04	0.5634760 04	0.427660 03	0.427660 03	0.4042090 04	
4	0.1112630 01	0.5885780 00	0.1106320 04	0.6075760 03	0.4702970 03	0.4717920 03	0.4702970 03	0.41122510 04	
5	0.1217080 01	0.56538890 00	0.1258970 04	0.6516100 03	0.3698550 03	0.5334800 03	0.3698450 03	0.4197660 04	
6	0.1297850 01	0.5551630 00	0.1349760 04	0.7559340 03	0.5038600 03	0.5635260 03	0.5038600 03	0.42267900 04	
7	0.1376150 01	0.5653880 00	0.1425860 04	0.6666950 03	0.2312070 03	0.4236010 03	0.2312070 03	0.4133480 04	
STRM	PRS	TH5	EFFS	PRC	INC	EFFC	M2	CX2/CXL	
1	0.2032860 01	0.12552710 01	0.8828640 00	0.20328640 01	0.12552710 01	0.8812350 00	0.5550930 00	0.122370 01	
2	0.2038750 01	0.1260160 01	0.8699790 00	0.2038750 01	0.1260160 01	0.8665690 00	0.5460590 00	0.120860 01	
3	0.1956270 01	0.1260590 01	0.8135380 00	0.1955260 01	0.1260490 01	0.8135380 00	0.5455980 00	0.1072290 01	
4	0.1889320 01	0.1260260 01	0.7603380 00	0.1889320 01	0.1260260 01	0.7603380 00	0.5446020 00	0.9454920 01	
5	0.1865640 01	0.1282950 01	0.6911120 00	0.1865640 01	0.1282950 01	0.6900130 00	0.3211910 00	0.743410 00	
6	0.2095160 01	0.1319140 01	0.7306110 00	0.2085160 01	0.1319140 01	0.7328670 00	0.4367010 00	0.101970 01	
7	0.1928650 01	0.1338310 01	0.6118350 00	0.1928650 01	0.1338310 01	0.6118350 00	0.1959970 00	0.4664230 00	
MCR2	NC12	MC/A2	PKSA	TKS	EFFSA	PRC6	FFFL6		
0.2474320 01	0.5262410 05	0.2585550 02	0.1980800 01	0.127730 01	0.779170 00	0.1980800 01	0.1277630 01	0.7776600 00	
PU2A	T02A	PM12	PS12	AREA2	MP5	WPC			
0.2513040 02	0.5966220 03	0.4513070 00	0.4053810 00	0.1370590 02	0.1351010 02	0.1732200 03	0.1734820 03		
CP	GAMA								
0.2394120 00	0.1401390 01								

TABLE VIII - Continued

***** STATOR *****											
STRN	P02A	P03A	T02A	P53	25	OPD/PO	PERL3	R3	R/RAT		
1	0.2579090 02	0.2579150 02	0.5662120 03	0.2167170 02	0.450150-01	0.000000-01	0.150000-01	0.1912000 01	0.702900 00		
2	0.2566560 02	0.2534830 02	0.5664950 03	0.2167170 02	0.509100-01	0.200000-01	0.202620 00	0.2081810 01	D.7653710 00		
3	0.2481950 02	0.2433150 02	0.5866450 03	0.2167170 02	0.601580-01	0.3759110 00	0.2220730 01	0.8164450 00			
4	0.2396590 02	0.2340500 02	0.5865400 03	0.2167170 02	0.7057110-01	0.200000-01	0.5402760 00	D.2322220 01	0.8647790 00		
5	0.2366790 02	0.2319650 02	0.5991460 03	0.2167170 02	0.7924770-01	0.200000-01	0.6959270 00	0.2476740 01	0.9105670 00		
6	0.2645640 02	0.2794540 02	0.6160380 03	0.2167170 02	0.6409570-01	0.200000-01	0.4438520 00	0.4954600 01	0.9388980 00		
7	0.24446370 02	0.2497930 02	0.6249890 03	0.2167170 02	0.8463380-01	0.200000-01	0.9850000 00	0.2700000 01	0.9955580 00		
STRN	AL7	META	AL3	DAL2	SLO	DFACTS	DP/DS	DEFQIV	DM3		
1	0.5165990 02	0.5165980 02	0.0	0.3719820 01	0.2268000 01	0.6427930 00	0.6342290 00	0.2339040 01	0.0		
2	0.5193910 02	0.518930 02	0.0	0.322087 01	0.2138190 01	0.5872660 00	0.5872660 00	0.7669500 00			
3	0.5270100 02	0.5270100 02	0.0	0.6228250 01	0.1992270 01	0.6542710 00	0.619190 00	0.2326310 01	0.9981680 00		
4	0.5400190 02	0.5406190 02	0.0	0.8885780 01	0.1867780 01	0.1616030 00	0.6616930 00	0.2547080 01	0.9554140 00		
5	0.5077770 02	0.6077770 02	0.0	0.16669730 02	0.1783260 01	0.5591010 00	D.663950 00	0.2583550 01	0.4783130 00		
6	0.5422760 02	0.5422760 02	0.0	0.1127730 02	0.1675400 01	0.583880 00	0.4200022 00	0.1888920 01	0.6226010 00		
7	0.7194420 02	0.7194420 02	0.0	0.2982420 02	0.1512000 01	0.8943220 00	0.5161640 00	0.1997940 01	0.326820 00		
STRN	AL2*	META*	AL3*	O/E/V	EPS3	RC3	F-TANG	F-AXIAL	R-STRESS		
1	0.4994390 02	0.4990000 02	0.0	0.0	0.0	D.1000000 01	0.0	0.0	0.0		
2	0.4801740 02	0.4801740 02	0.0	0.0	0.0	0.1000000 01	0.1869880 02	-0.111610 02	0.192460 01		
3	0.4647720 02	0.4647720 02	0.0	0.0	0.0	0.0000000 01	0.1226630 02	-0.8567700 01	0.2241980 01		
4	0.511620 02	0.511620 02	0.0	0.0	0.0	0.0000000 01	0.9737740 01	-0.802900 01	0.2384950 01		
5	0.4403140 02	0.4403140 02	0.0	0.0	0.0	0.1000000 01	0.1700000 01	-0.8669320 01	0.2519310 01		
6	0.4314440 02	0.4314440 02	0.0	0.0	0.0	D.1010000 01	0.144570 02	-0.1605970 02	-0.1D47200 02		
7	0.42123230 02	0.42123230 02	0.0	0.0	0.0	0.1010000 01	0.1605970 02	-0.1D47200 02	0.2646750 01		
STRN	M24	M3A	C2A	C3A	CX3	CX3	CX3	CX3	U3		
1	0.9416270 00	0.4797310 00	0.1111910 04	0.5502650 03	0.5502650 03	0.0	0.5502650 03	0.0	0.5515720 03		
2	0.8749910 00	0.4782640 00	0.4919580 03	0.5553800 03	0.5553800 03	0.0	0.5553800 03	0.0	0.5025260 04		
3	0.7811730 00	0.4592350 00	0.4193540 03	0.4789620 03	0.4789620 03	0.0	0.4789620 03	0.0	0.1093780 04		
4	0.7064440 00	0.3410980 00	0.4613100 03	0.4011750 03	0.4011750 03	0.0	0.4011750 03	0.0	0.1155640 04		
5	0.6579280 00	0.3113340 00	0.7575910 03	0.3721420 03	0.3721420 03	0.0	0.3721420 03	0.0	0.1219810 04		
6	0.7506110 00	0.5125930 00	0.8660380 03	0.6077910 03	0.6077910 03	0.0	0.6077910 03	0.0	0.1277920 04		
7	0.6121670 00	0.4921780 00	0.74559690 03	0.4625610 03	0.4625610 03	0.0	0.4625610 03	0.0	0.1333780 04		
STRN	PAS	TAS	EFFS	PHC	TBC	EFFC	M33	CU2			
1	0.1992200 01	0.1255270 01	0.85469890 00	0.1992200 01	0.1255270 01	0.0535640 00	0.4737310 00	0.8312350 03			
2	0.1797310 01	0.1260160 01	0.8427810 00	0.1994980 01	0.1260160 01	0.0413980 00	0.4782640 00	0.7620310 03			
3	0.1917170 01	0.1266490 01	0.7866940 00	0.191170 01	0.1266490 01	0.0409540 00	0.4092350 00	0.6995150 03			
4	0.1851540 01	0.1260260 01	0.4143170 00	0.1851540 01	0.1260260 01	0.0402310 00	0.3410980 00	D.6687620 03			
5	0.1828310 01	0.1242970 01	0.6667240 00	0.1828370 01	0.1242970 01	0.0656590 00	0.3130340 00	0.6611410 03			
6	0.2044660 01	0.1319140 01	0.717440 00	0.2044660 01	0.1319140 01	0.105120 00	0.5122930 00	0.7043730 03			
7	0.1893070 01	0.1313110 01	0.5912560 00	0.1890070 01	0.1335310 01	0.3902550 00	D.3827780 00	0.7092340 03			
WCA1	MC82	VG3A	PH11	PRSA	VASA	EFFSA	TRCA	EFFCA			
0.252030 01	0.5255390 05	0.3112650 02	0.1946940 01	0.1261040 01	0.1401290 00	0.1946940 01	D.1261040 01	0.7469040 00			
P03A	TG3A	PH11	P513	AREA3	AREE3	CP	GAMMA				
0.247030 02	0.5982460 03	0.3638470 00	0.5407370 00	0.1166160 02	0.1131170 02	0.2402800 00	0.1399340 01				

TABLE VIII - Continued

***** ROTUR 2*****											
STR#	PR1#	P01#	P02#	P01A	P02A	PS1#	PS2	J#	PERL1#	R2	R/R7
1	0.3859340	0.2	0.3406610	0.2	0.4417640	0.3	0.4753810	0.3	0.4362410	0.2	0.7708570
2	0.4117540	0.2	0.3523120	0.2	0.6162220	0.3	0.6876090	0.3	0.4743210	0.2	0.8130300
3	0.4202800	0.2	0.3540960	0.2	0.6867640	0.3	0.729290	0.2	0.4316840	0.0	0.2213270
4	0.4315970	0.2	0.3533179	0.2	0.7005370	0.3	0.7076430	0.3	0.4234240	0.0	0.8532670
5	0.4477050	0.2	0.3600860	0.2	0.7231610	0.3	0.726360	0.3	0.4352660	0.0	0.2424330
6	0.5206650	0.2	0.3668410	0.2	0.7523040	0.3	0.7548100	0.3	0.4619080	0.0	0.9277730
7	0.5046010	0.2	0.3930560	0.2	0.7734270	0.3	0.7944600	0.2	0.3894470	0.2	0.9826800
8	0.7047520	0.2	C.1303110	0.2	0.5784200	0.2	0.5784200	0.2	0.5955000	0.0	0.2710950
STR#	M1	M2	THETA	B2	081	SLD	OFAC7N	OP/DR	OEQUIV	OM2	R-STRESS
1	0.559650	0.2	0.3175830	0.2	0.2620230	0.2	0.4630510	0.1	0.2390400	0.0	0.1801020
2	0.615150	0.2	0.278520	0.2	0.3464700	0.1	0.4676120	0.0	0.2943740	0.0	0.7967820
3	0.6635160	0.2	0.2615040	0.2	0.4020090	0.2	0.8104920	0.1	0.5009790	0.0	0.1916660
4	0.7090210	0.2	0.2433070	0.2	0.4656960	0.2	0.1151860	0.2	0.2060360	0.1	0.6498650
5	0.7303460	0.2	D.2146640	0.2	0.5155020	0.2	0.1219510	0.2	0.1955980	0.1	0.2054400
6	0.4505190	0.2	0.1771990	0.2	0.5104390	0.2	0.2370620	0.1	0.1863380	0.1	0.5973330
7	0.4519330	0.2	0.1185300	0.2	0.5047370	0.2	0.5047370	0.2	0.5231800	0.0	0.1995340
8	0.615150	0.2	0.1050000	0.2	0.5276500	0.2	0.5276500	0.1	0.1746900	0.1	0.5946170
STR#	M1#	M2#	THETA	B2#	081#	SLD#	OFAC7N#	OP/DR#	OEQUIV#	OM2#	R-STRESS
1	0.5139330	0.2	0.2379000	0.2	0.2954000	0.2	0.3557170	0.1	0.1000000	0.1	0.201630
2	0.5545010	0.2	0.2045280	0.2	0.3507140	0.2	0.4677710	0.1	0.3000000	0.1	-0.1096110
3	0.5779940	0.2	0.1751290	0.2	0.4007340	0.2	0.1271360	0.0	0.1000000	0.1	-0.1266610
4	0.4942190	0.2	0.1527790	0.2	0.4604400	0.2	0.2221590	0.0	0.1000000	0.1	-0.1529160
5	0.6064970	0.2	0.1395110	0.2	0.4764460	0.2	0.4105660	0.1	0.1000000	0.3	-0.1359680
6	0.462114210	0.2	0.1185300	0.2	0.5047370	0.2	0.5047370	0.2	0.1000000	0.1	-0.1246601
7	0.4519330	0.2	0.1050000	0.2	0.5276500	0.2	0.5276500	0.1	0.1000000	0.1	-0.1255330
8	0.615150	0.2	0.1050000	0.2	0.5276500	0.2	0.5276500	0.1	0.1000000	0.1	-0.1265190
STR#	M1#	M2#	THETA	B2#	081#	SLD#	OFAC7N#	OP/DR#	OEQUIV#	OM2#	R-STRESS
1	0.5139330	0.2	0.2379000	0.2	0.2954000	0.2	0.3557170	0.1	0.1000000	0.1	0.201630
2	0.5545010	0.2	0.2045280	0.2	0.3507140	0.2	0.4677710	0.1	0.3000000	0.1	-0.1096110
3	0.5779940	0.2	0.1751290	0.2	0.4007340	0.2	0.1271360	0.0	0.1000000	0.1	-0.1266610
4	0.4942190	0.2	0.1527790	0.2	0.4604400	0.2	0.2221590	0.0	0.1000000	0.1	-0.1529160
5	0.6064970	0.2	0.1395110	0.2	0.4764460	0.2	0.4105660	0.1	0.1000000	0.3	-0.1359680
6	0.462114210	0.2	0.1185300	0.2	0.5047370	0.2	0.5047370	0.2	0.1000000	0.1	-0.1246601
7	0.4519330	0.2	0.1050000	0.2	0.5276500	0.2	0.5276500	0.1	0.1000000	0.1	-0.1255330
8	0.615150	0.2	0.1050000	0.2	0.5276500	0.2	0.5276500	0.1	0.1000000	0.1	-0.1265190
STR#	M1#	M2#	THETA	B2#	081#	SLD#	OFAC7N#	OP/DR#	OEQUIV#	OM2#	R-STRESS
1	0.5139330	0.2	0.5944640	0.0	0.1099220	0.4	0.1311710	0.3	0.6566520	0.3	0.4566520
2	0.5072790	0.1	0.5081440	0.0	0.1166580	0.4	0.7541710	0.3	0.6227230	0.3	0.4187720
3	0.1020250	0.1	0.5644860	0.0	0.1194050	0.4	0.7383640	0.3	0.5636920	0.3	0.4765920
4	0.1072810	0.1	0.5643650	0.0	0.1226040	0.4	0.7213160	0.3	0.5493170	0.3	0.5036950
5	0.1122678	0.1	0.5645630	0.0	0.1275360	0.4	0.7284390	0.3	0.5704790	0.3	0.4522660
6	0.1172275	0.1	0.5641122	0.0	0.1415100	0.4	0.6294110	0.3	0.5126810	0.3	0.1288660
7	0.1164720	0.1	0.6479460	0.0	0.1411710	0.4	0.6893420	0.3	0.4515610	0.3	0.1335030
STR#	M1#	M2#	THETA	B2#	081#	SLD#	OFAC7N#	OP/DR#	OEQUIV#	OM2#	R-STRESS
1	0.5139330	0.2	0.5944640	0.0	0.1099220	0.4	0.1311710	0.3	0.6566520	0.3	0.4566520
2	0.5072790	0.1	0.5081440	0.0	0.1166580	0.4	0.7541710	0.3	0.6227230	0.3	0.4187720
3	0.1020250	0.1	0.5644860	0.0	0.1194050	0.4	0.7383640	0.3	0.5636920	0.3	0.4765920
4	0.1072810	0.1	0.5643650	0.0	0.1226040	0.4	0.7213160	0.3	0.5493170	0.3	0.5036950
5	0.1122678	0.1	0.5645630	0.0	0.1275360	0.4	0.7284390	0.3	0.5704790	0.3	0.4522660
6	0.1172275	0.1	0.5641122	0.0	0.1415100	0.4	0.6294110	0.3	0.5126810	0.3	0.1288660
7	0.1164720	0.1	0.6479460	0.0	0.1411710	0.4	0.6893420	0.3	0.4515610	0.3	0.1335030
STR#	M1#	M2#	THETA	B2#	081#	SLD#	OFAC7N#	OP/DR#	OEQUIV#	OM2#	R-STRESS
1	0.5139330	0.2	0.5944640	0.0	0.1099220	0.4	0.1311710	0.3	0.6566520	0.3	0.4566520
2	0.5072790	0.1	0.5081440	0.0	0.1166580	0.4	0.7541710	0.3	0.6227230	0.3	0.4187720
3	0.1020250	0.1	0.5644860	0.0	0.1194050	0.4	0.7383640	0.3	0.5636920	0.3	0.4765920
4	0.1072810	0.1	0.5643650	0.0	0.1226040	0.4	0.7213160	0.3	0.5493170	0.3	0.5036950
5	0.1122678	0.1	0.5645630	0.0	0.1275360	0.4	0.7284390	0.3	0.5704790	0.3	0.4522660
6	0.1172275	0.1	0.5641122	0.0	0.1415100	0.4	0.6294110	0.3	0.5126810	0.3	0.1288660
7	0.1164720	0.1	0.6479460	0.0	0.1411710	0.4	0.6893420	0.3	0.4515610	0.3	0.1335030
STR#	M1#	M2#	THETA	B2#	081#	SLD#	OFAC7N#	OP/DR#	OEQUIV#	OM2#	R-STRESS
1	0.5139330	0.2	0.5944640	0.0	0.1099220	0.4	0.1311710	0.3	0.6566520	0.3	0.4566520
2	0.5072790	0.1	0.5081440	0.0	0.1166580	0.4	0.7541710	0.3	0.6227230	0.3	0.4187720
3	0.1020250	0.1	0.5644860	0.0	0.1194050	0.4	0.7383640	0.3	0.5636920	0.3	0.4765920
4	0.1072810	0.1	0.5643650	0.0	0.1226040	0.4	0.7213160	0.3	0.5493170	0.3	0.5036950
5	0.1122678	0.1	0.5645630	0.0	0.1275360	0.4	0.7284390	0.3	0.5704790	0.3	0.4522660
6	0.1172275	0.1	0.5641122	0.0	0.1415100	0.4	0.6294110	0.3	0.5126810	0.3	0.1288660
7	0.1164720	0.1	0.6479460	0.0	0.1411710	0.4	0.6893420	0.3	0.4515610	0.3	0.1335030
STR#	M1#	M2#	THETA	B2#	081#	SLD#	OFAC7N#	OP/DR#	OEQUIV#	OM2#	R-STRESS
1	0.5139330	0.2	0.5944640	0.0	0.1099220	0.4	0.1311710	0.3	0.6566520	0.3	0.4566520
2	0.5072790	0.1	0.5081440	0.0	0.1166580	0.4	0.7541710	0.3	0.6227230	0.3	0.4187720
3	0.1020250	0.1	0.5644860	0.0	0.1194050	0.4	0.7383640	0.3	0.5636920	0.3	0.4765920
4	0.1072810	0.1	0.5643650	0.0	0.1226040	0.4	0.7213160	0.3	0.5493170	0.3	0.5036950
5	0.1122678	0.1	0.5645630	0.0	0.1275360	0.4	0.7284390	0.3	0.5704790	0.3	0.4522660

TABLE VIII - Continued

***** STATOR *****												
STRM	PD2A	P13A	T023A	PS3	LS	OPD/PO	PERL3-	A3	R/A7			
1	0.403100	02	0.1R97170	02	0.708170	03	0.3336280	02	0.105060	00	0.2163170	01
2	0.392160	02	0.3834960	02	0.7104990	03	0.3336280	02	0.974310	-01	0.1926310	00
3	0.387251	02	0.370750	02	0.7151970	03	0.3336280	02	0.947790	-01	0.2277540	00
4	0.391631	02	0.3729550	02	0.7231860	03	0.3336280	02	0.947790	-01	0.2327230	01
5	0.376882	02	0.3710490	02	0.7385130	03	0.3336280	02	0.8540100	-01	0.2214600	01
6	0.365240	02	0.3764490	02	0.7531540	03	0.3336280	02	0.7826610	-01	0.2547740	00
7	0.3713860	02	0.3668960	02	0.7624470	03	0.3336280	02	0.8433170	-01	0.1844340	01
STRM	AL2	THE7A	AL3	DAL2	SL0	OPFACTS	OP/QJS	DEQUV	DR3			
1	0.4721170	J2	0.4721170	02	0.0	0.3216830	00	0.229550	01	0.5317790	00	
2	0.469580	02	0.4694580	02	0.0	0.9285860	00	0.2203670	01	0.5278530	00	
3	0.4976490	02	0.4976470	02	0.0	0.4642260	01	0.2118960	01	0.5574670	00	
4	0.5405050	02	0.5405050	02	0.0	0.9104280	01	0.2036940	01	0.5219560	00	
5	0.5603550	02	0.5603550	02	0.0	0.1239860	01	0.1951860	00	0.5045000	00	
6	0.5117750	02	0.5117750	02	0.0	0.8182040	01	0.1881710	01	0.5495910	00	
7	0.5319190	02	0.5319190	02	0.0	0.1139190	02	0.1807500	01	0.5751040	00	
STRM	AL2*	THE7A*	AL3*	DEV	EPS3	AC3	F-TANG	F-AXIAL	A-STRESS			
1	0.4695000	02	0.4695000	02	0.0	0.0	0.1000000	01	0.0	0.4841050	00	
2	0.4534720	02	0.4534720	02	0.0	0.0	0.1000000	01	0.0	0.4891240	00	
3	0.4512260	02	0.4512260	02	0.0	0.0	0.1000000	01	0.0	0.5008240	00	
4	0.4444220	02	0.4434220	02	0.0	0.0	0.1000000	01	0.0	0.5025000	00	
5	0.4361690	02	0.4361690	02	0.0	0.0	0.1000000	01	0.0	0.4961850	00	
6	0.4239540	02	0.4239540	02	0.0	0.0	0.1000000	01	0.0	0.4947830	00	
7	0.4240000	02	0.4240000	02	0.0	0.0	0.1000000	01	0.0	0.487040	01	
STRM	H2A	H3A	C2A	C3A	C4A	C5A	CU3	C43	C13	U3		
1	0.78621d1	03	0.4766300	00	0.9671660	03	0.6081760	03	0.6081760	03	0.1075260	04
2	0.7405130	00	0.4504990	00	0.9187460	03	0.5769180	03	0.5769180	03	0.1122270	04
3	0.6953220	00	0.4219220	00	0.8730910	03	0.5436460	03	0.5436460	03	0.1168550	04
4	0.6601660	00	0.4022640	00	0.351910	03	0.5217920	03	0.5217920	03	0.121440	04
5	0.6326080	00	0.3927420	00	0.4107770	03	0.5152060	03	0.5152060	03	0.125475	04
6	0.6318110	00	0.4190460	00	0.8177900	03	0.5533920	03	0.5533920	03	0.124994	04
7	0.5831990	00	0.3711060	00	0.7664260	03	0.4954240	03	0.4954240	03	0.133566	04
STRM	PRS	TRS	FFFS	PAC	TAC	EFFC	MX3	CU2				
1	0.1541970	01	0.1208960	01	0.4219500	00	0.3071920	01	0.1517590	01	0.7848760	00
2	0.1512750	01	0.1207310	01	0.6306340	00	0.3022430	01	0.1521410	01	0.7113360	00
3	0.1530270	01	0.1215930	01	0.6175600	00	0.2972130	01	0.1532540	01	0.6464170	00
4	0.1581690	01	0.1228710	01	0.6163360	00	0.2939660	01	0.1544580	01	0.6436390	00
5	0.1599570	01	0.1232700	01	0.6168920	00	0.2924600	01	0.1581530	01	0.3927420	00
6	0.142070	01	0.122290	01	0.5046090	00	0.2967220	01	0.1612760	01	0.4190440	00
7	0.1530060	01	0.1219940	01	0.5861700	00	0.2891930	01	0.1632650	01	0.3711060	00
STRM	MCR2	SC/A3	PRSA	TASA	PRCA	EFFSA	PRCA	TACA	EFFCA			
0.1621720	01	0.4746260	05	0.31130000	02	0.1526870	01	0.1217630	01	0.5698960	00	
PO3A	T02A	PM13	PS13	PS13	AK6A3	AK63	CP	CP	CP			
0.3771490	02	0.7254430	03	0.44346900	00	0.35640000	00	0.8331060	01	0.2426450	00	
										0.1395250	01	

TABLE IX
COMPUTER OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - REDESIGN -
TEST NUMBER 16

***** INLET *****												
STRM	PUL	TUL	P5	U1	AL1	EPS1	PERL					R/AT
							0.0	0.0	0.0	0.0	0.0	
1	0.1210000 02	0.4650000 03	0.1035890 02	0.4447610 03	0.0	0.0	0.5000000-02	0.1346900 01	0.4511840 00	0.1554320 01	0.4086140 00	
2	0.1210000 02	0.4650000 03	0.1035890 02	0.4447610 03	0.0	0.0	0.2285730 00	0.1913610 01	0.7036470 00	0.2141680 01	0.7874550 00	
3	0.1210000 02	0.4650000 03	0.1035890 02	0.4447610 03	0.0	0.0	0.4152290 00	0.5810510 00	0.2348160 01	0.8432930 00	0.2334650 01	
4	0.1210000 02	0.4650000 03	0.1035890 02	0.4447610 03	0.0	0.0	0.7105480 00	0.1671390 00	0.4974330 00	0.2713100 01	0.9974330 00	
5	0.1210000 02	0.4650000 03	0.1035890 02	0.4447610 03	0.0	0.0	0.4950000 00	0.2713100 01	0.9974330 00			
6	0.1210000 02	0.4650000 03	0.1035890 02	0.4447610 03	0.0	0.0						
7	0.1210000 02	0.4650000 03	0.1035890 02	0.4447610 03	0.0	0.0						
***** CTRM *****												RC
STRM	Cx1	Cy1	Cx1	RC								
1	0.924900 03	0.0	0.0	0.0	0.4924900 03	0.4518630 03	0.4924900 03	0.4761600 00	0.4924900 03	0.4761600 00	0.4924900 03	0.1000000 01
2	0.924900 03	0.0	0.0	0.0	0.4924900 03	0.4137470 03	0.4924900 03	0.4761600 00	0.4924900 03	0.4761600 00	0.4924900 03	0.1000000 01
3	0.924900 03	0.0	0.0	0.0	0.4924900 03	0.4902550 03	0.4924900 03	0.4761600 00	0.4924900 03	0.4761600 00	0.4924900 03	0.1000000 01
4	0.924900 03	0.0	0.0	0.0	0.4924900 03	0.1052500 04	0.4924900 03	0.4761600 00	0.4924900 03	0.4761600 00	0.4924900 03	0.1000000 01
5	0.924900 03	0.0	0.0	0.0	0.4924900 03	0.1153680 04	0.4924900 03	0.4761600 00	0.4924900 03	0.4761600 00	0.4924900 03	0.1000000 01
6	0.924900 03	0.0	0.0	0.0	0.4924900 03	0.1244650 04	0.4924900 03	0.4761600 00	0.4924900 03	0.4761600 00	0.4924900 03	0.1000000 01
7	0.924900 03	0.0	0.0	0.0	0.4924900 03	0.1333210 04	0.4924900 03	0.4761600 00	0.4924900 03	0.4761600 00	0.4924900 03	0.1000000 01
WCTR	MCAL	MC/AL	PUA	TUA	PHI	MUB/TIP	AREA	AREA				
0.310070 01	0.5987260 05	0.3522070 02	0.1210000 02	0.4450000 03	0.4937060 00	0.4926670 00	0.1760170 02	0.1742570 02				
CP	GAMMA											
0.2394060 00	0.1401410 01											

TABLE IX - Continued

***** ROTOR *****											
STHM	POLR	PO2R	PO1R	702R	PS2	LR	PERL2	R2	PERL2	R2	M/R/T
1	0.157588D 02	0.167847D 02	0.301555D 03	0.526362D 03	0.131565D 02	0.345352D 00	0.100000D-01	0.174485D 01	0.641489D 00		
2	0.179022D 02	0.181130D 02	0.320218D 03	0.140981D 03	0.140340D 02	0.193760D 00	0.193760D 01	0.713147D 00			
3	0.202227D 02	0.191661D 02	0.538770D 03	0.555511D 03	0.151357D 02	0.336555D 00	0.386582D 00	0.211578D 01	0.776610D 00		
4	0.227611D 02	0.199195D 02	0.557435D 03	0.569468D 03	0.157751D 02	0.375100D 00	0.552477D 00	0.227919D 01	0.837938D 00		
5	0.255631D 02	0.205928D 02	0.516499D 03	0.584139D 03	0.163104D 02	0.412493D 00	0.423164D 00	0.893986D 00			
6	0.285551D 02	0.211730D 02	0.594622D 03	0.598233D 03	0.160930D 02	0.441652D 00	0.452027D 00	0.257425D 01	0.946414D 00		
7	0.318885D 02	0.208426D 02	0.613316D 03	0.612994D 03	0.173022D 02	0.508531D 00	0.990000D 00	0.271015D 01	0.993379D 00		
STHM	B1	THETA	82	82	U81	SLO	OFACTR	O7/QR	DEQULV	OM2	
1	0.533477D 02	0.546180D 02	-708584D-01	0.8653472D 01	0.239400D 01	0.377508D 00	0.318080D 00	0.157183D 01	0.763868D 00		
2	0.584886D 02	0.497210D 02	0.148366D 02	0.8533472D 01	0.227527D 01	0.448907D 00	0.522865D 00	0.174220D 01	0.743468D 00		
3	0.623552D 02	0.341752D 02	0.281800D 02	0.819016D 01	0.216855D 01	0.515194D 00	0.483786D 00	0.193620D 01	0.743468D 00		
4	0.649240D 02	0.243117D 02	0.405522D 02	0.786928D 01	0.206851D 01	0.454674D 00	0.437799D 00	0.677240D 01	0.207503D 01	0.592700D 00	
5	0.668866D 02	0.183520D 02	0.483513D 02	0.762272D 01	0.197565D 01	0.591574D 00	0.391434D 00	0.220230D 01	0.592700D 00		
6	0.684412D 02	0.152727D 02	0.511685D 02	0.739555D 01	0.188678D 01	0.433713D 00	0.354493D 00	0.231924D 01	0.550100D 00		
7	0.692757D 02	0.207646D 01	0.616492D 02	0.719568D 01	0.180600D 01	0.713881D 00	0.323705D 00	0.260303D 01	0.419147D 00		
STHM	B10	THETA	82*	82*	DEV	EPS2	RC2	F-7ANG	F-AXIAL	R-STRESS	
1	0.44449000D 02	0.35220000D 02	0.31700000D 01	0.924096D 01	0.0	0.10000000D 01	0.0	0.0	0.0	0.0	
2	0.502739D 02	0.278330D 02	0.224409D 02	-160435D 01	0.0	0.10000000D 01	-174804D 02	-103607D 02	0.161174D 01		
3	0.551644D 02	0.216508D 02	0.325136D 02	-433368D 01	0.0	0.10000000D 01	-174581D 02	-127641D 02	0.198100D 01		
4	0.570347D 02	0.170333D 02	0.400013D 02	0.550927D 00	0.0	0.10000000D 01	-146291D 02	-135095D 02	0.211256D 01		
5	0.592593D 02	0.135715D 02	0.456878D 02	0.268352D 01	0.0	0.10000000D 01	-127870D 02	-139364D 02	0.230210D 01		
6	0.610458D 02	0.105948D 02	0.501491D 02	0.301945D 01	0.0	0.10000000D 01	-121332D 02	-145472D 02	0.242676D 01		
7	0.625300D 02	0.876000D 01	0.5315000D 02	0.138992D 02	0.0	0.10000000D 01	-967604D 01	-149865D 02	0.263354D 01		
STHM	MIR	M2R	MIR	M2R	CR2	MU2	CR2	CR2	CR2	CR2	
1	0.797635D 01	0.599997D 00	0.824491D 03	0.651193D 03	0.651193D 03	0.806278D 00	0.451193D 03	0.451193D 03	0.451193D 03	0.451193D 03	0.854415D 03
2	0.194404D 00	0.604406D 00	0.901494D 03	0.601494D 03	0.601494D 03	0.643194D 03	0.3111487D 03	0.3111487D 03	0.3111487D 03	0.3111487D 03	0.951193D 03
3	0.102623D 01	0.590411D 00	0.101613D 04	0.659595D 03	0.581049D 03	0.431660D 03	0.581149D 03	0.581149D 03	0.581149D 03	0.581149D 03	0.101969D 04
4	0.112249D 01	0.586748D 00	0.120230D 04	0.664425D 03	0.670471D 03	0.445366D 03	0.545377D 03	0.545377D 03	0.545377D 03	0.545377D 03	0.111999D 04
5	0.121249D 01	0.588442D 00	0.125458D 04	0.670166D 03	0.677314D 03	0.406616D 03	0.548217D 03	0.548217D 03	0.548217D 03	0.548217D 03	0.114990D 04
6	0.129530D 01	0.585288D 00	0.134027D 04	0.677314D 03	0.684326D 03	0.406616D 03	0.550616D 03	0.550616D 03	0.550616D 03	0.550616D 03	0.124980D 04
7	0.137414D 01	0.522337D 00	0.142127D 04	0.617613D 03	0.234986D 03	0.571214D 03	0.234986D 03	0.234986D 03	0.234986D 03	0.234986D 03	0.133176D 04
STHM	PRS	TWS	EFFS	PNC	TRC	EFFC	MM2	MM2	MM2	MM2	
1	0.203975D 01	0.126409D 01	0.457713D 00	0.203975D 01	0.126409D 01	0.856294D 00	0.599996D 00	0.599996D 00	0.599996D 00	0.599996D 00	
2	0.204270D 01	0.126780D 01	0.489233D 00	0.204270D 01	0.126780D 01	0.846272D 00	0.584255D 00	0.584255D 00	0.584255D 00	0.584255D 00	
3	0.197423D 01	0.127172D 01	0.471614D 00	0.197423D 01	0.127172D 01	0.793100D 00	0.520429D 00	0.520429D 00	0.520429D 00	0.520429D 00	
4	0.190071MD 01	0.127660D 01	0.520209D 00	0.190071MD 01	0.127660D 01	0.729120D 00	0.445819D 00	0.445819D 00	0.445819D 00	0.445819D 00	
5	0.1490307D 01	0.129167D 01	0.679900D 00	0.190307D 01	0.129167D 01	0.678660D 00	0.388391D 00	0.388391D 00	0.388391D 00	0.388391D 00	
6	0.195230D 01	0.138181D 01	0.643635D 00	0.195230D 01	0.138181D 01	0.643635D 00	0.349406D 00	0.349406D 00	0.349406D 00	0.349406D 00	
7	0.193749D 01	0.136351D 01	0.573797D 00	0.193749D 01	0.136351D 01	0.573036D 00	0.19864AD 00	0.19864AD 00	0.19864AD 00	0.19864AD 00	
STHM	MC2	MC2	MC/AZ	PRSA	7RSA	EFFSA	PRCA	PRCA	PRCA	PRCA	EFFCA
0.2242240 01	0.524280D 05	0.259491D 02	0.196809D 01	0.128679D 01	0.7462300 00	0.196809D 01	0.128679D 01	0.128679D 01	0.128679D 01	0.128679D 01	0.745001D 00
PO2A	TO2A	PH12	PS12	AREA2	AREA2	HPS	HPS	HPS	HPS	HPS	
0.2361380 02	0.598158D 03	0.481924D 00	0.599299D 00	0.137859D 02	0.135101D 02	0.169276D 03	0.169276D 03	0.169276D 03	0.169276D 03	0.169276D 03	
CP	GAMMA										
0.2394060 00	0.140141D 01										

TABLE IX - Continued

***** STATOR *****											
STRM	P02A	P03A	7023A	PS1	L5	DPO/P0	PERL3	R3	RAT		
1	0.246810D 02	0.741317D 02	0.587020D 03	0.205450D 02	0.428321D-01	0.200000D-01	0.193200D 01	0.710294D 00			
2	0.267447D 02	0.242698D 02	0.589525D 03	0.205450D 02	0.473975D-01	0.200000D-01	0.202262D 00	0.208181D 01	0.765371D 00		
3	0.239882D 02	0.234104D 02	0.591350D 03	0.205450D 02	0.545659D-01	0.200000D-01	0.315911D 00	0.222071D 01	0.816444D 00		
4	0.227995D 02	0.225395D 02	0.593618D 03	0.205450D 02	0.636718D-01	0.200000D-01	0.340276D 00	0.235222D 01	0.864787D 00		
5	0.210272D 02	0.225267D 02	0.603418D 03	0.205450D 02	0.685682D-01	0.200000D-01	0.495927D 00	0.247740D 01	0.910567D 00		
6	0.225225D 02	0.221903D 02	0.617590D 03	0.205450D 02	0.693617D-01	0.200000D-01	0.463252D 00	0.259464D 01	0.938980D 00		
7	0.214485D 02	0.222936D 02	0.630304D 03	0.205450D 02	0.763007D-01	0.200000D-01	0.365005D 00	0.270800D 01	0.995588D 00		
STRM	AL2	THE7A	A3	DAL2	SLO	OFAC7S	DP/QS	DEQUIV	DM3		
1	0.527777D 02	0.527777D 02	0.0	0.283770D 01	0.2288000 01	0.467748D 00	0.461186D 00	0.237240D 01	0.0		
2	0.505919D 02	0.505919D 02	0.0	0.227447D 01	0.213819D 01	0.615763D 00	0.597856D 00	0.233010D 01	0.749380D 00		
3	0.513956D 02	0.513956D 02	0.0	0.292286D 01	0.199927D 01	0.646177D 00	0.618125D 00	0.218934D 01	0.693979D 00		
4	0.531417D 02	0.537417D 02	0.0	0.656545D 01	0.186774D 01	0.710167D 00	0.680361D 00	0.252278D 01	0.586510D 00		
5	0.531510D 02	0.573151D 02	0.0	0.132331D 02	0.174326D 01	0.710446D 00	0.630559D 00	0.240903D 01	0.536741D 00		
6	0.506734D 02	0.606734D 02	0.0	0.175290D 02	0.162824D 01	0.664615D 00	0.646339D 00	0.212616D 01	0.579707D 00		
7	0.724388D 02	0.724388D 02	0.0	0.305188D 02	0.151200D 01	0.700787D 00	0.227735D 00	0.200550D 01	0.601540D 00		
STRM	AL2*	THE7A*	AL3*	DEV	EPS3	RC3	F-7ANG	F-AXIAL	R-STRESS		
1	0.499400D 02	0.499400D 02	0.0	0.0	0.0	0.1000000 01	0.4213800 01	0.0	0.0		
2	0.493017D 02	0.480174D 02	0.0	0.0	0.0	0.1000000 01	0.190488D 02	0.111057D 02	0.192460D 01		
3	0.647227D 02	0.464722D 02	0.0	0.0	0.0	0.1000000 01	0.182960D 02	0.979880D 01	0.208952D 01		
4	0.417621D 02	0.451176D 02	0.0	0.0	0.0	0.1000000 01	0.710446D 02	0.680361D 01	0.252278D 01		
5	0.440813D 02	0.440814D 02	0.0	0.0	0.0	0.1000000 01	0.129431D 02	0.115227D 02	0.842794D 01		
6	0.411444D 02	0.431444D 02	0.0	0.0	0.0	0.1000000 01	0.127651D 02	0.885125D 01	0.234950D 01		
7	0.421205D 02	0.423200D 02	0.0	0.0	0.0	0.1000000 01	0.138661D 02	0.104558D 02	0.254475D 01		
STRM	M2A	M3A	C2A	C3A	CX3	CU3	CR3	CU3	U3		
1	0.918187D 00	0.48H600 00	0.107770 04	0.567152D 03	0.567152D 03	0.0	0.567152D 03	0.0	0.991400 03		
2	0.920320D 00	0.492197D 00	0.101319D 04	0.522350D 03	0.522350D 03	0.0	0.522350D 03	0.0	0.103000 04		
3	0.814100D 00	0.435662D 00	0.915652D 03	0.509950D 03	0.509950D 03	0.0	0.509950D 03	0.0	0.104260 04		
4	0.751802D 00	0.365977D 00	0.453317D 03	0.515451D 03	0.431547D 03	0.0	0.531547D 03	0.0	0.115580D 04		
5	0.719229D 00	0.368379D 00	0.824724D 03	0.378760D 03	0.437876D 03	0.0	0.437876D 03	0.0	0.121700D 04		
6	0.714136D 00	0.416166D 00	0.829557D 03	0.498743D 03	0.498743D 03	0.0	0.498743D 03	0.0	0.127480D 04		
7	0.732466D 00	0.402931D 00	0.795985D 03	0.489872D 03	0.489872D 03	0.0	0.489872D 03	0.0	0.133700D 04		
STRM	PRS	TRS	EFFS	PRC	TRC	EFEC	MX3	GU2			
1	0.199896D 01	0.126499D 01	0.830916D 00	0.199896D 01	0.126499D 01	0.829519D 00	0.488220D 00	0.858221D 03			
2	0.000412D 01	0.128780D 01	0.822788D 00	0.000412D 01	0.126780D 01	0.821403D 00	0.492197D 00	0.782211D 03			
3	0.193470 01	0.127172D 01	0.765812D 00	0.193470 01	0.127172D 01	0.764530D 00	0.315662D 00	0.724203D 03			
4	0.186227D 01	0.127866D 01	0.705125D 00	0.186227D 01	0.127866D 01	0.705125D 00	0.365977D 00	0.688128D 03			
5	0.186507D 01	0.129767D 01	0.659593D 00	0.186507D 01	0.129767D 01	0.655500D 00	0.683790D 00	0.694131D 03			
6	0.191325D 01	0.132815D 01	0.622356D 00	0.191325D 01	0.132815D 01	0.621316D 00	0.416244D 00	0.722070D 03			
7	0.1489919D 01	0.136355D 01	0.555794D 00	0.1489919D 01	0.136355D 01	0.555680D 00	0.402931D 00	0.760547D 03			
WC43	MCR2	MC/A3	PRSA	TASA	EFFSA	PRCA	TACA	EFFCA			
0.253982D 01	0.523252D 05	0.313499D 02	0.192825D 01	0.120505D 01	0.712472D 00	0.192855D 01	0.120505D 01	0.711280D 00			
PO1A	103A	PM13	PS13	AREAS	CP	GAMMA					
0.2233352D 07	0.600085D 03	0.388298D 00	0.281759D 00	0.116416D 02	0.113117D 02	0.240299D 00	0.139932D 01				

TABLE IX - Continued

SYSTEM ROTOR 200000											
	POLR	PO2R	701R	702R	P32	IR	PFR12	R2	R/R		
1	0.545220 02	0.3203260 02	0.3443040 02	0.4613010 03	0.4765620 03	0.2701290 02	0.4114530 00	0.1500000-01	-0.209450 01	0.7718570 00	
2	0.3942700 02	0.3443040 02	0.3764950 03	0.4681180 03	0.2776870 02	0.3833490 00	0.1956680 00	0.2213270 01	0.8137030 00		
3	0.4026190 02	0.3537620 02	0.4690180 03	0.4996480 03	0.2824500 02	0.34040470 00	0.2364860 00	0.2308990 01	0.8532670 00		
4	0.4110530 02	0.3512250 02	0.4951020 03	0.7150140 03	0.2814490 02	0.3412430 00	0.5934660 00	0.2424320 01	0.8912970 00		
5	0.4372160 02	0.3495600 02	0.7270180 03	0.7317150 03	0.2921950 02	0.3780500 00	0.6816160 00	0.2523940 01	0.9277750 00		
6	0.4630250 02	0.3423270 02	0.7529330 03	0.759270 03	0.2964470 02	0.3720800 00	0.8387860 00	0.2613440 01	0.9426600 00		
7	0.4774940 02	0.3499630 02	0.7617930 03	0.7820700 03	0.3000860 02	0.32329970 00	0.9850000 00	0.2710550 01	0.9965220 00		
SYSTEM	BL1	BL2	THETA	BL1	BL2	SL0	DEACTA	BL1	DEQUIV	BL2	
1	0.5914630 02	0.3327870 02	0.2536740 02	0.5816260 01	0.2390400 01	0.2347700 00	0.3972540 00	0.198630 01	0.0	0.0	
2	0.6077170 02	0.2670780 02	0.1380290 02	0.4923540 01	0.2274770 01	0.5145250 00	0.3812750 00	0.1974260 01	0.7146500 00		
3	0.6495270 02	0.2981910 02	0.3997090 02	0.7306130 01	0.2155550 01	0.518270 00	0.3905420 00	0.173400 01	0.7074500 00		
4	0.6952640 02	0.2360490 02	0.5572190 02	0.1020490 02	0.2040360 01	0.9445300 00	0.3987960 00	0.202160 01	0.6580750 00		
5	0.1021230 02	0.1915790 02	0.3103440 02	0.9372660 01	0.1959590 01	0.5938720 00	0.3811820 00	0.2179130 01	0.5105960 00		
6	0.6861570 02	0.1327530 02	0.5336060 02	0.46442480 01	0.1863180 01	0.5722990 00	0.3532240 00	0.2121980 01	0.5403760 00		
7	0.6479794 02	0.1217060 02	0.5726280 02	0.4367400 01	0.1794900 01	0.5405510 00	0.3478930 00	0.2059870 01	0.5391110 00		
SYSTEM	BL1	BL2	THETA	BL1	BL2	DEV	EP32	RC2	F-AXIAL	A-STRESS	
1	0.5333000 02	0.2279000 02	0.2954000 02	0.2954000 02	0.2672590 01	0.0	0.1000000 01	0.0	0.0	0.0	
2	0.5595010 02	0.2044280 02	0.3540730 02	-1.6064490 01	0.0	0.1000000 01	0.1000000 01	0.1151540 02	0.2081630 01		
3	0.5766460 02	0.1957280 02	0.4072780 02	-10.56680 00	0.0	0.1000000 01	0.1000000 01	0.1287040 02	0.2209170 01		
4	0.5932190 02	0.1927490 02	0.4474940 02	0.7444460 02	0.3609790 01	0.0	0.1000000 01	0.149210 02	0.2329540 01		
5	0.6083970 02	0.1339510 02	0.7444460 02	0.5347490 02	0.3017490 01	0.0	0.1000000 01	0.1219310 02	0.2444210 01		
6	0.6219320 02	0.1184530 02	0.5336060 02	0.46442480 01	0.1863180 01	0.0	0.1000000 01	0.1565860 02	0.2553310 01		
7	0.6343000 02	0.1058000 02	0.5289500 02	0.4776780 01	0.0	0.1000000 01	0.1000000 01	0.1507720 02	0.2657790 01		
SYSTEM	M1R	M2R	W1R	M2R	C12	W2R	W32	CM2	U2		
1	0.9520590 00	0.5355100 00	0.11050890 00	0.6638790 03	0.59736420 03	0.2094440 03	0.59736420 03	0.59736420 03	0.1031660 00	0.1031660 00	
2	0.1008060 01	0.5476980 00	0.1172220 00	0.7014360 03	0.58187670 03	0.3935720 03	0.5078470 03	0.5078470 03	0.1087600 00	0.1087600 00	
3	0.1029501 01	0.5481730 00	0.6204540 04	0.6204540 04	0.5546600 03	0.4653360 03	0.5546600 03	0.5546600 03	0.1140400 04	0.1140400 04	
4	0.1046440 01	0.5641700 00	0.1233810 00	0.7117580 03	0.50103970 03	0.51308860 03	0.50103970 03	0.50103970 03	0.1191310 04	0.1191310 04	
5	0.1088150 01	0.5612810 00	0.1293440 00	0.6974390 03	0.4833980 03	0.5424280 03	0.4833980 03	0.4833980 03	0.1240000 04	0.1240000 04	
6	0.1142650 01	0.5601330 00	0.1349060 04	0.7565710 03	0.4515660 03	0.6010770 03	0.4515660 03	0.4515660 03	0.1276690 04	0.1276690 04	
7	0.1166160 01	0.6235440 00	0.1417940 04	0.6223140 03	0.4407760 03	0.6922690 03	0.4407760 03	0.4407760 03	0.1331980 04	0.1331980 04	
SYSTEM	PRS	7RS	EFFS	PRC	TAC	EFFFC	EFFSA	CM2/CM1			
1	0.1650370 01	0.1217010 01	0.7082340 00	0.3269010 01	0.1538610 01	0.7511610 00	0.4916150 00	0.103270 01			
2	0.1627170 01	0.1213430 01	0.492180 00	0.3205050 01	0.1534390 01	0.7455480 00	0.4717350 00	0.1027040 01			
3	0.1667680 01	0.1217240 01	0.1226740 01	0.1233180 00	0.3228560 01	0.1547990 01	0.7238000 00	0.44417920 00	0.1016660 01		
4	0.1714980 01	0.1226740 01	0.1226740 01	0.12339170 00	0.3194460 01	0.1566050 01	0.6932720 00	0.3952870 00	0.1161160 01		
5	0.1704540 01	0.1239130 01	0.1239130 01	0.48870800 00	0.3178920 01	0.1607990 01	0.6426300 00	0.3402600 00	0.1001190 01		
6	0.1666910 01	0.1226240 01	0.1226240 01	0.6445160 00	0.3189220 01	0.1641810 01	0.6166950 00	0.3462150 00	0.903890 00		
7	0.1648190 01	0.1223250 01	0.1223250 01	0.6864780 00	0.3130140 01	0.1617920 01	0.5758230 00	0.3338850 00	0.9010440 00		
WCR2	TO2A	MC/A2	PHSA	TRSA	AREA2	PRCA	EFFCA				
0.1683600 01	0.4313230 03	0.25466640 02	0.1667910 01	0.12233370 01	0.7036580 00	0.3216650 01	0.1578770 01	0.6831920 00			
CP	GAMMA										
0.2402990 00	0.1399320 01										

TABLE IX - Continued

***** STATOR *****											
STR#	P02A	P01A	Tn23A	PS3	Z5	DPO/P0	PERL3	R3	R/RPT		
1	0.39910400 02	0.38228100 02	0.71534600 03	0.33900400 02	0.13017200 00	0.420850-01	0.15000000-01	0.210317D	01	0.80261380 00	
2	0.39455300 02	0.38143100 02	0.71534600 03	0.33900400 02	0.11158600 00	0.32800000 00	0.328630 00	0.83848360 00			
3	0.394130 02	0.37922900 02	0.71918160 03	0.33904040 02	0.10359400 00	0.2846780-01	0.3620820 00	0.237230 01	0.87261820 00		
4	0.3865470 02	0.37666600 02	0.77821200 03	0.33904040 02	0.997118D-01	0.246173D	00	0.246173D	01	0.90546800 00	
5	0.386480 02	0.37566900 02	0.78771600 03	0.33904040 02	0.976470-01	0.232663D-01	0.683140 00	0.25478900 00			
6	0.3878960 02	0.37765400 02	0.76348800 03	0.33904040 02	0.92136400-01	0.2135880-01	0.68319400 00	0.25478900 01			
7	0.3787460 02	0.37129900 02	0.77558300 03	0.33904040 02	0.94666900-01	0.196210-01	0.98300000 00	0.24309400 01	0.962570 00		
STR#	AL2	THE7A*	THETA	AL3	DLA2	SLO	DFACTS	OP/OS	OP/DLV	OM3	
1	0.5116330 02	0.5116430 02	0.0	0.421250 01	0.2292500 01	0.498090 00	0.533550 00	0.2224780 01	0.0	0.6663240 00	
2	0.497330 02	0.497350 02	0.0	0.3747800 01	0.2203670 01	0.590790 00	0.532940 00	0.2157890 01	0.0	0.6663240 00	
3	0.5011190 02	0.5011190 02	0.0	0.5489920 01	0.2118940 01	0.5896190 00	0.523860 00	0.2127890 01	0.0	0.648490 00	
4	0.5350910 02	0.5350930 02	0.0	0.9167100 01	0.2036940 01	0.5970010 00	0.5222970 00	0.210750 01	0.0	0.6290820 00	
5	0.5785640 02	0.5785640 02	0.0	0.1421750 02	0.1957800 01	0.602746 00	0.5139600 00	0.2054540 01	0.0	0.6071920 00	
6	0.56440170 02	0.56440170 02	0.0	0.1481710 01	0.1881710 01	0.5796110 00	0.4824800 01	0.1978170 01	0.0	0.602370 00	
7	0.5530540 02	0.5530540 02	0.0	0.1290540 02	0.1607500 01	0.50202230 00	0.50202230 00	0.1604010 00	0.0	0.5877890 01	
STR#	AL2*	THE7A*	AL3*	0EV	EPS3	RC3	F-TANG	F-AXIAL	A-STRESS		
1	0.449500 02	0.448500 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0	0.0	
2	0.4598720 02	0.4598720 02	0.0	0.0	0.0	0.1000000 01	0.1487020 C2	-1.7988540 01	0.2193970 01		
3	0.4512260 02	0.4512260 02	0.0	0.0	0.0	0.1000000 01	0.1379930 D2	-7.447130 01	0.2296420 01		
4	0.443434220 02	0.443434220 02	0.0	0.0	0.0	0.1000000 01	0.1322690 02	-7.339590 01	0.2394820 01		
5	0.4363690 02	0.4363690 02	0.0	0.0	0.0	0.1000000 01	0.297510 02	-7.77930 01	0.248490 01		
6	0.4299540 02	0.4299540 02	0.0	0.0	0.0	0.1000000 01	0.1301860 02	-7.780490 01	0.2580230 01		
7	0.4240000 02	0.4240000 02	0.0	0.0	0.0	0.1000000 01	0.1202380 02	-7.7029050 01	0.2667940 01		
STR#	M2*	M3A	C2A	C3A	Cx3	CM3	CM3	CR3	U3		
1	0.764939	0.4152920 03	0.9525930 03	0.5352070 03	0.5352070 03	0.5352070 03	0.5352070 03	0.0	0.107810 04		
2	0.7298170 00	0.4108420 00	0.9095290 03	0.5296560 03	0.5296560 03	0.5296560 03	0.5296560 03	0.0	0.1120390 04		
3	0.6962070 00	0.400310 00	0.8740730 03	0.5181070 03	0.5181070 03	0.5181070 03	0.5181070 03	0.0	0.1163760 04		
4	0.65445540 00	0.3816230 00	0.8424110 03	0.5051000 03	0.5051000 03	0.5051000 03	0.5051000 03	0.0	0.1206190 04		
5	0.63394620 00	0.3828580 00	0.8239430 03	0.5055520 03	0.50554520 03	0.5054520 03	0.5054520 03	0.0	0.125080 04		
6	0.6256220 00	0.3952680 00	0.8159220 03	0.5235910 03	0.5235910 03	0.5235910 03	0.5235910 03	0.0	0.129840 04		
7	0.5865500 00	0.3594000 00	0.7743760 03	0.48481070 03	0.48481070 03	0.48481070 03	0.48481070 03	0.0	0.1332580 04		
STR#	PAS	TAS	EFFS	PAC	TAC	EFFC	MM3	CU2			
1	0.1580910 01	0.1217010 01	0.6434050 00	0.3160170 01	0.1938410 01	0.7213150 00	0.4192920 00	0.1420210 03			
2	0.1577920 01	0.1213430 01	0.6446450 00	0.3152320 01	0.1538360 01	0.7195110 00	0.4104420 00	0.1440240 03			
3	0.161992 01	0.1217240 01	0.6793210 00	0.3134120 01	0.1547990 01	0.7027210 00	0.4001030 00	0.1555410 03			
4	0.1671140 01	0.1226740 01	0.6964020 00	0.31112940 01	0.1575540 01	0.6762320 00	0.3876230 00	0.1774250 03			
5	0.1664400 01	0.1239139 01	0.65474010 00	0.31048470 01	0.16079791 01	0.64272940 00	0.3826580 00	0.1776340 03			
6	0.1631310 01	0.1236246 01	0.6344370 00	0.3121110 01	0.1641910 01	0.5973360 00	0.3955680 00	0.1797160 03			
7	0.1645790 01	0.1223250 01	0.6572880 00	0.3068590 01	0.1667920 01	0.5640860 00	0.3594000 00	0.1634880 03			
STR#	MCR2	MC/A3	PSA	TRSA	EFFSA	PRCA	TRCA	EFFCA			
0.1734460 01	0.4728110 05	0.298000 02	0.1620740 01	0.1226030 01	0.4536760 00	0.3125720 01	0.1582190 01	0.6596220 00			
PO3A	U3A	PH13	PS13	AREE3	CP	GAMMA					
0.1782120 02	0.7357209 03	0.4239330 00	0.4135440 00	0.3101020 01	0.312930 01	0.2421920 00	0.1394940 01				

TABLE X
COMPUTER OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - REDESIGN -
TEST NUMBER 17

***** INLET *****									
RPM = 0.5444000 05									RAT
FLOW = 0.4147000 01									
STAN	PUL	T01	PS	T5	A1	EPS1	PBL	R1	RAT
1	0.1316000 02	0.4670000 03	0.1117280 02	0.4456100 03	0.0	0.0	0.5000000 02	0.1346000 01	0.4951840 00
2	0.1314000 02	0.4470000 03	0.1117280 02	0.4456100 03	0.0	0.0	0.2285730 00	0.1655430 01	0.408140 00
3	0.1314000 02	0.4470000 03	0.1117280 02	0.4456100 03	0.0	0.0	0.4195290 00	0.1913430 01	0.7036670 00
4	0.1316000 02	0.4670000 03	0.1117280 02	0.4456100 03	0.0	0.0	0.5810510 00	0.2161850 01	0.7874450 00
5	0.1316000 02	0.4670000 03	0.1117280 02	0.4456100 03	0.0	0.0	0.7305480 00	0.2148110 01	0.8427910 00
6	0.1316000 02	0.4670000 03	0.1117280 02	0.4456100 03	0.0	0.0	0.8671390 00	0.2536630 01	0.932920 00
7	0.1316000 02	0.4470000 03	0.1117280 02	0.4456100 03	0.0	0.0	0.9950000 00	0.2713100 01	0.9974630 00
STAN	CRL	CUI	CRI	CML	U1	CAL	MIA	ML1	RC
1	0.5063140 03	0.0	0.0	0.5063140 03	0.4641910 03	0.5063140 03	0.4800420 00	0.0	0.1000000 01
2	0.5063140 03	0.0	0.0	0.5063140 03	0.4641910 03	0.5063140 03	0.4800420 00	0.1000000 01	
3	0.5063140 03	0.0	0.0	0.5063140 03	0.4642250 03	0.5063140 03	0.4800420 00	0.4883900 00	0.1000000 01
4	0.5063140 03	0.0	0.0	0.5063140 03	0.1094930 04	0.5063140 03	0.4800420 00	0.4925340 00	0.1000000 01
5	0.5063140 03	0.0	0.0	0.5063140 03	0.1156940 04	0.5063140 03	0.4800420 00	0.4925340 00	0.1000000 01
6	0.5063140 03	0.0	0.0	0.5063140 03	0.1259380 04	0.5063140 03	0.4800420 00	0.4881800 00	0.1000000 01
7	0.5063140 03	0.0	0.0	0.5063140 03	0.1336290 04	0.5063140 03	0.4800420 00	0.4925340 00	0.1000000 01
	MCAL	MCAL	MCAL	POA	POA	PHI	MUB/TIP	AREA	AREAF
	0.4395370 01	0.5948220 05	0.1575860 02	0.1310000 02	0.4670000 03	0.5063060 00	0.4926470 00	0.1760170 02	0.1762570 02
	CO	GAMMA							
	0.2394120 00	0.1601390 01							

TABLE X - Continued

***** RUTUR *****											
***** LEESES *****											
ITEM	P01R	P02K	T01R	T02R	P52	ZR	PERL2	R2	R/A1		
1	0.1714070 J2	0.1826600 02	0.2033710 03	0.226240 03	0.1426240 02	0.3450840 00	0.1744590 01	0.1744590 01	0.644890 00		
2	0.194350 J2	0.1966090 02	0.2224220 03	0.5431620 03	0.1557510 02	0.3180590 00	0.2078790 00	0.193970 01	0.7131470 00		
3	0.2200850 02	0.2080220 02	0.5611090 03	0.5576120 03	0.1647850 02	0.3259310 00	0.3885820 00	0.2115750 01	0.7778610 00		
4	0.2478850 02	0.2187190 02	0.5548660 03	0.5721490 03	0.1715220 02	0.3574210 00	0.4524770 00	0.2279190 01	0.8379380 00		
5	0.2740030 02	0.2261700 02	0.5786100 03	0.5868466 03	0.177080 02	0.393770 00	0.7012497 00	0.2231440 01	0.8539860 00		
6	0.3104430 02	0.2365230 02	0.5972420 03	0.6011370 03	0.1821950 02	0.416580 00	0.8520270 00	0.2574220 01	0.946140 00		
7	0.3460450 02	0.2174440 02	0.6159940 03	0.6156740 03	0.1872950 02	0.4607220 00	0.9900000 00	0.2710130 01	0.9633790 00		
STRM	M1	M1	H2	UB1	SLO	OFACR	OP/QR	OP/U/V	OM2		
1	0.5766310 02	0.5324740 02	-0.190580 00	0.8151350 01	0.2394000 01	0.3871710 00	0.5215150 00	0.1593410 01	0.0		
2	0.5816070 02	0.436230 02	0.2275280 02	0.7886800 01	0.2275270 01	0.4740110 00	0.5303550 00	0.1807610 01	0.812060 00		
3	0.6173330 02	0.3255320 02	0.4930000 02	0.7588840 01	0.2168050 01	0.5199100 00	0.4868820 00	0.1957750 01	0.7870400 00		
4	0.6416130 02	0.2321100 02	0.4115130 02	0.7326600 01	0.2068510 01	0.5451990 00	0.439240 00	0.2044770 01	0.7311610 00		
5	0.6655510 02	0.1728420 02	0.4917660 02	0.691690 01	0.1975630 01	0.5798380 00	0.3928460 01	0.653050 00	0.633050 00		
6	0.6733160 02	0.1511160 02	0.2828200 02	0.683850 01	0.1861760 01	0.6062510 00	0.3562560 00	0.2221220 01	0.607980 00		
7	0.6924450 02	0.1122000 02	0.3802850 02	0.6718500 01	0.1806000 01	0.6572590 00	0.3289040 00	0.2389070 01	0.5549810 00		
STRM	M1	M1	H2	DFV	EPS2	AC2	F-TANG	F-AITAL	R-STRESS		
1	0.4444700 U2	0.3512000 U2	0.9170000 01	-0.9004040 01	0.1000000 01	0.1000000 01	0.0	0.0	0.0		
2	0.5027390 U2	0.2783100 02	0.7744080 02	-0.7912520 01	0.0	0.1000000 01	-0.2094820 02	0.2	0.1471740 01		
3	0.5416640 U2	0.2165040 02	0.3251360 02	-0.3213600 01	0.0	0.1000000 01	-0.1831100 02	-0.1345650 02	0.1906100 01		
4	0.5703470 02	0.1703340 02	0.1703130 02	0.1149560 01	0.0	0.1000000 01	-0.439240 00	0.439240 00	0.2112560 01		
5	0.5925940 02	0.1357150 02	0.5956480 02	0.3349010 01	0.0	0.1000000 01	-0.1372450 02	-0.1523230 02	0.2302120 01		
6	0.6104530 U2	0.1089680 02	0.60014910 02	0.2619460 01	0.0	0.1000000 01	-0.100510 02	-0.1597690 02	0.2472670 01		
7	0.6253300 02	0.8700000 01	0.53175000 02	0.4276480 01	0.0	0.1000000 01	-0.1266450 02	-0.169420 02	0.2633540 01		
STRM	M14	M14	M2W	WIR	EPS2	CR2	CR2	CR2	CR2		
1	0.8060950 JJ	0.5981600 00	0.8454510 03	0.6514960 03	0.6514960 03	-0.72626240 01	0.6214550 03	0.0	0.8593940 03		
2	0.9270640 00	0.5863490 00	0.5959760 03	0.6462030 03	0.6462030 03	0.1626080 03	0.6214760 03	0.0	0.9553940 03		
3	0.1031370 01	0.3881380 00	0.5492780 04	0.658050 03	0.658050 03	0.3214290 03	0.3214290 03	0.0	0.102090 04		
4	0.1130270 01	0.5399520 00	0.1170140 04	0.6715150 03	0.6715150 03	0.4469150 03	0.5113830 03	0.0	0.112570 04		
5	0.1219500 01	0.6025320 00	0.2625210 04	0.6910190 03	0.6910190 03	0.5226500 03	0.4266500 03	0.0	0.197640 04		
6	0.1321240 01	0.6136330 00	0.1348080 03	0.7114670 03	0.4298750 03	0.5666150 03	0.4298750 03	0.0	0.1261900 04		
7	0.1403100 01	0.5119930 00	0.1429490 04	0.6982190 03	0.3686410 03	0.5906110 03	0.3686410 03	0.0	0.1339840 04		
STRM	PRS	PRS	PRS	PRC	TRC	EFFC	MX2	MX2	CR2/CR1		
1	0.2043950 01	0.1266150 01	0.1256360 00	0.207960 01	0.1266150 01	0.8549130 00	0.5911230 00	0.128660 01			
2	0.2043550 01	0.1270660 01	0.1135750 00	0.2045480 01	0.1270660 01	0.8321790 00	0.5676000 00	0.123900 01			
3	0.1451770 01	0.1269360 01	0.1866210 00	0.1951370 01	0.1268360 01	0.7853330 00	0.5113670 00	0.1131320 01			
4	0.1449030 01	0.1211040 01	0.188030 00	0.1698600 01	0.1211040 01	0.7317790 00	0.4513720 00	0.1010010 01			
5	0.1442740 01	0.1289120 01	0.18869120 00	0.1862240 01	0.12892120 01	0.4517740 00	0.3966840 00	0.1940090 00			
6	0.1936930 01	0.1317600 01	0.6563640 00	0.1936690 01	0.1317600 01	0.6552720 00	0.307630 00	0.490380 00			
7	0.1945440 01	0.1555000 01	0.6114730 00	0.1955480 01	0.1355500 01	0.610520 00	0.3134090 00	0.7280860 00			
4CH	NC42	NC42	MC42	PKSA	TRSA	EFFSA	PRCA	REGA	EFFCA		
1	0.2467510 U1	0.5248980 05	0.2666200 02	0.1955860 01	0.1284260 01	0.7452300 00	0.1955850 01	0.1284260 01	0.7439890 00		
2	PU2A	TU2A	PM12	PS12	AREA2	AREE2	MPS				
3	0.2573910 U2	0.55497500 U3	0.40392400	0.5930420 00	0.137890 02	0.1351010 02	0.1864980 03	0.1867010 03			
CP	GAMMA	J.2144170 U3	0.10131390 01								

TABLE X - Continued

STATOR											
10000											

STRN	PU24	P036	T0236	PS3	LS	DPD/PD	PERL3	R3	R/A1	R/A2	R/A3
1	0.2695110	02	0.264110	02	0.5917930	03	0.2205410	02	0.4231120-01	0.2000000-01	0.1932000
2	0.2677510	02	0.262190	02	0.5933940	03	0.2205410	02	0.4781270-01	0.2022220	0.0
3	0.2568530	02	0.2517160	02	0.5923240	03	0.2205430	02	0.4557910-01	0.2000000	0.0
4	0.24446970	02	0.2437330	02	0.5935750	03	0.2205430	02	0.6443630-01	0.2000000	0.0
5	0.2477030	02	0.2427790	02	0.6020170	03	0.2205430	02	0.7015240-01	0.2000000	0.0
6	0.2548940	02	0.2497970	02	0.6133200	03	0.2205430	02	0.7012310-01	0.2000000	0.0
7	0.2612900	02	0.2566440	02	0.6321630	03	0.2205430	02	0.7062510-01	0.2000000	0.0
STRN	AL2	TH16	TH16	AL3	062	SL0	OFAC5	OP/QS	DEQIV	043	043
1	0.5066940	02	0.5306640	02	0.0	0.3128390	01	0.2288000	01	0.4338280	03
2	0.5133940	02	0.5161300	02	0.0	0.3621580	01	0.2138190	01	0.4021180	00
3	0.5122240	02	0.5152240	02	0.0	0.5069730	01	0.1999270	01	0.3784940	00
4	0.5207910	02	0.5207910	02	0.0	0.7702970	01	0.1867783	01	0.2273810	01
5	0.5617550	02	0.5617550	02	0.0	0.1209410	02	0.1743220	01	0.2415400	01
6	0.5866150	02	0.58466150	02	0.0	0.1533710	02	0.1625940	01	0.2355970	01
7	0.61646840	02	0.63646840	02	0.0	0.2132860	02	0.1512000	01	0.2270500	01
STRN	AL2*	1MTIA*	1MTIA*	AL3*	QFV	EP33	AC3	F-TANG	F-AXIAL	R-STRESS	R-STRESS
1	0.4986030	02	0.4994000	02	0.0	0.0	0.0	0.1000000	01	0.2127450	02
2	0.4891740	02	0.49011740	02	0.0	0.0	0.0	0.1000000	01	0.2089220	01
3	0.4681270	02	0.4647270	02	0.0	0.0	0.0	0.1000000	01	0.203010	01
4	0.4517620	02	0.4517620	02	0.0	0.0	0.0	0.1000000	01	0.2241980	01
5	0.4606140	02	0.4606140	02	0.0	0.0	0.0	0.1000000	01	0.2394650	01
6	0.4314440	02	0.4314440	02	0.0	0.0	0.0	0.1000000	01	0.2419310	01
7	0.4212030	02	0.42320200	02	0.0	0.0	0.0	0.1000000	01	0.24463750	01
STRN	M2A	M1A	C2A	C3A	C4A	C5A	C6A	C7A	C8A	C9A	C10A
1	0.9354420	03	0.5139850	03	0.1084200	04	0.5972190	03	0.5472390	03	0.51972390
2	0.9145740	03	0.5042640	03	0.5874600	04	0.5876000	03	0.5876000	03	0.5876000
3	0.8219590	03	0.4395210	03	0.9205950	03	0.5136000	03	0.5136000	03	0.5136000
4	0.7619250	03	C.3601860	03	0.46474650	03	0.4483460	03	0.4483460	03	0.4483460
5	0.7090370	03	0.3125740	03	0.8131860	03	0.4422130	03	0.4422130	03	0.4422130
6	0.7092220	03	0.3254200	03	0.8222960	03	0.5083750	03	0.5083750	03	0.5083750
7	0.7090740	03	0.46666370	03	0.93032440	03	0.5633500	03	0.5633500	03	0.5633500
STRN	PAS	TRs	EFFS	PAC	TAC	EFFC	M3	C12	C13	C14	C15
1	0.2001000	01	0.1266150	01	0.8291290	00	0.2007000	04	0.1266150	01	0.139050
2	0.1493830	01	0.1270640	01	0.8074980	00	0.1993890	01	0.1270660	01	0.8666610
3	0.1912740	01	0.1268360	01	0.7603340	00	0.1912740	01	0.1268360	01	0.7927860
4	0.1852000	01	0.1271040	01	0.7122550	00	0.1852000	01	0.1271040	01	0.7206410
5	0.1644590	01	0.1289120	01	0.6429200	00	0.1644590	01	0.1289120	01	0.6755360
6	0.1398150	01	0.1317600	01	0.6344100	00	0.1398150	01	0.1317600	01	0.70998
7	0.1495780	01	0.1355500	01	0.59161970	00	0.1945740	01	0.1355500	01	0.7442240
STRN	MCR3	MCA2	MC/43	PH56	TAS6	EFFSA	PRC6	TAC4	EFFC4	PRC6	EFFC4
0.25598420	01	0.52444030	05	0.3208590	02	0.1918700	01	0.7159890	00	0.1918700	01
PU3A	703A	PH13	PS13	ARE63	CP	GM63	CP	GM63	CP	GM63	CP
0.2525010	02	0.6008620	03	0.4012250	00	0.57666030	00	0.11311170	02	0.2403960	00
						0.5506950	03	0.5506950	03	0.7442240	03

TABLE X - Continued

TABLE X - Continued

STHM	P01H	PU2R		7D1R		102R		PS2		RA		PERAL2		R2		RA7			
		0.3518710	02	0.4468470	03	0.4504000	03	0.2550680	02	0.4385340	00	0.1500000	-01	0.2094430	01	0.771570	00		
1	0.4019150	02	0.3698240	02	D.6911250	D3	D.6925110	D3	D.2566930	D2	D.2516150	D2	D.1534440	D0	D.2213270	D1	D.8133030	D0	
2	0.4246850	02	0.3698240	02	D.3787520	D2	D.4992150	D3	D.7013240	D3	D.2616150	D2	D.1534440	D0	D.2220860	D0	D.8053260	D0	
3	0.4335760	02	D.3923230	D2	D.7540780	02	D.7055720	D3	D.7125170	D3	D.2617440	D2	D.1594810	D0	D.2944330	D1	D.8915900	D0	
4	0.4456310	02	D.3802320	D2	D.7540780	02	D.7125170	D3	D.7304940	03	D.2617440	D2	D.1594810	D0	D.2977330	D0	D.8915900	D0	
5	0.447180	02	D.3923230	D2	D.7540780	02	D.7125170	D3	D.7304940	03	D.2617440	D2	D.1594810	D0	D.2977330	D0	D.8915900	D0	
6	0.5022350	02	D.3977800	02	D.7515870	03	D.7515870	03	D.7515870	02	D.2675120	D2	D.3445320	D0	D.6881620	D0	D.9264600	D0	
7	0.5344080	02	D.3975110	02	D.7612220	D3	D.7615000	D3	D.7690630	D2	D.2675120	D2	D.3445320	D0	D.6881620	D0	D.9264600	D0	
STHM	A1	IM7A		B2	081		540		DFACTR		OP/QR		DEQIV		Q042				
1	0.5718620	02	D.244050	02	D.3114570	D2	D.4555620	D1	D.2590400	D1	D.2274770	D1	D.3460170	D0	D.93570	D0	D.174740	D1	
2	D.021850	D2	C.1904240	D2	D.4108980	D2	D.4333900	D1	D.2274770	D1	D.2274770	D0	D.1869220	D0	D.1548870	D1	D.8271440	D0	
3	0.6484680	D2	D.1831160	D2	D.4655340	D2	D.7200980	D1	D.2165450	D1	D.2197370	D0	D.1915850	D0	D.1542330	D1	D.782250	D0	
4	0.6845580	D2	D.1684860	D2	D.4902880	D2	D.5343490	D1	D.2030560	D1	D.3922540	D0	D.1919330	D0	D.1576890	D1	D.672400	D0	
5	0.707110	D2	D.144950	D2	D.55597900	D2	D.9234390	D1	D.1959580	D1	D.3409840	D0	D.1822860	D0	D.1571940	D1	D.6575450	D0	
6	0.8010670	D2	D.1046210	D2	D.5784460	D2	D.6113140	D1	D.1863100	D1	D.3701120	D0	D.1647400	D0	D.1620860	D1	D.6262740	D0	
7	0.8370950	D2	D.1866510	D1	D.64263200	D2	D.76665940	D1	D.1769400	D1	D.3944600	D0	D.1545910	D0	D.1644580	D1	D.5414420	D0	
STHM	M1R	THE7A		B2*	DEV		EPS2		RC2		F-TANG		D-D		F-AXIAL		B-STRESS		
1	0.5133100	02	D.7379000	02	D.2954000	D2	D.3885170	D1	D.0	D.1000000	D1	D.0	D.1371160	D2	D.8448440	D1	D.2081630	D1	
2	0.552010	02	D.2046240	D2	D.3340710	D2	D.5682470	D1	D.0	D.1000000	D1	D.0	D.1371160	D2	D.8448440	D1	D.220270	D1	
3	0.5164660	D2	D.1757290	D2	D.4902730	D2	D.6461150	D1	D.0	D.1000000	D1	D.0	D.1039120	D2	D.970910	D1	D.232564	D1	
4	0.5932190	D2	D.1339510	D2	D.4404460	D2	D.7966230	D1	D.0	D.1000000	D1	D.0	D.9365310	D1	D.9755650	D1	D.244210	D1	
5	0.6083970	D2	D.1339510	D2	D.4744460	D2	D.8134680	D1	D.0	D.1000000	D1	D.0	D.7265370	D1	D.8633240	D1	D.553330	D1	
6	0.6219120	D2	D.1186530	D2	D.5034700	D2	D.7498700	D1	D.0	D.1000000	D1	D.0	D.7498700	D1	D.7076710	D1	D.2657900	D1	
7	0.6343000	D2	D.1050000	D2	D.5285000	D2	D.1238700	D2	D.0	D.1000000	D1	D.0	D.7466890	D1	D.7076710	D1	D.2657900	D1	
STHM	M2R	W2R		M1R	W2R		CR2		W02		CM2		CR2		W2		CM2		
1	0.966070	D0	D.69398690	00	D.1123410	D4	D.87476690	D3	D.7072150	D3	D.44677670	D3	D.7072150	D3	D.0	D.103050	D4	D.103050	D4
2	0.1014460	D1	D.7379180	D0	D.1181600	D4	D.98972740	D3	D.8377510	D3	D.6777510	D3	D.6777510	D3	D.0	D.109510	D4	D.1143110	D4
3	0.1313120	D1	D.7476560	D0	D.1208360	D4	D.9203260	D3	D.6331030	D3	D.6779610	D3	D.6331030	D3	D.0	D.1152720	D4	D.1143110	D4
4	0.1054540	D1	D.7624880	D0	D.1242160	D4	D.9218670	D3	D.5674622	D3	D.5676530	D3	D.5676530	D3	D.0	D.1190660	D4	D.1143110	D4
5	0.1093220	D1	D.7600000	D0	D.1297550	D4	D.9635580	D3	D.5466646	D3	D.7948440	D3	D.5466646	D3	D.0	D.1242220	D4	D.1143110	D4
6	0.1150870	D1	D.7748500	D0	D.1375330	D4	D.98531750	D3	D.5244340	D3	D.8342260	D3	D.5244340	D3	D.0	D.1289460	D4	D.1143110	D4
7	0.114990	D1	C.7681540	D0	D.1447930	D4	D.9953170	D3	D.4170050	D3	D.9030400	D3	D.4170050	D3	D.0	D.1330303	D4	D.1330303	D4
STHM	PRS	7RA		EFFF5	TRC		PAC		TAC		EFFEC		MX2		CM2/CH1		CM2		
1	0.1392650	D1	D.1165410	01	D.5989810	D0	D.27794650	D1	D.1475590	D1	D.7168810	D0	D.57792040	D1	D.1184140	D1	D.1184140	D1	
2	0.1351310	D1	D.1153090	01	D.5860410	D0	D.2694400	D1	D.1445190	D1	D.7030060	D0	D.5527020	D0	D.1152720	D0	D.1152720	D0	
3	0.1371360	D1	D.1153080	01	D.6160280	D0	D.2623050	D1	D.1422530	D1	D.6851490	D0	D.51613220	D0	D.1222450	D1	D.1222450	D1	
4	0.1217160	D1	D.1157070	D1	D.6009520	D0	D.2546050	D1	D.1476380	D1	D.6476520	D0	D.4570370	D0	D.1245500	D1	D.1245500	D1	
5	0.135760	D1	D.1154580	D1	D.5899220	D0	D.2503600	D1	D.1488380	D1	D.6132390	D0	D.43463620	D0	D.1231690	D1	D.1231690	D1	
6	0.1151620	D1	D.1154580	D1	D.5044890	D0	D.2489650	D1	D.1527800	D1	D.5635160	D0	D.4122890	D0	D.1031590	D1	D.1031590	D1	
7	0.1216950	D1	D.1152130	D1	D.3787920	D0	D.23263700	D1	D.1561140	D1	D.4971800	D0	D.3218140	D0	D.7460210	D0	D.7460210	D0	
STHM	MCR2	MC/2		PRSA	ARF2		ARFA		TAC		WPS		PRCA		WPC		EFFCA		
0.26064940	D1	0.4881720	05	0.3130330	D2	0.1347680	D1	D.1153940	D1	D.2789700	D0	D.2587900	D1	D.1644640	D1	D.6433120	D0	D.6433120	D0
0.1405670	02	0.6933380	03	0.46466440	D0	0.2447020	D0	0.9519970	D1	D.9234370	D1	D.1304300	D3	D.3190510	D3	WPC		WPC	
CP	GAMMA	0.1399300		01	0.1399300		00		0.1399300		00		0.1399300		00		0.1399300		

TABLE X - Continued

***** STATUS *****											
STAR	P02A	P03A	P03A	P03A	P03A	P03A	P03A	P03A	P03A	P03A	R/A/T
1	0.3677750 U2	0.3622420 02	0.6999980 03	0.2801160 02	0.4865230 U1	0.1499880 U1	0.1500000-01	0.2183170 01	0.802380 00	PERL3	A3
2	0.3555940 02	0.3505240 02	0.6442420 03	0.2803160 U2	0.4213770-01	0.1149880-01	0.1926160 00	0.2280000 01	0.838260 00	UPD/PU	A/R7
3	0.4511930 02	0.4510000 01	0.6930000 03	0.2801160 U2	0.4172640-01	0.1012700-01	0.2372320 01	0.271820 00	0.878180 00	PERL3	A3
4	0.3343300 32	0.3312490 02	0.6866100 03	0.2803160 U2	0.365180-01	0.921010D-02	0.5261140 00	0.2461730 01	0.905480 00	UPD/PU	A/R7
5	0.3296740 U2	0.3265210 02	0.6957460 03	0.2803160 U2	0.4624560-01	0.8946330-02	0.6463940 00	0.2547980 01	0.936731 00	PERL3	A3
6	0.3276370 02	0.3246210 02	0.714820 03	0.2803160 U2	0.3015940-01	0.9204850-02	0.5848860 01	0.4630940 01	0.947570 00	UPD/PU	A/R7
7	0.3116160 U2	0.3089290 02	0.7249220 03	0.2803160 U2	0.7253350-01	0.990750-02	0.9850000 00	0.2711820 01	0.996940 00	PERL3	A3
STAR	AL2	TMFTA	AL3	UAL2	SLO	OFAC75	OP/OS	OP/OS	OP/OS	OP/OS	OP/OS
1	0.3873160 U2	0.3873160 02	0.0	-0.9216360 01	0.2292500 01	0.2927310 00	0.2240080 00	0.1481350 01	0.0	0.0	0.0
2	0.3640210 U2	0.3640210 02	0.0	-0.9544870 01	0.220360 01	0.2871480 00	0.217540 00	0.8217580 00	0.0	0.0	0.0
3	0.3688820 U2	0.3688820 02	0.0	-0.8234420 01	0.2118960 01	0.2920000 00	0.2256040 00	0.482440 01	0.764060 00	0.0	0.0
4	0.3448590 02	0.3448590 02	0.0	-0.4855300 01	0.3120660 01	0.3120660 00	0.2236760 00	0.1502530 01	0.706100 00	0.0	0.0
5	0.3944230 U2	0.3944230 02	0.0	-0.4164280 01	0.1957600 01	0.3159590 00	0.222550-01	0.1504950 01	0.656324 00	0.0	0.0
6	0.4091220 U2	0.4091220 02	0.0	-0.2031910 01	0.18H1710 01	0.3206910 00	0.21259-01	0.1499160 01	0.634020 00	0.0	0.0
7	0.4596030 U2	0.4596030 02	0.0	0.35603160 01	0.1907500 01	0.3877400 00	0.26844290 00	0.1588740 01	0.5628860 00	0.0	0.0
STAR	AL2*	TMFTA*	AL3*	UV	EPS3	BC3	F-TANG	F-ANIAL	F-ANIAL	F-ANIAL	A-STRESS
1	0.4695000 02	0.4695000 02	0.0	0.0	0.0	0.1000000 01	0.0	0.0	0.0	0.0	0.0
2	0.4549870 U2	0.4549870 02	0.0	0.0	0.0	0.1000000 01	0.1362230 02	-0.405760 01	0.2193970 01	0.0	0.0
3	0.4512260 U2	0.4512260 02	0.0	0.0	0.0	0.1000000 01	0.1158020 02	-0.2296620 01	0.0	0.0	0.0
4	0.4636220 U2	0.4636220 02	0.0	0.0	0.0	0.1000000 01	0.104870 02	-0.3495750 01	0.2396820 01	0.0	0.0
5	0.4363630 U2	0.4363630 02	0.0	0.0	0.0	0.1000000 01	0.9361780 01	-0.3277760 01	0.248490 01	0.0	0.0
6	0.4249550 U2	0.4249550 02	0.0	0.0	0.0	0.1000000 01	0.8913320 01	-0.3140320 01	0.2580230 01	0.0	0.0
7	0.4249550 U2	0.4249550 02	0.0	0.0	0.0	0.1000000 01	0.77556090 01	-0.2945730 01	0.2667940 01	0.0	0.0
STAR	M2A	M3A	C24	C34	C34	CH3	CH3	CM3	CM3	CM3	CM3
1	0.7425040 U3	0.6167870 00	0.0	0.0	0.0	0.7649420 03	0.0	0.7649420 03	0.0	0.0	0.0
2	0.6868491 U3	0.57441220 00	0.0	0.0	0.0	0.7132290 03	0.0	0.7132290 03	0.0	0.0	0.0
3	0.6043060 U3	0.5395940 U0	0.0	0.0	0.0	0.67134350 03	0.0	0.67134350 03	0.0	0.0	0.0
4	0.5521850 U3	0.4945680 00	0.0	0.0	0.0	0.6152520 03	0.0	0.6152520 03	0.0	0.0	0.0
5	0.5621840 U3	0.4721450 00	0.0	0.0	0.0	0.5980850 03	0.0	0.5980850 03	0.0	0.0	0.0
6	0.54621970 U3	0.6280920 00	0.0	0.0	0.0	0.5932740 03	0.0	0.5932740 03	0.0	0.0	0.0
7	0.4620340 U3	0.3277780 00	0.0	0.0	0.0	0.4865660 03	0.0	0.4865660 03	0.0	0.0	0.0
STAR	PAS	IRS	EFFS	EFFS	EFFS	TMC	TMC	EFFC	EFFC	EFFC	EFFC
1	0.1165410 01	0.1165410 01	0.510650 00	0.510650 00	0.510650 00	0.1475980 01	0.1475980 01	0.705120 00	0.6167780 00	0.6167780 00	0.0
2	0.1335920 01	0.1153000 01	0.5427890 00	0.5427890 00	0.5427890 00	0.1465190 01	0.1465190 01	0.69361790 03	0.5744100 00	0.5744100 00	0.4994280 03
3	0.1354760 01	0.1153000 01	0.5927890 00	0.5927890 00	0.5927890 00	0.1462510 01	0.1462510 01	0.6768460 00	0.5359590 00	0.5359590 00	0.4751310 03
4	0.1359120 01	0.1157070 01	0.5927890 00	0.5927890 00	0.5927890 00	0.170480 01	0.170480 01	0.6403100 00	0.443680 00	0.443680 00	0.4675180 03
5	0.1345120 01	0.1154580 01	0.5711520 00	0.5711520 00	0.5711520 00	0.1488930 01	0.1488930 01	0.6056200 00	0.4721450 00	0.4721450 00	0.4480190 03
6	0.1299540 01	0.1152130 01	0.5864390 00	0.5864390 00	0.5864390 00	0.1527600 01	0.1527600 01	0.5570320 00	0.4426090 00	0.4426090 00	0.4554630 03
7	0.1204690 01	0.1152130 01	0.3590130 00	0.3590130 00	0.3590130 00	0.1561160 01	0.1561160 01	0.4901100 00	0.3227780 00	0.3227780 00	0.4312240 03
STAR	MCA2	MC/A3	PRSA	PRSA	PRSA	TASA	TASA	EFFC	EFFC	EFFC	EFFC
0.2092670 01	0.4680880 US	0.3595940 02	0.1314060 01	0.1154360 01	0.1154360 01	0.5554250 00	0.2259670 01	0.1485180 01	0.6342760 00	0.6342760 00	0.6342760 00
POIA	TU3A	PW13	PS13	PS13	PS13	AREA3	AREA3	CP	CP	CP	GAMMA
0.3568520 U2	0.6935770 03	0.5195760 00	0.21346560 00	0.1381000 01	0.8120830 01	0.2214960 00	0.1396550 01	0.0	0.0	0.0	0.0

TABLE XI
COMPUTER OUTPUT OF TRAVERSE DATA FOR COMPRESSOR - REDESIGN -
TEST NUMBER 18

***** 1MLFT *****									
RPM = 0.4931000 05									R/R7
P _{IN} = 0.3119000 01									
S744	PUL	T01	T01	P5	T5	A1	EP1	PBL	R1
1	0.1379000 02	0.6703000 03	0.1280900 02	0.4400710 03	0.0	0.0	0.0	0.5000000-02	0.1346900 01
2	0.1379000 02	0.6703000 03	0.1280900 02	0.4400710 03	0.0	0.0	0.0	0.4285710 00	0.4951840 00
3	0.1379000 02	0.6703000 03	0.1280900 02	0.4400710 03	0.0	0.0	0.0	0.4153200 00	0.4084140 00
4	0.1379000 02	0.6703000 03	0.1280900 02	0.4400710 03	0.0	0.0	0.0	0.3810100 00	0.3913430 01
5	0.1379000 02	0.6703000 03	0.1280900 02	0.4400710 03	0.0	0.0	0.0	0.2161810 00	0.2034610 00
6	0.1379000 02	0.6703000 03	0.1280900 02	0.4400710 03	0.0	0.0	0.0	0.1305980 00	0.1874450 00
7	0.1379000 02	0.6703000 03	0.1280900 02	0.4400710 03	0.0	0.0	0.0	0.0671160 00	0.0612230 00
S744M									
1	0.14327409 U1	0.0	CRI	CRI	U1	C41	MIA	RC	
2	0.14327409 U1	0.0	0.0	0.36427300 03	0.3325700 01	0.3642300 03	0.3261440 00	0.0	0.1000000 01
3	0.14327409 U1	0.0	0.0	0.36427300 03	0.34549840 03	0.3632300 03	0.3261440 00	0.0	0.1000000 01
4	0.14327409 U1	0.0	0.0	0.3632300 03	0.3563790 03	0.3632300 03	0.3261440 00	0.0	0.1000000 01
5	0.14327409 U1	0.0	0.0	0.3632300 03	0.44663970 03	0.3632300 03	0.3261440 00	0.5177530 00	0.1000000 01
6	0.14327409 U1	C.0	0.0	0.3632300 03	0.286710 03	0.3632300 03	0.3261440 00	0.208760 00	0.1000000 01
7	0.14327409 U1	0.0	0.0	0.3632300 03	0.1001000 04	0.3632300 03	0.3261440 00	0.3261440 00	0.1000000 01
MC41									
J.116374U1	0.97519461 U5	0.25590030 02	PDA	70A	PMI	MAB/1IP	AR/EA	AR/AC	
L.P.	Gamma							0.4926470 00	0.1760170 02
J.719273U 00	C.140137m 01							0.1742570 02	

TABLE XI - Continued

STRM	PUL*	PU2M		T01R		T02R		PS2		TA		PEAL2		B2		R/R7		
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
1	J.1636850 02	0.169210 02	0.439850 03	0.5100140 03	0.1599270 02	D.3904460 00	0.1000000-01	0.1744850 01	0.6414890 00	0.1744850 01	0.6414890 00	0.1744850 01	0.6414890 00	0.1744850 01	0.6414890 00	0.1744850 01	0.6414890 00	
2	0.1790970 02	0.1803800 02	0.5360490 03	0.5193830 03	0.1411730 02	D.3939760 00	D.2078790 00	0.1939760 01	0.1939760 01	0.1939760 01	0.1939760 01	0.1939760 01	0.1939760 01	0.1939760 01	0.1939760 01	0.1939760 01	0.1939760 01	
3	0.1912470 02	0.1836510 02	0.5180600 03	0.5286960 03	0.1563450 02	D.3690030 00	0.3863820 00	0.2115780 01	0.778610 00	0.2115780 01	0.778610 00	0.2115780 01	0.778610 00	0.2115780 01	0.778610 00	0.2115780 01	0.778610 00	
4	0.2095020 02	0.1859740 02	0.5301440 03	0.5388640 03	0.1895690 02	D.4257840 00	0.5527740 00	0.5527740 00	0.5527740 00	0.5527740 00	0.5527740 00	0.5527740 00	0.5527740 00	0.5527740 00	0.5527740 00	0.5527740 00		
5	0.2266530 02	0.1842790 02	0.5622260 03	0.5476130 03	0.1640910 02	D.5079540 00	D.7072490 00											
6	0.244710 02	0.1849310 02	0.5562360 03	0.5567750 03	0.1624230 02	D.5454280 00	D.8520270 00											
7	0.24816049 02	0.19552290 02	0.5663230 03	0.5663140 03	0.1720190 02	D.9043010 00	D.9700000 00											
STRM	B1	THE7A		S2		SLO		DFACTR		DP/DR		OEQIV		DM2				
1	0.2114910 02	C.5903190 02	-1054810 01	-1270910 02	D.2394000 01	D.2847810 00	D.3326390 00	D.1980910 01										
2	0.6212910 02	0.42211800 02	0.1311410 02	0.1205520 02	0.2275270 01	0.3657510 00	0.4015230 00	0.1541220 01	0.1541220 01	0.1541220 01	0.1541220 01	0.1541220 01	0.1541220 01	0.1541220 01	0.1541220 01	0.1541220 01	0.1541220 01	
3	0.6359810 02	0.4389510 02	0.2174110 02	0.2174110 02	0.2168050 01	0.4874340 00	0.4227860 00	0.69453740 00	0.69453740 00	0.69453740 00	0.69453740 00	0.69453740 00	0.69453740 00	0.69453740 00	0.69453740 00	0.69453740 00	0.69453740 00	
4	0.6793930 02	0.35495120 02	0.3248710 02	0.1090360 02	0.2068510 02	0.5736380 00	0.38664220 00	0.2077950 01	0.2077950 01	0.2077950 01	0.2077950 01	0.2077950 01	0.2077950 01	0.2077950 01	0.2077950 01	0.2077950 01	0.2077950 01	
5	0.6971200 02	0.23335750 02	0.23335750 02	0.4655460 02	0.1046270 02	0.1975650 01	0.4835990 00	0.3622180 00	0.4997070 00	0.4997070 00	0.4997070 00	0.4997070 00	0.4997070 00	0.4997070 00	0.4997070 00	0.4997070 00	0.4997070 00	
6	0.7110890 02	0.91227740 01	0.6198620 02	0.1008610 02	0.1884780 01	0.7586570 01	0.5522490 00	0.3231230 00	0.3231230 00	0.3231230 00	0.3231230 00	0.3231230 00	0.3231230 00	0.3231230 00	0.3231230 00	0.3231230 00	0.3231230 00	
7	0.7225510 02	0.62935900 01	0.6596420 02	0.97207070 01	0.1806000 01	0.7191660 00	0.3233480 00	0.2640760 01	0.2640760 01	0.2640760 01	0.2640760 01	0.2640760 01	0.2640760 01	0.2640760 01	0.2640760 01	0.2640760 01	0.2640760 01	
STRM	M1R	THE1A*		S1*		UV		EPS2		RC2		F-7 ANG		R-STRESS				
1	0.4449000 02	0.3535200D 02	0.9170000 01	-1102800 02	0.0	0.1000000 01	0.0	0.1000000 01	0.0	0.1000000 01	0.0	0.1000000 01	0.0	0.1000000 01	0.0	0.1000000 01	0.0	0.1000000 01
2	0.5027290 02	0.27881300 02	0.2244000 02	-9324660 02	0.0	D.1000000 01	D.1500000 02	D.2897130 01										
3	0.5416440 02	0.2162090 02	0.1251360 02	-107750 02	0.0	D.1000000 01	D.1000000 01	-1368850 02	-1368850 02	-1368850 02	-1368850 02	-1368850 02	-1368850 02	-1368850 02	-1368850 02	-1368850 02	-1368850 02	
4	0.6681170 02	0.1701130 02	0.4000130 02	-7512230 01	0.0	D.1000000 01	D.1000000 01	-1532230 01	-1532230 01	-1532230 01	-1532230 01	-1532230 01	-1532230 01	-1532230 01	-1532230 01	-1532230 01	-1532230 01	
5	0.5925910 02	0.1355150D 02	0.4668760 02	0.4668760 02	0.4668760 03	0.3184490 03	0.3184490 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	
6	0.6104580 02	0.10898600 02	0.5014910 02	0.1183710 02	0.0	D.1000000 01	D.1000000 01	-4227230 03	-4227230 03	-4227230 03	-4227230 03	-4227230 03	-4227230 03	-4227230 03	-4227230 03	-4227230 03	-4227230 03	
7	0.1070270 01	0.42727120 00	0.1126340 04	0.4495200D 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	
STRM	PAS	TAS		W2R		W3R		CM2		CM2		CR2		U2				
1	0.6020510 00	0.52271700 00	0.6335910 03	0.5682210 03	0.5682210 03	0.5682210 03	0.5682210 03	-1894320 02	0.567943D 03									
2	1.7021030 00	0.51656470 00	0.7390950 01	0.5935151 03	0.5935151 03	0.5935151 03	0.5935151 03	0.1324140 03	0.4683920 03	0.4683920 03	0.4683920 03	0.4683920 03	0.4683920 03	0.4683920 03	0.4683920 03	0.4683920 03	0.4683920 03	
3	0.7614310 00	0.51021740 00	0.5307490 03	0.5307490 03	0.5307490 03	0.5307490 03	0.5307490 03	0.1313220 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	
4	0.6681170 00	0.47426520 00	0.9138060 03	0.32262290 03	0.32262290 03	0.32262290 03	0.32262290 03	0.2825530 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	0.43471120 03	
5	0.9406020 00	0.41010360 00	0.4630680 03	0.4630680 03	0.4630680 03	0.4630680 03	0.4630680 03	0.3184490 03	0.3184490 03	0.3184490 03	0.3184490 03	0.3184490 03	0.3184490 03	0.3184490 03	0.3184490 03	0.3184490 03	0.3184490 03	
6	0.1007310 01	0.17013100 00	0.1640100 04	0.4227230 03	0.4227230 03	0.4227230 03	0.4227230 03	0.2732320 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	
7	0.1070270 01	0.42727120 00	0.1126340 04	0.4495200D 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	0.19557200 03	
STRM	MCR2	MCRA2		EFFS		PRC		TAC		EFFCA		M2		C42/Cx1				
0.2175640 01	0.4152210 05	0.2226960 02	0.1589760 01	0.1193740 01	0.732993D 00	0.1599860 01	0.1599860 01	0.1599860 01	0.1599860 01	0.15998								

TABLE XI - Continued

***** STATUS *****									
STEP#	PO2A	PO3A	T023A	P53	L5	OPO/FU	PERL3	R3	R/R7
1	0.2227070 02	0.218520 02	0.5518470 03	0.194950 02	0.5380730-01	0.200000D-01	0.150000D-01	0.1932000 01	0.702940 00
2	0.222310 02	0.217930 02	0.5515190 03	0.194950 02	0.5380730-01	0.200000D-01	0.150000D-01	0.2081020 01	0.7653710 00
3	0.2221340 02	0.2177110 02	0.5514910 03	0.194950 02	0.5352330-01	0.200000D-01	0.1575910 01	0.2220130 01	0.8164440 00
4	0.193670 02	0.2139360 02	0.5633390 03	0.194950 02	0.7433810-01	0.200000D-01	0.5402760 00	0.2352220 01	0.8647870 00
5	0.130110 02	0.2081410 02	0.5706210 03	0.194950 02	0.8709580-01	0.200000D-01	0.6959720 00	0.2476740 01	0.9105870 00
6	0.213180 02	0.2085550 02	0.5737940 03	0.194950 02	0.949400D-01	0.200000D-01	0.6432220 00	0.259460 01	0.9518980 00
7	0.214790U 02	0.2104940 02	0.5819810 03	0.194950 02	0.1004380 00	0.200000D-01	0.9850000 00	0.2270800 01	0.9955880 00
***** AL12 *****									
1	0.5127650 02	0.5127650 02	0.0	0.1336520 01	0.2288000 01	0.6633600 00	0.6644860 00	0.24747830 01	0.0
2	0.481510 02	0.481510 02	0.0	0.1366200 00	0.2138190 01	0.6394410 00	0.6305930 00	0.2355930 01	0.5090940 00
3	0.5088120 02	0.5088120 02	0.0	0.4408500 01	0.1988270 01	0.6335910 00	0.5990350 00	0.2264920 01	0.5861450 00
4	0.5435160 02	0.5435160 02	0.0	0.917550 01	0.1867780 01	0.6446370 00	0.6026630 00	0.2304440 01	0.5588310 00
5	0.6301020 02	0.6301020 02	0.0	0.892480 02	0.174260 01	0.7369550 00	0.6312200 00	0.2432410 01	0.4826400 00
6	0.7287920 02	0.7287920 02	0.0	0.2997400 02	0.1628190 02	0.7424940 00	0.7419980 01	0.24431500 00	0.4431500 00
7	0.7229400 02	0.7229400 02	0.0	0.2997400 02	0.1512000 01	0.7214380 00	0.2364620 00	0.2083760 01	0.4574360 00
***** AL2* *****									
1	0.499400 02	0.499400 02	0.0	0.0	0.0	0.1000000 01	0.1000000 01	0.0	0.0
2	0.4801740 02	0.4801740 02	0.0	0.0	0.0	0.1000000 01	0.1233240 02	-0.7697650 01	0.1924600 01
3	0.4664720 02	0.4664720 02	0.0	0.0	0.0	0.1000000 01	0.1153410 02	-0.6956930 01	0.2095920 01
4	0.4517620 02	0.4517620 02	0.0	0.0	0.0	0.1000000 01	0.1085900 02	-0.6556560 01	0.2216180 01
5	0.4601440 02	0.4601440 02	0.0	0.0	0.0	0.1000000 01	0.9330710 01	-0.6839100 01	0.2384950 01
6	0.4314440 02	0.4314440 02	0.0	0.0	0.0	0.1000000 01	0.7345410 01	-0.730350 01	0.2519310 01
7	0.4232000 02	0.4232000 02	0.0	0.0	0.0	0.1000000 01	0.3022200 01	-0.767760 01	0.26366750 01
***** M2A *****									
1	0.9422130 00	0.9422130 00	0.4458060 00	0.9018920 03	0.458060 03	CX3	CX3	CR3	F-AXIAL
2	0.7838940 00	0.7838940 00	0.4018740 00	0.8518470 03	0.4555320 03	0.0	0.4555320 03	0.0	0.0
3	0.7601830 00	0.7601830 00	0.4000030 00	0.8142450 03	0.4563350 03	0.0	0.4563350 03	0.0	0.0
4	0.6840190 00	0.6840190 00	0.3666660 00	0.7613330 03	0.4209390 03	0.0	0.4209390 03	0.0	0.0
5	0.6217860 00	0.6217860 00	0.3136860 00	0.7016880 03	0.3639140 03	0.0	0.3639140 03	0.0	0.0
6	0.5903640 00	0.5903640 00	0.3119350 00	0.6745200 03	0.3682800 03	0.0	0.3682800 03	0.0	0.0
7	0.5720200 00	0.5720200 00	0.3323440 00	0.63555860 03	0.3891460 03	0.0	0.3891460 03	0.0	0.0
***** PRS *****									
1	0.15d290 01	0.1113390 01	0.8106960 00	0.158290 01	0.1113390 01	EFFC	EFFC	M3	CU2
2	0.15d070 01	0.1127700 01	0.8110010 00	0.1580370 01	0.1127700 01	PRC	PRC	0.7639210 03	0.0
3	0.1578760 01	0.1187520 01	0.7451120 00	0.1578760 01	0.1187520 01	EFFSA	EFFSA	0.8231570 03	0.0
4	0.1551390 01	0.1197830 01	0.6774930 00	0.1551390 01	0.1197830 01	TRC	TRC	0.8708660 03	0.0
5	0.1513170 01	0.1113310 01	0.5910210 00	0.1513170 01	0.1213310 01	EFFCA	EFFCA	0.9300780 03	0.0
6	0.1514540 01	0.1222820 01	0.5622660 00	0.1511460 01	0.1232820 01	PRCA	PRCA	0.9733150 03	0.0
7	0.1526430 01	0.1231740 01	0.54222790 00	0.1526430 01	0.1231740 01	EFFCA	EFFCA	0.105920 04	0.0
***** MCRA *****									
0.2233640 01	0.43345450 05	0.2758400 02	0.1551940 01	0.1193110 01	0.6737190 00	AREE3	AREE3	0.1199110 01	0.6730240 00
PUJA	703A	PH13	PS13	AREA3	CP	GAMMA	GAMMA	0.11616160 02	0.2399650 00
0.2140130 02	0.5639420 03	0.4708960 00	0.5881610 00	0.11616160 01	0.1131170 02	0.1400100 01	0.1400100 01	0.2245310 03	0.0

TABLE XI - Continued

***** ROTOR 2*****												
STRM	PDIR	PD2R	TDIR	7D2R	PS2	IR	PERL2	R2	R/R1	R/R2	R/R3	
1	0.2932000	02	0.2054950	02	0.6095390	03	0.2332980	02	0.2341140	00	0.2094450	01
2	0.3044900	02	0.2868760	02	0.6154940	03	0.2367160	02	0.2331700	00	0.1958400	01
3	0.3185670	02	0.2902900	02	0.6228240	03	0.2428740	03	0.3155100	00	0.3664840	00
4	0.3259010	02	0.2882210	02	0.6355160	03	0.4399990	03	0.3496820	00	0.3304660	00
5	0.3306680	02	0.4937390	02	0.6506420	03	0.5366880	03	0.4811510	00	0.4235400	01
6	0.3617450	02	0.3071510	02	0.64676120	03	0.6692290	03	0.2554330	02	0.2525440	00
7	0.3580990	02	0.3094690	02	0.6776430	03	0.6778230	03	0.2486060	02	0.2618440	01
STRM	81	7NE7A	B2	801	SLD	DFACTR	DP/GK	DEQIV	DW2	DW3	DW4	
1	0.5902230	02	C.1056370	02	0.285360	02	0.3692300	01	0.3867350	00	0.3901370	00
2	0.6104000	02	D.2677370	02	0.3426630	02	0.3189880	01	0.2274770	01	0.1635000	01
3	0.6253940	02	D.2265900	02	0.3988050	02	0.4892770	01	0.2165450	01	0.3746330	00
4	0.6364930	02	D.117270	02	0.4647660	02	0.5327350	01	0.4491290	00	0.3619110	00
5	0.6961490	02	D.1830870	02	0.5130620	02	0.175220	01	0.2066360	01	0.3621500	01
6	0.7025310	02	D.1666610	02	0.5398700	02	0.0595950	01	0.51446420	00	0.3688790	00
7	0.7002750	02	D.1180202	02	0.5820700	02	0.6597250	01	0.1862180	01	0.4781950	00
STRM	81*	7NEA*	B2*	801*	DEV	EPS2	RC2	F-TANG	F-AXIAL	R-STRESS	R-STRESS	
1	0.5333000	02	D.2379000	02	0.2954000	02	-1.086340	01	0.0	0.1000000	01	0.0
2	0.5585010	02	D.2044280	02	0.3500730	02	-1.141010	01	0.0	0.1000000	01	-1.032240
3	0.5184660	02	D.1517290	02	0.4007380	02	-1.933210	01	0.0	0.1000000	01	-1.941240
4	0.5919190	02	D.1527790	02	0.4404400	02	0.2632340	01	0.0	0.1000000	01	-1.941240
5	0.6083970	02	D.1339510	02	0.4744460	02	0.3861610	01	0.0	0.1000000	01	-1.7334350
6	0.6219320	02	D.1184530	02	0.5034700	02	0.2339050	01	0.0	0.1000000	01	-1.051660
7	0.6333000	02	D.1056800	02	0.5285000	02	0.53557010	01	0.0	0.1000000	01	-1.6629770
STRM	MIR	M2R	WIR	M2R	WIR	CR2	WU2	CR2	U2	U2	U2	
1	0.7059950	00	D.54448870	00	D.8910C90	03	D.6405910	03	D.5632090	03	D.0	0.8301320
2	0.8299770	00	D.1312000	00	D.5907960	03	D.5193320	03	D.3052080	03	D.0	0.8751310
3	0.8614260	00	C.3302640	00	D.9895840	03	D.3341900	03	D.4388850	03	D.0	0.9176880
4	0.88687870	00	D.5036830	00	D.1020900	03	D.609320	03	D.4066400	03	D.0	0.9585910
5	0.9005480	00	D.5169310	00	D.1046760	04	D.6312420	03	D.39462260	03	D.0	0.9978190
6	0.9221830	00	D.5676820	00	D.1090020	04	D.6977590	03	D.5615270	03	D.0	0.1035340
7	0.9735680	00	D.3681680	04	D.1139280	04	D.7027890	03	D.3702650	03	D.0	0.1071760
STRM	PAS	TRS	EFFS	PRC	TRC	EFFC	M22	M22	M22	M22	M22	
1	0.1425760	01	C.1131670	01	D.8101890	00	0.2255650	01	0.1321890	01	0.4798480	00
2	0.1409900	01	D.1117940	01	D.7477390	00	0.2228160	01	0.1334460	01	0.4390330	00
3	0.1393510	01	D.1140070	01	D.7101010	00	0.2200620	01	0.1353860	01	0.7141240	00
4	0.1391830	01	D.1146690	01	D.6754710	00	0.2159240	01	0.1375540	01	0.6586410	00
5	0.1415000	01	D.114790	01	D.7075640	00	0.2141910	01	0.1392140	01	0.6208990	00
6	0.1413320	01	D.1141210	01	D.7598230	00	0.2140530	01	0.1406510	01	0.3369780	00
7	0.1388630	01	D.1145840	01	D.6744660	00	0.2119460	01	0.14117940	01	0.5129420	00
	MC42	MC82	MC/A2	PRSA	7ASA	EFFSA	PRSA	PRCA	TRCA	EFFCA	EFFCA	
J.16971920	01	0.4067720	05	0.2567390	02	0.1405960	01	0.1141210	01	0.7241640	00	
PD2A	712A	PH12	PS12	ARFA2	AREE2	HPS	HPS	HPS	HPS	HPS	HPS	
3.1008930	02	0.6435790	03	0.4511170	00	0.4116350	00	0.95119970	01	0.9234310	01	
CP	GAMMA											
0.2399650	00	0.1400100	01									

TABLE XI - Continued

***** STATOR *****										
1	P112A	P01A	T02A	0.31111720	0.2	0.1054760	0.2	0.6245090	0.3	
2	0.3022640	0.2	0.3025390	0.2	0.6275970	0.3	0.2666290	0.2	0.731740	0.1
3	0.3033810	D2	0.2943550	0.2	0.6362210	0.3	0.2666290	0.2	0.46468	'D-0.1
4	0.2977620	0.2	0.2943550	0.2	0.6459760	0.3	0.2666290	0.2	0.130315D	D-0.1
5	0.2953450	0.2	0.292393U	0.2	0.6547220	0.3	0.2666290	0.2	0.114417D	D-0.1
6	0.2925370	0.2	0.292393U	0.2	0.6616690	0.3	0.2666290	0.2	0.107610	-0.1
7	0.2977990	0.2	0.289934D	0.2	0.6668560	0.3	0.2666290	0.2	0.899059D	-0.2
8	0.2977990	D1	0.289934D	0.2	0.6668560	0.3	0.2666290	0.2	0.967570	0.0
9	0.2977990	D1	0.289934D	0.2	0.6668560	0.3	0.2666290	0.2	0.9500000	0.0
10	0.2977990	D1	0.289934D	0.2	0.6668560	0.3	0.2666290	0.2	0.2711020	0.1
11	0.2977990	D1	0.289934D	0.2	0.6668560	0.3	0.2666290	0.2	0.959940	0.0
12	0.4294620	0.2	0.4294620	0.2	0.4294620	0.2	0.229290	0.1	0.4541100	0.0
13	0.4310020	0.2	0.4510020	0.2	0.4510020	0.2	0.229290	0.1	0.4579000	0.0
14	0.4633950	0.2	0.4633950	0.2	0.4633950	0.2	0.2118940	0.1	0.4631880	0.0
15	0.5092080	0.2	0.5092080	0.2	0.5092080	0.2	0.4919070	0.0	0.478200	0.0
16	0.5200210	0.2	0.5200210	0.2	0.5200210	0.2	0.1957000	0.1	0.4956160	0.0
17	0.4884120	0.2	0.4884120	0.2	0.4884120	0.2	0.5045780	0.1	0.4316910	0.0
18	0.5202970	0.2	0.5202970	0.2	0.5202970	0.2	0.1881110	0.1	0.4094720	0.0
19	0.4240000	0.2	0.4240000	0.2	0.4240000	0.2	0.9029670	0.1	0.4756180	0.0
20	0.4240000	0.2	0.4240000	0.2	0.4240000	0.2	0.1807900	0.1	0.4125010	0.0
21	0.4645000	0.2	0.4645000	0.2	0.4645000	0.2	0.0	0.0	0.1500000	0.1
22	0.4538720	0.2	0.4538720	0.2	0.4538720	0.2	0.0	0.0	0.1500000	0.1
23	0.4517260	0.2	0.4517260	0.2	0.4517260	0.2	0.0	0.0	0.1500000	0.1
24	0.4434220	0.2	0.4434220	0.2	0.4434220	0.2	0.0	0.0	0.1500000	0.1
25	0.4361620	0.2	0.4361620	0.2	0.4361620	0.2	0.0	0.0	0.1500000	0.1
26	0.5249340	0.2	0.5249340	0.2	0.5249340	0.2	0.0	0.0	0.1500000	0.1
27	0.5120300	0.0	0.5120300	0.0	0.5120300	0.0	0.0	0.0	0.1500000	0.1
28	0.4865321	0.3	0.4865321	0.3	0.4865321	0.3	0.4353890	0.3	0.4353890	0.3
29	PAS	TNS	C2A	C3A	C4A	C5A	C6A	C7A	C8A	C9A
30	EFFFS	PAC	TRC	EFFFC	M13	M13	M13	M13	M13	M13
31	0.1199650	0.1	0.1113160	0.1	0.1059040	0.0	0.2215200	0.1	0.132780	0.0
32	0.1384310	0.1	0.113740	0.1	0.715570	0.0	0.2194050	0.1	0.1334460	0.0
33	0.1373350	0.1	0.114007D	0.1	0.6007330	0.0	0.2171350	0.1	0.1352160	0.0
34	0.1375420	0.1	0.114007D	0.1	0.6568730	0.0	0.2134550	0.1	0.1377540	0.0
35	0.1407740	0.1	0.147790	0.1	0.6859120	0.0	0.2120330	0.1	0.1392140	0.1
36	0.1406670	0.1	0.1141210	0.1	0.7151640	0.0	0.2121370	0.1	0.1406910	0.1
37	0.1377410	0.1	0.1145940	0.1	0.65773380	0.0	0.2102520	0.1	0.1417940	0.1
38	MC41	MC42	MC/A3	PMSA	TASA	EFFSA	PACA	TACA	EFFCA	U3
39	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.1143300	0.1
40	P01A	P01A	PML3	PM13	PS13	AREA3	CP	GAMA	EFFCA	U3
41	0.2469340	D7	0.4441460	D3	0.4441460	0.0	0.3962770	0.0	0.831060	0.1
42	0.2469340	D7	0.4441460	D3	0.4441460	0.0	0.8129630	0.1	0.2408030	0.0
43	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
44	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
45	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
46	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
47	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
48	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
49	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
50	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
51	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
52	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
53	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
54	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
55	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
56	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
57	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
58	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
59	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
60	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
61	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
62	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
63	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
64	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
65	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
66	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
67	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
68	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
69	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
70	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
71	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
72	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
73	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
74	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
75	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
76	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
77	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
78	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
79	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
80	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
81	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
82	0.1171730	D1	0.4065300	D5	0.2936500	0.2	0.1987460	0.1	0.136970	0.1
83	0.117									

Unclassified

Security Classification		
DOCUMENT CONTROL DATA - R & D		
(Security classification of title, body of abstract and indexing annotation must be entered when the overall report is classified)		
1. ORIGINATING ACTIVITY (Corporate author)		2a. REPORT SECURITY CLASSIFICATION Unclassified
Continental Aviation and Engineering Corporation Detroit, Michigan		2b. GROUP
3. REPORT TITLE ADVANCEMENT OF SMALL GAS TURBINE COMPONENT TECHNOLOGY		
4. DESCRIPTIVE NOTES (Type of report and inclusive dates) Final Report		
5. AUTHOR(S) (First name, middle initial, last name) James V. Davis Edmund J. Dellert		
6. REPORT DATE February 1970	7a. TOTAL NO. OF PAGES 171	7b. NO. OF REFS
8a. CONTRACT OR GRANT NO. DA 44-177-AMC-296(T)	8b. ORIGINATOR'S REPORT NUMBER(S) USAAVLABS Technical Report 69-10B	
8c. PROJECT NO. 1G162203D14413	8d. OTHER REPORT NO(S) (Any other numbers that may be assigned to this report)	
10. DISTRIBUTION STATEMENT This document is subject to special export controls, and each transmittal to foreign governments or foreign nationals may be made only with prior approval of U. S. Army Aviation Materiel Laboratories, Fort Eustis, Virginia 23604.		
11. SUPPLEMENTARY NOTES Volume II of a 2-volume report	12. SPONSORING MILITARY ACTIVITY U. S. Army Aviation Materiel Laboratories Fort Eustis, Virginia	
13. ABSTRACT This report presents the redesign analysis of a two-stage axial compressor program for the advancement of small gas turbine component technology. The discussion covers fabrication, test, and redesign of the axial compressor which was presented in Volume I. The Continental-redesigned compressor demonstrated a potential for a 0.457-pound-per-horsepower-hour SFC turboshaft engine at 2500°F turbine inlet temperature. It exceeded the contract objective by demonstrating 80 percent efficiency at 3.1:1 pressure ratio with a 4.91-lb/sec airflow.		

DD FORM 1 NOV 66 1473 REPLACES DD FORM 1473, 1 JAN 64, WHICH IS
OOGLETE FOR ARMY USE.

Unclassified

Security Classification

Unclassified

Security Classification

14. KEY WORDS	LINK A		LINK B		LINK C	
	ROLE	WT	ROLE	WT	ROLE	WT
Axial Compressor Design Component Technology Small Gas Turbine						

Unclassified

Security Classification